

Trimble 3600 Zeiss Elta

Basic & Expert Software User Guide



Part no.: 571 703 011



1	Trimble 3600 The System	Operation 1-1
		Switching the instrument on and off..... 1-2
		Zeiss Elta® keyboard..... 1-5
		Graphic display 1-7
		Laser Plummet (Option) 1-8
		Menu guidance 1-9
		Help function 1-11
		Distance Mode (Option 3600 DR) 1-12
		EDM Mode and reflector typ 1-14
		When using EDM Modes?..... 1-15
		Direct Reflex Distanzmessung..... 1-16
		Prism and Addition Constants 1-19
		Software overview 1-20
		Modular structure of the system software 1-21
2	First Steps	Before Measurement..... 2-2
		Set Up and Centering..... 2-2
		Levelling and Fine Centering..... 2-3
		Telescope Focussing 2-4
		Check-List 2-5
		Project Management..... 2-6
		Create a New Project..... 2-6
		Select an existing Project 2-6
		Connect Projects 2-6
		Edit a Project..... 2-7
		Delete, Rename, and Copy a Project 2-7
		Project Information 2-7

Measuring in a Local System.....2-8
Principle 2-8
Input of Parameters 2-8
Input of the Point Identification Pl..... 2-11
Using Codelists 2-11
Indirect Survey 2-12
Hidden Point Measurement..... 2-14
Object Height Measurement 2-15
Vertical Plane 2-16
Control Point Measuring 2-17
Hz-Circle Orientation..... 2-17
Corrections of the Measured 2-18
Further Switches and Technical Matters . 2-19

3 Stationing

Free Stationing.....3-2
Principle 3-2
Free Stationing Measurement 3-3
Adjustment Procedure..... 3-6
Configuration of Free Stationing 3-9
Neighbourhood principle and Distance Re-
ductions..... 3-11
Error Handling 3-12
Heightstationing 3-13
Results of the Free Stationing..... 3-14

Stationing on a Known Point.....3-15
Principle 3-15
Orientation through Backsight
Measurement..... 3-16
Orientation through input
and measurement of a bearing 3-17
Results of Stationing on a Known Point.. 3-18

Heightstationing3-19
Principle 3-19
Measurement and Adjustment.....3-20
Entering a height value 3-20
Results of the Heightstationing 3-21

Eccentric Stationing3-22
Principle 3-22
Measurement Eccentric Station 3-23

4 Coordinates

Detail Points.....4-2
Principle 4-2
Inirect Survey 4-3
Hidden Point Measurement..... 4-5
Object Height Measurement 4-6
Vertikal Plane 4-7
Connecting Distances..... 4-8
2 Face Measurement..... 4-8
Value Corrections..... 4-9

Setting Out.....4-10
Principle 4-10
Rectangular Coordinates 4-10
Station Check..... 4-13

5	Advanced Applications	Point-to-Line Distance 5-2
		Principle 5-2
		Measuring in a local system 5-3
		Measuring in a coordinate system 5-5
6	Data Management	Editor 6-2
		Principle 6-2
		Entering a data record 6-3
		Editing a data record 6-4
		Filtering of records 6-5
		Searching for data records 6-8
		Deleting data records 6-11
		Further function keys 6-13
		Data Transfer 6-14
		Principle 6-14
		Hyperterminal Settings 6-16
		Data transmission 6-17
		Data reception 6-18
		Zeiss Control Center 6-19
		Data Format 6-20
		M5 data format 6-20
		M5 data line 6-20

7	Adjustment	Adjustment 7-1
		Adjustment methods 7-2
		Instrument errors and their correction..... 7-3
		Adjusting V-Index / Hz-Collimation..... 7-4
		Adjusting Compensator 7-6
		DR EDM System 7-7
8	Configuration	Configuration..... 8-1
		Operation in the submenus..... 8-2
		Configuration Instrument 8-3
		Overview Instrument Configuration..... 8-3
		Instrument Type, EDM Calibration..... 8-4
		Illumination, Periphery 8-5
		Adjustments, Units..... 8-6
		Reference System 8-7
		Recording 8-8
		Error Limits, Operation 8-9
		Alphanumeric-Input 8-9
		Clock, On-Off Configuration 8-10
		Language, Batteries..... 8-11
		Default Settings 8-12

- Configuration Programs 8-13**
 - Overview Configuration Stationing..... 8-13
 - Free Stationing 8-14
 - Heightstationing 8-17
 - Overview Configuration Coordinates..... 8-18
 - Setting Out 8-19
 - Overview Configuration Special..... 8-20
 - Point to Line Distances 8-20
 - Overview Configuration
 - General Functions 8-21
 - 2-Face Measuring 8-22
 - Control Point..... 8-23
 - Konfiguration functions Distance 8-24
 - Configuration..... 8-25
 - Configuration Standard Settings 8-25

- Configuration Markings 8-26**
 - Principle 8-26
 - Processing of set markings 8-27
 - Generating new Markings..... 8-28
 - Store marking 8-35

- Konfiguration Codelisten 8-36**
 - Codelisten bearbeiten 8-36
 - Neue Codelisten erzeugen..... 8-38
 - Codelisten editieren 8-38

- Configuration Update 8-41**
 - Input of Authorisation Code 8-41

9 Annex

- Symbols and keys.....9-2**
 - Symbols for instrument settings 9-2
 - Keys and Function..... 9-3

- Geodetic Glossary9-5**

- Technical Data.....9-12**
 - External Interface Port 9-12

- Formulae and Constants9-13**
 - Computations formulae for angle measurement..... 9-13
 - Computations formulae for distance measurement..... 9-14
 - Reduction formulae 9-15
 - Verifying on Calibration Distances..... 9-17

- Further available Documentation9-18**

Main Menu *and Pages*

- **1 Project Management *Page 3-6***
- **2 Adjustment *Page 8-1***
 - 21 Instrument Corrections *Page 8-3*
 - 22 Compensator *Seite 8-4*
- **3 Measure *Page 3-8***
- **4 Stationing *Page 4-1***
 - 41 Free Stationing *Page 4-2*
 - 42 Stationing on known Point *Page 4-15*
 - 43 Eccentric Stationing *Page 4-22*
 - 44 Heightstationing *Page 4-19*
- **5 Coordinates *Page 5-1***
 - 51 Detail Points *Page 5-2*
 - 52 Setting Out *Page 5-7*
 - 53 Traverse
 - 54 Intersections of Lines
 - 55 Intersections of Arcs
 - 56 Transformations
 - 57 Roadline Lite
- **6 Special *Page 6-1***
 - 61 Multiple Rounds
 - 62 Point-to-Line Distances *Page 6-2*
 - 63 3D-Plane
 - 64 Area Calculation
 - 65 Connecting Distances
- **7 Editor *Page 7-2***
- **8 Data Transfer *Page 7-14***
- **9 Configuration *Page 9-1***
 - 91 Instrument *Page 9-3*
 - 92 Programs *Page 9-13*
 - 93 Markings *Page 9-25*
 - 94 Codelists *Page 9-35*
 - 95 Update *Page 9-40*
 - 96 Standard Settings *Page 9-24*
- **0 Remote Control *Page 10-8***

This chapter gives you an overview of the **Control Unit** Zeiss Elta.

It describes the operation and controls of the instrument with the Control Unit as well as the sensors and peripheries which are a special feature of the Trimble 3600 Total Stations.

Operation

Software Overview

Switching the instrument on and off

Switching the instrument on

When you press the **PWR** key, the startup logo is briefly displayed:

Display of






- Instrument type
- Instrument serial no.
- Software release data

Trimble System 3600	100000
Version 1.10	
Date Feb. 15 2001	
Time 10:10:00	
(C) Geom. Systems GmbH 1997 2001	

Unless otherwise defined in the configuration, this is followed by the display of the main menu of the Trimble 3600 Zeiss Elta software:

Main Menu		PROJECT	
Proj. Management	1	Special	6
Adjustment	2	Editor	7
Measure	3	Data Transfer	8
Stationing	4	Configuration	9
Coordinates	5	Remote Control	0

The project last processed is loaded and displayed. If there is no project stored on the data drive D:\DATEN on the PC, a project named "NONAME" will be automatically opened.

Use     to select the application and press  to start the program. A shorter way is to use the hotkey numbers 1 - 0 to start the application directly from main menu.



Configuration


Instrument
On/Off Configur.

Station Input

The instrument configuration permits you to define which functions should be executed after the PC is booted or which menu should be directly accessed by the program. There are two options:

After starting the application *Measure* (in a local system) the program goes directly to the station input with input parameters like point identification, instrument height, reflector height, temperature, air pressure or type of prism.


Levelling After loading the Trimble 3600 software the program goes automatically to the levelling menu.



Press any key to exit this menu.

Hard- and Software Scan


Starting the program checks automatically for all necessary Hard- and Software Components are rightly installed and set. If not, a message like this appears:



e.g.: Missing configuration data.
Default values will be set.

Switching the instrument off

Esc in the main menu to quit the program after answering the inquiry:



Yes Quitting the program; the instrument is automatically shut off.

DOS Quitting the program, back to the Trimble 3600 System Control Menu.

No Return to the main menu.

Trimble 3600 System Control Menu




The following actions are possible from this control menu:

- Trimble 3600 Starts the Software
- Remote Service Update Service Program
- DOS Change to the MS-DOS®
Prompt D:\ELTAC\BIN>_
- C_XXXXXX Calls up an installed API Program
(XXXXXX = Name)
- OFF \ AUS Switches the instrument off.

⚠ Attention !








A change to the MS-DOS® prompt from the System Controller needs to change another keyboard mode.

Zeiss Elta® keyboard



Dual assignments (yellow function keys) can be activated with the shift key (2).







Keys and their functions

-  **Esc** 1 Escape
Quitting program levels
-  2 Shift
Dual assignment switchover
-  3 Function keys
Instrument Control and Softkey activation (in the display above)
-  4 Cursor keys
Cursors positioning
-  5 Space key
Space and selector key
-  **Tab** 6 Tabulator
Selector and tab key
-  7 Enter key
Confirmation and triggering of measurement


- 4** 8 Numeric block
Alphanumeric Input
- PWR** 9 Power key
Switching the instrument on
- Fcn** 10 Function key
Softkey activation in the measurement programs

Instrument Control

The yellow signed symbols above the function keys 1-6 are used for controlling of significant instrument switches and parameters and can be activated pressing Shift + key:

-  Illumination Crosshair + Display On / Off
-  Instrument Levelling
-  Battery Control
-  PositionLight On / Off
- Help** Online-Help
-  EDM Mode
-  Laser Pointer

Alphanumeric Input

The keys 1-9 have multiple assignments for entering numbers and letters as well. Capitals can be activated by simultaneous pressing of the  Shift key. Multiple pressing of the key in an input field displays the 4 characters associated to the key. At first the alpha characters will be displayed following by the key number. The exception is pure numeric fields (as defined in the Marking) where only the number is displayed.

Further key functions



Annex Symbols and keys



   = „B“
press shortly Shift + 2x

    = „7“
press shortly 4x



Configuration Markings



Configuration

Instrument






Switches


Alphanumeric Input

Throughout the software, the keys will be automatically assigned (e.g. Target height input is only possible in numerics).


The frequency of multiple key pressing for the alphanumeric input can be configured user optimized in the instrument configuration.

Softkeys

In every measurement menu the lower display row is filled with softkeys. They can be activated (deactivated) by pressing the  F key and can be switched by the 6 function keys below and the keys    and .

The key  is for toggling the next available softkey row (→1 / →2 / →3).

Important Note

If the Softkeys are activated, the numerical key block for entering an alpha-numerical point identification is locked. Press  again to unlock.

Fon

Graphic display



Configuration

Instrument

Switches

The display is a LCD screen with 320 x 80 pixels in the display window.

You can switch on the display and the crosshair illumination using either the illumination switch or the hotkey



Tip


Contrast variation is also possible.

Laser Plummet (Option)

The Laser Plummet is used to center the instrument over a station point. The plummet is a Laser Pen with an additional optical element which illustrates a center circle on the ground. The instrument has to be moved on the tripod head for centering over the station point.

The Laser Center Circle has a diameter of 45 mm at an instrument height of 1,5 m.

The Laser Plummet can be switched on from the configuration menu or calling up the levelling menu of the Instrument.



Yes The Laser Plummet is switched on until exit the levelling menu.

No No switch on.


⚠ Attention!

Never look directly into the laser beam!
Please read the given warnings and hints for laser beam safety in this chapter.

Menu guidance

Menus support the user at any stage of the program.

Options menu




Key:

- 1 Menu number
- 2 Menu title
- 3 Project name or address
- 4 Selection cursor
- 5 Option + number
- 6 Additional data
- 7 Meas./comp.values
- 8 Marking
- 9 Point identification
- 10 Function keys
- 11 Status symbols
- 12 Next of function keys

To select an option, use either the selection cursor plus or the appropriate hotkey for the option number.

Measurement menu



Switch on/off the function keys with **Fcn.**

1-6 for the first 6 Softkeys.

7 8 9 0 for Softkeys 7-10.

and for navigation between the input fields for PI and target height.

or to start the measurement.

Input menu

9243 Control Point Error Limits			
Linear Dev.	dr :	<input type="text" value="0.030"/>	m
Angle Dev.	da :	0.0050	gon
Orthog. Dev.	dq :	0.020	m
Lateral Dev.	dl :	0.020	m



can be used in the input field.



ends the entry.

Switch menu

9133 Correction Switches	
Tilt Compensation	<input type="checkbox"/> On
Index Correction	<input type="checkbox"/> On
Collimation Correction	<input type="checkbox"/> On
Atmospheric Corrections	<input type="checkbox"/> On

Key:

- 13 Input option
- 14 Input field cursor
- 15 Switch
- 16 Switch field
- 17 Error number
- 18 Error type
- 19 Error information

For toggling, use the (space bar) key in the switch field.

Error messages in the display

Error 123456	Instr. Corr. Standard Limits Exceeded
Index Correction lil > 50 mgon	
Press any key to continue...	

Lists

Key:

- 20 List cursor
- 21 Function keys

414 Residuals L2				s = free	
Nr.	vy[m]	vx[m]	vr[m]		
1	-0.005	0.001	0.005		
2	-0.002	-0.005	0.006		
e 3	0.007	0.004	0.008		

Mode More :BP Del. New SP-A Scl.e Rst.t L1-R ↵2

20 21

    for scrolling.


All 10 Softkeys are activated automatically in the list menu.

Quitting the menu

You can quit all menus with **Esc**. If any entries have been made or edited, an inquiry is first displayed as to whether the changes should be saved.

Help function


The integrated on-line help is available in all program parts. The help function will be called using the hotkey

 + **Help** at any point of the program.

Help	
5 Coordinates	
—	51 Detail Points
—	52 Setting Out

Operation

Distance Mode (Option 3600 DR)



Note
Laser Pointer and EDM mode switches via Hotkey are only possible in measurement menus.

Default EDM Mode:
 **Prism Mode**

Note
After instrument start the EDM Mode is set to Prism Mode PM.

Swtp Configuration Instrument Periphery Switches.

EDM Mode:


DR = Direct Reflex Mode
PR = Prism Mode

Switches

In the Configuration Menu the EDM functions can also be switched ON or OFF. Enter to configuration menu **9132** or use the softkey **Swtp** in the measurement menus:






Use  space key to toggle

Press  to save settings.



In measurement menu the actual settings are displayed in the instrument status window.

The following EDM modes are possible:

-  Direct Reflex mode.
The „reflectorless“ mode.
-  Direct Reflex mode.
The reflector „high power“ mode.
-  Prism mode.
The reflector mode.

In measurement menus the EDM Mode can be switched using the hotkey

 + .


The Laser Pointer can be switched ON/OFF using the hotkey  + .


EDM Mode and reflector typ

The EDM modes are combined with reflector types set in the Input Menu of the measurement program. To enter this menu, press **Fcn** to activate the softkeys and press softkey **Inpt**:

Inpt Input Menu

Input of Parameters			
R.Type :	Normal	Temp. :	6 °C
Ref1. :	1.300 m	Press :	969 hPa
Inst. :	1.705 m	PrismC :	-30 mm
Scale :	1.000000	ppm :	0


Use  space key to toggle between reflector types Normal Prism, 360° round Prism, Foil and None Reflector.

Press  to save settings.

Note

If Prism Mode is set, only one of the three reflectors can be selected. A „None reflector“ type can be activated only in EDM DR mode.

The last used mode will be stored and activated again after reload the program.



When using EDM Modes ?



Direct Reflex Mode (reflectorless)

When measuring without prisms or other reflectors. The prism constant and reflector height is set to Zero (default). If needed both values can be changed in the Input Menu for the „None“ reflector type.

Measuring Range: 1,5 ... 80 m (depending on the object surface and light conditions)



Prism Mode

When measuring to prisms or other reflectors like foil. The prism constant and reflector height refers to the actual selected reflector type and can be changed in the Input Menu.

Measuring Range: 0 ... 2500 m (for one prism)
0,5 ... 100 m (for foil reflector)



Direct Reflex Mode (prism high power)

When measuring to prisms or other reflectors at large distances or bad weather conditions. The prism constant and reflector height refers to the actual selected reflector type and can be changed in the Input Menu.

Measuring Range: 1000 ... 5000 m (for one prism)
0 ... 500 m (for foil reflector)

Note

Prisms should be measured in Prism Mode, because the EDM is then not so sensitive to disturbing influences and has the highest accuracy.

Direct Reflex Distance Measurement



Appendix Technical Data

The values given in the technischen Datenblatt concerning accuracy, range and measurement time depend on the following effects:

EDM Modes:



- Atmospheric influences (sight conditions, rain, wavering heat)
- Radiation of the sun at the aim
- Disruption of the beam by moving objects


To ensure a maximum result in distance measurement a time out (of the measuring time) has been set to max. 50 secs. This way even at bad conditions greater distances can be measured. Usually however a measurement takes 2 seconds.

Tip

If there are unfavourable sighting distances or measuring conditions, you should await the time – out of the measurement. Every measurement taken within that time matches the accuracies granted for this mode of measurement.

The range of unambiguity of an indicated measurement covers up to 9 km using Prism Mode as well as Direct Reflex Mode.

When measuring in Direct Reflex Mode the following measuring range at the target is significant for a measured distance of 50 meters.



When aiming at a target at a distance of approx. 150 m the signal range is approx. 0.13 gon in V resp. 0,09 gon in Hz.. This allows an aiming range of approx. 300 mm in V resp 210 mm in Hz to grant a secure distance measurement. To make sure that there is always enough signal no distance measurement should be taken out of this range.


⚠ Attention !

When using Direct Reflex Mode avoid any interruptions of the beam. If the beam is interrupted while measuring (e.g. shortly by moving objects) the measured distance has to be checked by remeasuring.

DSet

Activation of multiple measurement

You can avoid incorrect distance measurement by activating multiple measurement in the measurement program. This is especially advisable when measuring across much used roads.



When measuring on surfaces with edges within the EDM range you have to make sure to definitely aim at the surface you want to be measured.

Tip

To separately measure angle and distance or indirectly determine points – „Eccentricity“.

When measuring greater distances the accuracy of the distance measurement depends on the correction of the atmospheric influences such as temperature pressure and humidity. In order to restrict the atmospheric correction to exactly 1ppm (mm/km) temperature has to be determined up to 1°C, pressure up to 4hPa and humidity up to 20% along the measuring section.

The correction formulas are given in the appendix.



Appendix



Formulas and constants

Tip

Using Direct Reflex Mode be aware of a minimum distance of 1.5 m. If there are unfavourable conditions you cannot fall short of this minimum distance.

Prism and Addition Constants

The input function for prism constants has been changed with the software version 1.36 (Elta S, Trimble 5600 with Zeiss Elta® Control Unit) and 1.06 (Trimble 3600). The first reason was to have conformity between all total stations in the Trimble Group. The second reason was conformity to the way in which prisms are marked.

Now it is necessary to enter the prism constant, and the addition constant isn't readable.

The calculation and the save function were not modified, only the method used to display.

Prism constants K:

Carl Zeiss :

KTO	-35 mm
KTR	-35 mm
KTM	-35 mm
Mini prism Kit	-18 mm
360°Prism	- 3 mm

Spectra Precision

Super prism	0 mm
Prism ring	2 mm

It is necessary to enter the correct value.

In case of measurements to reflectors of other manufacturers the user has to enter the prism constant and check the correctness by measurements to known distances.

Storage:

The connection between addition constant A and prism constant is shown in the following calculation formula:


$$A = P_F + 35 \text{ mm}$$

Example:


Foreign reflector prism constant $P_F = -30 \text{ mm}$

Addition constant in connection with this foreign reflector $A = + 5 \text{ mm}$


Software overview



Main Menu



Modular structure of the system software



The Trimble 3600 modular software comprises four packages. Thanks to the full MS-DOS® compatibility of the Elta® PC, you can integrate your own software while making allowance for the programming interfaces.

The *Basic* package provides the basis for *Expert*, i.e. *Expert* enhances the functionality.

Basic

The *Basic* software is standard in all hardware packages and offers the following functions:

- Project management
- Adjustment
- Measurement in a local system
- Editor
- Data transfer
- Configuration

Expert

The software with the basic functions for surveying in coordinates.

- Stationing
 - Free Stationing
 - Stationing on a known point
 - Eccentric Stationing
 - Heightstationing
- Coordinates
 - Detail Points
 - Setting Out
- Special
 - Point-to-line distance

The *Expert* module can be optionally enhanced by the *Professional* and *Special* upgrades.

Professional

Professional surveying with

- Coordinates
 - Traverse
 - Transformation
 - Intersection of Lines
 - Intersection of Arcs
- Special
 - Area calculation
 - Connecting distances

Professional Plus!

The Plus! Package in Detail Points program which allows to make Verification Points by either point number or position. It´s a great tool for controlling the quality of surveys.

Special

For special tasks in surveying such as

- Coordinates
 - RoadLine Lite
- Special
 - Multiple Rounds
 - 3D Plane

The first steps cover the setup and check of the instrument. The data is stored projectwise, and is controlled via the *Project Management*.


In the Program *Measuring in a Local System*, one can measure using all functions of the Trimble™ 3600 series Total Station.

Before Measurement

Project Management

Measuring in a Local System

Set Up and Centering



⚠ Attention !

In order to guarantee the stability of measurement we recommend the use of a Tripod and an Tribrach from Trimble.

Setup:

Fix the the tripod legs (1) over the required point using the tripod locking screw (2). Screw the instrument tribrach to the tripod head (3).

Centering:


With the tripod set over the station point, look through the optical plummet (5) and position the center over the station point using the tribrach screws (4).

⚠ Attention !

For precise measurement it is necessary to control the tribrach-instrument connection.

1. Make sure, that the tribrach is stabil and OK.
2. Set the instrument on the tribrach correctly.
3. Lock the DIN tribrach screw strong enough.

Levelling and Fine Centering




Coarse Levelling:

Level the Circular Bubble (6) by adjusting the tripod legs (1).

Fine Levelling:

The digital fine levelling is accessed using the hotkey for the levelling menu:




The inclination values displayed are in the same unit as set in instrument configuration.



Adjustment
Compensator



Configuration
Instrument



Position the instrument parallel to two of the tribrach screws. Turn the two tribrach screws together in opposite directions, and the third alone. Level the instrument in the Trunnion Axis (1) and Sighting Axis (2). Turn the instrument to check the verticality of the instrument. The Mis-Levelling should be within the working range of the compensator (± 0.092 grad).

After adjustment press **Esc** to return to the program screen.

Fine Centering:

Check the final position over the point. Move the instrument on the tripod head and repeat the fine levelling if necessary.

Telescope Focussing

Focussing the Cross Hairs:

With the telescope focussed on Infinity, bring the cross hairs into focus.

⚠ Attention !

Do not use the telescope to look at the sun or other bright and concentrated light sources or you risk permanent eye damage.










👁 Tip

Check the telescope Parallax: Move the position of your eye slightly whilst looking through the telescope. If the cross hairs are not correctly focussed they will appear to move. If this occurs, refocus the crosshairs as above.

Before Measurement

Check-List

Before measuring, it is a good idea to check the status of the instrument. You will find the symbols in the display are very helpful. It will also be useful to use the following check List:

1. **Set Up OK ?**
 - Levelling, Centering
2. **Adjustment OK ?**
 - V-Index- and Hz-Collimation
 - Compensator run center point
3. **Data OK ?**
 - Enough internal memory ?
4. **EDM Mode ?**
 - DR or PR Mode 
 - Laserpointer On ? 
5. **Battery OK ?**
 - Battery Strength  , use  
6. **Project OK ?**
 - Is the current Project OK ?
7. **Switches OK ?**
Configuration / Instrument / Switches /
 - Compensation activated  ?
 - Units / Decimal Points are set ?
 - Measure system  OK ?
 - Recording  on ?
 - Recording mode R-C, R-M, R-MC selected?
 - Measure mode  selected?


Project Management

Create a New Project

Proj.-Management 1

 or **1** to select from the main menu.

New to create a new project. Input a new project name and


 to confirm.


1 Project Management				ZOTTELST
PROJ_F	9801	11_02_97	12826	
BACKLEBN	18029	12_02_97	9922	
TAMBACH	43681	NONAME	20086	
GESTERN	11011	JENA	16940	
10_02_97	28677	ZOTTELST	19481	

New Del Conn Copy Name Info Edit

The Projects and their file size are displayed in the project screen (121 Byte per Data Line).

Select an existing Project

 Select the Project with the cursor keys.

 to confirm as the current Project.

Tip

Scrol with **PgUp, PgDn, Home, End** . Edit Project data with the **Edit** softkey.

Connect Projects

Conn to connect one Project with another.

Project TAMBACH combine with	
HO	Project TAMBACH combine with
PR	
BA	Project JENA
GE	
10	Yes No

Attention !

After connection, the Project („JENA“) will be completely integrated and still exists on as a separate project file.

Project Management

Edit a Project

Edit to call the editor

 **Data Management Editor**

7 Editor				HOCHTIEF
1	DDKS	9303	4104	
2	DDKS	9303	4104	
3	DDKS	9303	4102	
4	DDKS	9303	4101	
5	DDKS	9302	4106	

Inprt Del Edit Srch Adr. PNR Rept. Filtr *2

Editor Menu.

Delete, Rename, and Copy a Project

Del Delete Project

Name Rename Project

Copy Copy Project

1 Project Management		HOCHTIEF
HO	Copy Project	
ST	A:\TAMBACH.DAT	
PR	Project exists !	
BA	Press any key to continue...	
IF		

New Del Conn Copy Name Info Edit

⚠ Attention !

It is not possible to rename or copy a Project if the same name exists.

Project Information

Info Input the Project Information.

18 Edit Project Info		ZOTTELST
Project	Zottelstedt	
Proj.-Nr.	98-0815-4711	
Detailer	Mr. Smith	
Observer	Mrs. Black	
Reflector	KTR 1 N	

Input of up to 10 Information lines in each Project Information. 16 alphanumeric characters per line.





PgUp **PgDn** to select the other page.

18 Edit Project Info		ZOTTELST
Instr.type	E1ta S10 Point	
Instr.Nr.	112 214	
Date	17/01/98	
Remark	Setting Out	
Remark	Main Street No.3	

Measuring in a Local System


Measure 3









Mode Press to toggle the measure mode:




-  SD Hz V
-  HD Hz h
-  y x z
-  Hz V

to copy the last measurement (measure buffer) and the PI with respect to the measure and registration mode to the current project.

Rec



3 Measure		Adr: 598	
s 1.000000	SD 123.457 m		
ih 1.690 m	HZ 8.8238 gon		
th 1.560 m	V1 100.0034 gon		
10013 Corner Point			
<---PNr---><---Info--->			
Mode	Rec	Io+I	R-M
Ecc	HtdP	Imp	Code
D:N	→2		


-  or  to start measuring,
-  to directly input the target height.

Tip




Use MODE and Rec to store different measure values without remeasuring the point.

Input of Parameters



Inpt Input

- (1) Instrument and Target Height
- (2) Prism Constants
- (3) Temperature and Pressure
- (4) Scale Factor of Local System / pip
- (5) Reflector Type ( to select)

Input of Parameters	
R.Type: Normal	Temp.: 20 °C
Ref1.: 0.000 m	
Inst.: 0.000 m	Press.: 1013 hPa
	PrismC: -35 mm
Scale: 1.000000	ppm: 0

-   to select,  to confirm.

Tip

For each reflector type a reflector height and a prism constant will be stored. If the type of reflector was changed, the last reflector height input for this reflector type is selected automatically. For controlling this leave the reflector type toggle field by pressing  or .

The local scale factor will be used to correct the distance measurements in a local system.

Default: $s = 1.000\ 000$

The scale factor of the local system will not be that calculated using the stationing routines. Entering a local scale factor will only effect measurements in a local system.

The values of addition and prism constant and the values of Scale Factor and PPM are connected. Changing one value will effect the other partner value.

If in the Instrument Switch Configuration the Thermometer are **On**, it is not possible to edit this value. The auto-measured value will be displayed.

R-MC

Recording Mode




Recording **On**
Configuration
Instrument
Switches

- (1) **R-M** for original measured data
- (2) **R-C** for computed data
- (3) **R-MC** for meas. and computed data

Selection of the Record mode is only possible when the recording Configuration is switch to **On**.


Measuring in a Local System

Ioff Incrementation of the point number On / Off

 $-9999 \leq \text{Inc} \leq 9999$




Set the increment step.

 to accept.


Tip

The furthest numerical part on the right of the point number will be incremented. For the incrementation it is necessary, that the point number can be moved to the left in the point number block of the marking.

Changing the Marking will cause the Incrementation to be switched off.



If the point number 99 was entered on the left side of the block, it cannot be incremented to 100. Then the following error message appears:



The incrementation will be automatically switched off. For an incrementation from 99 up to 100 it is necessary, to enter the number more to the right in the block.


Input of the Point Identification PI

Use the cursors to navigate the input field.

Switch between code fields using **Tab**.

Input the PI using the keyboard or a Codelist.

Mark Changes the actual marking



Configuration Marking

Input field of the Point Identification PI (27 characters) with freely configurable fields.

Using Codelists

Code Call Codelist

To activate this softkey, the PI field must have a codelist already attached to it (as defined during the Configuration of the Marking).

The cursor must be positioned within the required code field.



Example: Codelist *ROAD_points_18*

Configuration Codelists

Select the required Code with **↑** and **←**.


The correct Code is then implemented in the PI field.


Measuring in a Local System

Indirect Survey



Ecc. Eccentricity / Intersection




 toggling between options.

Type: Eccentricity


Type: Intersection

Eccentricity


 Length $L < 100$ m




Reflector Offset:




right of




left of




front of




behind



slope (in sighting axis)
to the Center.



 toggling between options.

Mode **Once** for a one off Measurement,


Mode **Perm** for a permanent eccentricity,

Mode **Off** to cancel.


- Height **On** To use the height of the eccentric point in position left, right, front of or behind to the center. The center height is calculated for a slope eccentric.
- Off** no height coordinate.

Intersection


Case of measurement:




Angle/Dist.




general



perpend.



Eccentricity		
	Type	: Intersection
	Case	: Separated D
	Mode	Off

 toggling between options.

- Mode **Once** for a one off Measurement,
- Mode **Perm** for a permanent eccentricity,
- Mode **Off** to cancel.

⚠ Attention !

If the height difference between the eccentric point in position left, right, front of or behind to the center is large, then set the height to **Off**.


The function **Ecc.** is not available during the Hidden Point Measurement.

Measuring in a Local System

Hidden Point Measurement




HidP Hidden Point



R2-P Distance between the reflector R2 and the Prism Point P

R1-R2 Distance between the Reflectors R1 and R2 on the Prism Rod.

Hidden Point	
	Mode : Once R2 - P : 0.655 m R1 - R2 : 1.855 m Tolerance : 0.003 m




Modes: see Eccentric Measurement



Tolerance: Error limit used to check the accuracy of the measurement of R1 - R2.

Default Value: 0.003 m

If the error limit is exceeded a message appears.

Record Mode - Hidden Point:

-  R-M
-  R-M, R-C, R-MC
-  R-M, R-C, R-MC

3 Hidden Point: Ref1 R1				Adr: 166				
R1	2.510 m	SD	100.120 m					
ih	1.750 m	HZ	112.3468 90H					
R2	0.655 m	V1	101.4688 90H					
100512		Channel No 5						
<---PNr---><---Info--->								
Mode	Rec	Ion	R-M	HidP	Inpt	Code	Srch	52

The program guides the user through the measurement of R1 and R2.

The height Z_p will always be calculated from $Z_{STATION}$, ih and R1-R2-P values.

Measuring in a Local System

Object Height Measurement



ObjH After measuring to one reference point in Mode:




SD Hz V

HD Hz h

y x z

is this softkey accessible.



The Reference Point defines the line of the Instrument - Reflector (I-R) and the vertical plane normal to I-R. It is then possible using only the angle measurement **HzV** to define heights and offsets in the plane:

HD Horizontal Distance I-R

O Perpendicular position L-R (90° to I-R)

h Object Height from R

3 Measure				Adr: 598
s	1.000000	SD	123.457 m	
ih	1.690 m	Hz	8.8238 gon	
th	1.560 m	V1	100.0034 gon	
10027 Reference Pn				
<---Pnr---><---Info--->				
Mode Rec Io ff R-M Ecc HidP Inpt Code D:N →2				

Measure Reference Point with .
Eccentric measuring is also possible.

3 Measure Object Height				Adr: 169
		HD	135.807 m	
		O	21.025 m	
		h	20.508 m	
700500 Object Height				
<---Pnr---><---Info--->				
Mode Rec Io n R-MC				

to measure Object Height + Offset in Hz V measure mode.

Toggle the **Mode** softkey to see **HD Hz h** and record with **Rec**:

Measuring in a Local System

- HD** Horizontal Distance I-L
- h** Height difference with respect to Station I

Vertical Plane



ObjH

After measuring to two reference points in Mode



D Hz V





E Hz h



y x z

is this function accessible.



Measuring 2 points P_E will define a vertical plane. Once the plane is established, points in the plane P_i can be measured only by the use of angles . There is no need to measure a distance. The coordinates of P_i are measured in the defined Coordinate System.

Measure Reference Point or .



Toggle the **Mode** softkey to see **HD Hz h** and record with **Rec**:

- h** Height difference with respect to Station

Measuring in a Local System

Control Point Measuring



CtrlP Control Point

Define 2

To set a Control Point (CtrlP). The measurement is available in all measuring modes:

5131 Define Control Point		
s	1.000000	SD 123.457 m
ih	1.690 m	HZ 8.8238 gon
th	1.560 m	V1 100.0034 gon
100431 Control Point		
<---PNr---><---Info--->		
Mode	Edit	Mark SwtC SwtP →

Sight CtrlP, Measure with or .

Check 1

Sighting and checking a CtrlP is possible in every measurement routine:

5133 Control Point		
d1[m]	da[gon]	dq[m]
-0.001	-0.0002	0.000
Mode	Rec	New
CtrlP		

Mode switch to **dr**

New Repeat Measure

Cfg Configuration
Error Limits CtrlP

Configuration
Programs

Results of CtrlP Measuring with :

d1	Length misclosure	[m]
da	Angle misclosure	[gon] (Hz)
dq	Cross misclosure	[m]
dr	Radial misclosure	[m]

Hz-Circle Orientation

HzOr Call up

Hz-Or. input,	
	HZ 100.0000 gon
1013 Hz-Orientat.	
<---PNr---><---Info--->	
Info	Mark Code

Input the Hz direction.

Configuration
Instrument
Switches
Reference System

Sight the direction, or to measure and set the new Hz-Orientation. In the Instrument Configuration the recording of original Hz-Circle readings or oriented Hz-Directions can be defined.

Corrections of the Measured Values

The measured values will be subjected to the following corrections:

- Influence of Temperature and Pressure (SD)
- Prism Constant (SD)
- Inclination of the Vertical Axis (HzV)
- Horizontal Collimation + Vertical Index (HzV)
- Trunnion axis (Hz)
- Circle Eccentricity (HzV)

The calculated values (HD, h, x, y, z) will be computed from the corrected measured values and are corrected by the configured local scale factor.

Sw1C

With this switch, One can toggle the various corrections **On** and **Off**.

9133 Correction Switches	
Tilt Compensation	On
Index Correction	On
Collimation Correction	On
Atmospheric Corrections	On

Toggle with  , Confirm with  .

After switching on the instrument all corrections are switched to **On**.



Compensator **On**

When the Compensator is switched on, the compensator symbol will be displayed.

⚠ Attention !

In order to improve the accuracy of the temperature measurement, the instrument should not be subject to direct sunlight.


 **Technical Tips** in [Further switches and Technical Matters](#)

Measuring in a Local System

Further Switches and Technical Matters



SwtP Periphery Switches

-  PositionLight **On**
- Laserpointer **On**
- Laser Plummet **On**

9132 Periphery Switches			
PositionLight	OFF		
EDM Mode	PR	Laserp.Off	Once
		Sound	On
Thermometer	On	Laser Plummet	Off

Zon Height **On / Off**

Info Input info line up to 27 characters.

Mark Change the actual Marking.

Technical Tips

The Temperature, Pressure and Humidity will have the following influence on the Distance accuracy:

- $\Delta t \pm 1 \text{ }^\circ\text{C}$ $\pm 1 \text{ ppm}$ (parts per million)
- $\Delta p \pm 4 \text{ hPa}$ $\pm 1 \text{ pip}$
- $\Delta h \pm 20\%$ $\pm 1 \text{ ppm}$

1Fce Measurement in 1

2Fce or 2 faces.

Error	Measure in 2 Faces	Measure Accept ?
	Limits Exceeded	
d1 =	0.0000 m	
dHz =	0.0000 gon	
dV =	-0.2400 gon	Yes No

The measurement values and mean values of measurement in face 1 and face 2 will be computed and stored as defined in the program configuration. If the error limits are exceeded, comes

Yes To accept and save the mean value.

No No saving. New measurement is possible.

Measuring in a Local System

D:N Toggle the distance meter Mode: **Normal / Rapid Tracking**

Technical Tips

The different measuring modes have the measuring times / accuracy:




Annex Technical Data



PR Mode:

Dset Configuration multiple measurements for distance meter mode N




Setting the standard deviation and/or a number of shots



Dset Configuration multiple measurements for distance meter mode N

DR Mode:



Setting a limit between the shots and/or a number of shots

In order to operate the instrument in a coordinate system, it is necessary to position and orientate the instrument within the system.

Free Stationing

Stationing on a Known Point

Heightstationing


Eccentric Stationing




Free Stationing


Stationing 4

Free Station. 1

If it is not possible to occupy a point with a known position, one can carry out a free Station.



-  : $BP_{YX(Z)}$
-  : $SDHzV_{S-BP}$ or HzV_{S-BP}
-  : $S_{YX(Z)}, Om, s$


 $2 \leq BP \leq 20$


Through measuring up to 20 known Backsight Points, the instrument will calculate the station position, the circle orientation **Om** and the scale factor **s**.

The program is separated into the plane adjustment and the height adjustment.

In order to calculate the station height, the instrument height **ih** and the target height **th** must be measured.

411 Station		Adr: 256
s	1.000000	
ih	1.750 m	
113 12 1962 Free Station		
<---PNr---><---Info--->		
Edit Info		Mark Code SwtP

 to input the instrument height **ih**.



 to confirm input of the station name.

Proj Change projects to recall BP's from another.

 see **Editor** for other functions.

After the coordinate filter, select the required BP

412 Backsight 1				PROJNAME
1	9	2714	0077	Backsight Pnt
2	9	2714	0061	Backsight Pnt
3	7	0429	4022	Backsight Pnt
4	8	0429	4032	Backsight Pnt
25	8	0429	5077	Center Pnt Z
Proj Inpt				Edit Srch Adr. PNr Filt

  Select first Backsight Point.


Free Stationing


Inpt to input a new BP


If BP is not in list, input BP:

72 Input		Adr : 257
Y	564738.255 m	
X	403500.582 m	
Z	-9999.000 m	
37904		BP5
<---PNr--->		>---Info---
Mode	loff	Info
		Mark
		Code

Mode for switching between YXZ, SDHzV and HDHzh.

 Z = -9999.000 for points without known height


Select the input fields with .


Record with . End Input with **Esc**.

Free Stationing Measurement



Mode Toggle measure mode **SDHzV / HzV**


 BP with distance measurement



 BP without distance measurement

413 Measure Backsight		Adr : 606
Nr.	1	SD 127.890 m
ih	1.690 m	Hz 205.3256 son
th	1.560 m	V1 97.7623 son
4013		Backsight Pn
<---PNr--->		>---Info---
Mode	R-M	Ecc. HidP Inpt Code
		→2

Start BP measurement with  or .

Tip

With Cursor  it is possible to edit the target height **th**.

For a proper calculation it is possible to have a minimum of 2 BPs measured with  or 3 BPs measured with only . Therefore:

 Select the second BP and measure.

You will then see the first adjustment screen:

Free Stationing

More to measure further BPs

→ 2 + **PI** to show the PI

± BP Off/On to skip the BP measurement

? AP Call up the point for intermediate Setting Out

414 Residuals L2				s = free
Nr.	vy[m]	vx[m]	vr[m]	
1	0.000	0.000	0.000	
2	0.000	0.000	0.000	



Mode More :BP Del New SP-A Scl. Rslt L1-A →2

The residuals here are zero, as this kind of selected adjustment method requires a third point for the residual computation.

It is possible to remove BPs from the adjustment to check their influence for the adjustment.

414 Residuals L2				s = fixed
Nr.	vl[m]	va[gon]	va[m]	
1	-0.001	-0.0009	-0.003	
2	-0.001	0.0009	0.013	
3	-0.001	0.0009	0.013	

More :BP Del New Helm Scl. Rslt L1-A →2

Use the cursors   to select the point and then **±BP**. The adjustment will be recalculated. Pressing the function key again, this point comes back into the adjustment.

If more points will be removed than required for the calculation, the following notice will be displayed:

Error	Free Stationing
More Backsights necessary	
Press any key to continue...	

The program will automatically allow the measurement of further BPs as an adjustment.

413 Measure Backsight			Adr: 21
Nr.	3	SD	141.421 m
in	0.000 m	HZ	150.0000 gon
th	0.000 m	V1	100.0000 gon
003			
<---PNr---><---Info--->			
Mode	:BP	R-M	Ecc. HidP Inpt. Code Srch →2

Free Stationing

Tip

If further BPs are not required for the calculation, the program will go immediately to the adjustment.

Del will mark the point with a **d** to be deleted

New New adjustment

414 Residuals L2				s = free
Nr.	vy[m]	vx[m]	vr[m]	
1	-0.010	-0.002	0.011	
2	0.011	-0.004	0.011	
3	0.000	0.003	0.003	
d 4	0.000	0.003	0.003	

Mode More #BP Del. New SP-A Scl. Rst. L1-A #2

BPs marked with a **d** are removed from the adjustment, and will be deleted when a new adjustment computation is needed or selected.

Rec to record the current adjustment and result

Tip

Rec will allow the storage of intermediate adjustments and results that will not be stored with the final calculation.

Rslt Results Display

Coordinate Position
Y, X (sy, sx)

Circle shift
Om (so)

Scale Factor
s (ss)

The display screen will show the result of the Free Stationing and the standard deviations:

415 Single Point Adjustment				s = free
sy	0.011 m	Y	470631.749 m	
sx	0.007 m	X	1088033.975 m	
so	0.0007 30n	Om	392.5653 30n	
ss	0.000012	S	0.996346	

Press any key to continue...

You will then return to the adjustment menu.

Adjustment Procedure

The Least Squares Adjustment (L2 Norm) has 2 variations:

- (1) **Single Point Adjustment**
- (2) **Helmert Transformation**

Measured distances will always be adjusted with a scale factor $s = 1.000\ 000$.

The adjustment menu will allow the selection of both adjustment methods. That means that the results can be seen from both adjustment types.

The switch is fixed when

- when the Configuration Change is set to Off,
- Measurement without distances, or less than two distance measurements (switch from SP-A to Helmert-Transf.)

The Residual Menu

414 Residuals L2				s = free
Nr.	vl[m]	va[gon]	va[m]	
1	0.000	-0.0006	-0.002	
2	0.000	-0.0011	-0.007	
e 3	0.000	0.0017	0.026	

More :BP Del New Helm Scl.e Rst.t L1-A ↵2

The adjustment L2-Norm with a default setting of single point adjustment.

L1-A Switch to an adjustment with Σ absolute Residuals → Min (L1-Norm)

Tip

An "e" in the first column means that the residual is outside the error limits set in the Configuration.

L1-A Norm will allow the detection of a gross error in one of the BP measurements. This can then be deleted, and a new adjustment calculated.

Helm Switch to Helmert Transformation

Helmert Transformation

Measurements to the BPs require a distance measurement in order that this adjustment type can be used.

The Helmert Transformation has the same weighting for direction and distance.

Adjustment:

vy y-coordinate
vx x-coordinate
vr radial

414 Residuals L2				s = free
Nr.	vy[m]	vx[m]	vr[m]	
1	-0.010	-0.002	0.010	
2	0.010	-0.004	0.011	
3	0.000	0.006	0.006	

Mode More :BP Del New SP-A Scl. Rst.t L1-A #2

Adjustment L2-Norm of the Helmert Transformation. A BP without distance measurement will not be used.

Mode Is used within Helmert Transformation to switch between **vl, va, vq**

Tip

Mode: Compare with the residuals of the single point adjustment..

SP-A Switch to Single Point Adjustment

Single Point Adjustment

With SP-A it is possible to control error limits and direction and distance weighting in the Configuration menu. It is also possible to have BPs without a distance measurement.

414 Residuals L2				s = free
Nr.	vl[m]	va[gon]	vq[m]	
1	0.000	-0.0009	-0.003	
2	0.001	-0.0016	-0.010	
3	0.000	0.0012	0.019	
e 4		0.0012	0.021	

Mode More :BP Del New Helm Scl. Rst.t L1-A #2


Residuals of the SPA:

vl is only displayed for points with a distance.

vl Residuals in length
va Residual in angle bearing
vq Residual in normal to direction

Free Stationing

Scle Scale Factor **Free** or **Fixed**



← after input.


Standard: $s = \text{free}$

Default value $s = \text{fixed}$: 1.000000

Choosing a fixed scale factor will recall the scale range values set in the Configuration.

If $s = \text{Free}$, then a scale factor is computed for the adjustment.

If the scale factor input is outside the scale range values set in the Configuration, then the following screen is displayed:



i.e.: ± 5000 ppm scale range value.

Tip

If the scale factor is **fixed** the number of unknowns of the adjustment decreases. I.e. even for the minimum geometry (2 BP's with Helmert Transformation) residuals can be computed.

You also can detect a faulty scale factor due to displaced BP's or measurement errors, as such errors normally have an impact on a free scale factor.

Scle to switch back

Pressing **Scle** again sets the scale free and the adjustment will be computed again.

Configuration of Free Stationing

Cfg Configuration
Free Stationing

Setting of standard deviations for both observations and centering define the weighting within the SP-A.

9211 Free Stationing			
Adjustment Type	1	Scale Range	6
Stand. Deviation	2		
Error Limits	3		
Adjustment	4		
Reductions	5		

Configuration menu Free Stationing.

Stand. Deviation 2

92112 Single Point Adjust.		
Orientation	:	0.0003 gon
Distances constant	:	0.003 m
Distances linear	:	0 ppm
Levelling	:	0.000 m

Default values are given as below:

Accuracy of directions:

Directions: 0.0003 gon

Accuracy of distances:

Distance, constant: 0.001 m

Distance, linear: 0 ppm

Accuracy of centering:

Centering of target: 0.000 m

Tip

When you enter 0.0, the appropriate parameter has no impact on weighting.

The weights are used for the SP-A only, but not for the Helmert Transformation.



Free Stationing

Cfg Configuration
Free Stationing

Adjustment Type 1

You can define as a standard, whether to use the **SP-A** or the **Helmert Transformation** and also whether to have a **fixed** or a **free** scale factor.

92111 Free Station. Adjustment Type	
Calculations :	Single Point Adjustment
Change :	On
Scale :	free
Change :	On

Select with , confirm with .

If **Change** is **Off**, you cannot change between different types of adjustments in your stationing.

Error Limits 3

Possibility to change error limits, without necessarily breaking off your stationing process.

92113 Free Stat. Error Limits				
		s=fix	s=free	
Linear Dev.	vr	0.040	0.030	m
Angle Dev.	va	0.0050	0.0050	gon
Orthog. Dev.	vq	0.030	0.020	m
Lateral Dev.	vl	0.030	0.020	m

Select with  , confirm with .

The error limits will only be used, if the switch **Error Limits** is set to **On** within the configuration menu.


 **Configuration**
Instrument
Switch

Scale Range 6

Defining the range within which a scale factor will only be accepted.

The scale factor might change within the stationing process.

92116 Stationing Scale range	
Scale Range : ±	1500 ppm

 $-9999 \leq SR \leq 9999$

Example: ± 1500 ppm would accept scale factors of $0.998500 < s < 1.001500$ as a result of the stationing. So for distances of 100 m you would accept deviations of ± 0.15 m.

Neighbourhood principle and Distance Reductions

Cfg Configuration
Free Stationing

Adjustment 4

The residuals for all BP's of stationing will proportionally be spread over the coordinate space for all detail points and set out points, in order to comply to the so-called neighbourhood principle.

Reductions 5

Measured distances can be corrected for projections into the Gauss-Krueger or the UTM system. They can also be corrected by a reduction from the site height to the mean sea level.

92114 Stationing Adjustment	
Mode	: Weight by distance
Weight exponent n	: 2.0 p=1/D ⁿ

Mode: Off / Distance weights
n: 0.5 / 1 / 1.5 / 2

The residuals are spread according to distance dependent weights which are applied to a weighted average. So the coordinates of any new measured point are corrected by that individually averaged value.

Tip

The higher the value of **n**, the smaller the impact of a far distanced BP.

92115 Reductions	
Height	: On
Projection	: Gauss-Krueger

Height : On / Off
Projection: Gauss-Krueger / UTM / Off


If distance reductions are applied, they are used additionally to the existing scale factor **s**. In that case the scale factor **s** only represents tensions of the BP network and uncertainties in the measurements.

Attention !

Make sure that the Reductions are set ON or OFF during both Stationing and on-board coordinate computations!


Error Handling

If at the end of your stationing error limits are exceeded for any BP, you will find that BP marked by e in column 1 and see the message:



- Yes** Accept stationing despite the errors.
- No** Back to displaying the residuals.

If the preset range for the scale factor is exceeded, the following display appears:



- Yes** Stationing is cancelled.
- No** Return to displaying the residuals. Solve the problem or extend the acceptance range for the scale.

In case of a SP-A with directions measured only to 3 BP's, the software checks the standpoint and the 3 BP's not to be approximately located on a circle (no solution possible).

👉 Attention !

If stand point and 3 BP's are on a circle and only directions are measured, there is a warning.

You can solve the problem by at least 1 additional distance measurement.

Heightstationing

After 2D stationing, a height stationing can be carried out using the BP measurements. At least one BP must have a known height value that was measured.

If no BP has a height value, it is possible to carry out a separate heightstationing from the stationing menu.

414 Residuals 1? e - free	
Nr	Free Stationing
e	Heightstationing ?
	Yes No
More :BP Del New Helm Sclt Rstt L1-A *2	

No The results of the Free Station will be 2D.

Yes The height of the Free Station will be calculated from the BP measurements and the program goes into the adjustment menu of the height stationing.

Heightstationing

If it is not possible to compute the height from the measured points of the planimetric stationing, then a normal Heightstationing follows.

After Heightstationing the final stationing result will be displayed:

417 Stationing OK?		
s	0.999963	Y 3398800.264 m
ih	1.650 m	X 5589314.299 m
		Z 111.435 m
1000	Free Station	Yes No
<----PNr-----><---Info----		


Attention !

No The complete stationing (plane stationing as well) will be ignored.

Yes Free Stationing results will be stored.

Results of the Free Stationing

Esc to exit the Free Stationing program:



No Remain in the adjustment menu.

Yes If the results of the Free Station are okay, then it is possible to go exit to the results display.



Error Handling

The program will check the computed residuals against the error limits set in the Configuration.

Results Display

417 Stationing OK?		
S 0.999942	Y 470631.745 m	
ih 1.750 m	X 1088033.971 m	
	Z 490.745 m	
113 12 1962 Free Station		Yes No

Results Display of the Free Stationing in 3D.

Yes to record the results and use the coordinate orientation.


No Cancel the results of the Free Stationing without saving.


Stationing on a Known Point


Stationing 4


Stat. known. Pnt. 2

By measuring up to a maximum of 20 Backsight Points from a known coordinate, it is possible to achieve position and orientation of the instrument within a coordinate system.

 1 ≤ BP ≤ 20



 : $S_{YX(Z)}, BP_{YX(Z)}$

 : $SDHzV_{S-BP}$ or HZV_{S-BP}

 : Om, s

The circle orientation shift **Om** and the scale factor **s** will be computed.

If no height coordinate is available for the known point, it is possible to compute a Heightstationing.

Selecting Known Station


Coordinate points are filtered into the editor ready for selection:

421 Station				PROJNAME
1	9	2714	0077	Backsight Pnt
2	9	2714	0061	Backsight Pnt
3	7	0429	4022	Backsight Pnt
4	8	0429	4032	Known Station
25	8	0429	5077	Center Pnt Z

Proj Inpt Edit Srch Adr. PNr Filt


Proj to select a point from another project


Inpt to input a new station coordinate

If the required station is not in the file, it is possible to manually enter the data into the editor. Select the known point with .

422 Station				Adr: 259
S	1.000000	Y	470431.740 m	
ih	1.250 m	X	1068033.970 m	
		Z	349.740 m	
8 0429 4032 Known Station				
<---PNr--->>---Info---				

Edit Info Mark Code SwtP

 see **Editor** for other functions


 to input the instrument height **ih**.

 to confirm the station.

Stationing on a Known Point

Orientation of the known station is through:

- (1) **Backsight Points**
- (2) **Input of a horizontal angle value**



Select with and press .

Orientation through Backsight Measurement



Backsight(s) 1

Free Stationing Measurement and Adjustment

Select and measure up to 20 BPs from the Project:

424 Backsight 1				PROJNAME
1	9	2714	0077	Backsight Pnt
2	9	2714	0061	Backsight Pnt
3	7	0429	4022	Backsight Pnt
4	8	0429	4032	Known Station
25	8	0429	5077	Center Pnt Z

Proj. Inpt. Edit. Srch. Adr. PNr. Filt.

Select with and press .

If BP = Station, comes the message:

424 Backsight 1		PROJNAME
Stat. Known. Pnt.		
Stat. and point identical		
Select New		
Press any key to continue...		

Proj. Inpt. Srch. Adr. PNr. Filt.

After measurement to the first BP, the Residual Screen will be shown.

More Measure further Backsights

Press **More** to call up and measure further Backsight Points.

426 Residuals L2				s = free
Nr.	vl[m]	va[gon]	va[m]	
1	0.002	0.0004	0.001	
2	-0.002	-0.0020	-0.013	
e 3	-0.007	0.0016	0.025	

More :BP Del. New Sclt. Rslt. L1-A ↵2

Residual Screen. Softkeys similar Free Stationing.

Stationing on a Kown Point

If there is a distance measurement to one BP, a scale can be computed.

Rslt Results display


427 Stat. Knwn. Pnt.		s = free	
SO	0.0010 gon	Y	470631.740 m
SS	0.000005	X	1088033.970 m
		Om	392.5644 gon
		S	0.999944
Press any key to continue...			

The display screen will show the results of the Stationing and the standard deviations:

- Circle shift **Om** (so)
- Scale factor **s** (ss)

Cfg Configuration of Stationing on a known point

9212 Stat. on Known Point	
Stand. Deviation 1	
Error Limits	2
Adjustment	3
Reductions	4
Scale Range	5







 **Configuration Programs**



The Configuration is the same as that for Free Stationing.

Orientation through input and measurement of a bearing

Input a Hz - Value 2

Input a bearing angle A_{pi} .

Input Hz-value: Measure		Adr: 608	
	Hz 147.1367 gon	 	
773000	Hz Direction	  	
<---PNr---> <---Info--->			
Info	Mark	Code	

 to input ,  to measure and orientate the Hz-Circle.

After orientation, the results of the stationing are displayed.

Stationing on a Known Point

Results of Stationing on a Known Point



Heightstationing

Esc from the residual screen to exit. If no height is known for the station, then the height-stationing routine will be automatically called.



Free Stationing Error Handling

The program will check the stationing results against the set error limits.

417 Stationing OK?		
ih 1.750 m	Y 470631.740 m X 1088033.970 m Z 490.729 m	
8 0429 4032 Known Station		Yes <input type="checkbox"/> No <input type="checkbox"/>

Results display of a 3D Stationing of a known station point.

Check the results,

Yes to save the results, implement the orientation and exit the program.


No Leave the Stationing without saving the results.


Heightstationing


Stationing 4


Heightstation. 4


The heightstationing is used in conjunction with a 2D stationing or as a separate menu program.

 1 ≤ BP ≤ 20



 : $BP_{(YX)Z}$

 : $SDHzV_{S-BP}$


 : Z_s

The Station height Z_s will be calculated from up to a maximum of 20 Backsightpoints.

All measurements are performed in the **SDHzV** mode, with scale factor $s=1$. After heightstationing the previously used scale factor is re-activated.

441 Heightstationing		Adr: 259
ih ████████ 1.250 m		
8 0429 4032 HeightStation		
<---Pnr---><---Info--->		
Edit Info		Mark Code SmtP

Enter station point ID and instrument height **ih** after selection in menu *Stationing*.

Continue with . To be proceeded with Heightstationing in the same way as after any stationing in the x-y plane:

2 alternatives for Heightstationing:

- (1) Measure to BP's
- (2) Enter a height value

442 Heightstationing from	
Backsight(s)	1
Input of Height	2

Measurement and Adjustment

Backsight(s) 1

Select BP with known height and measure.

More to measure more BP's

±BP Off / on to skip or to activate BP's in the adjustment.

Selection of BP's and measurements to be performed the same way as in [Measurement Free Stationing](#). After one BP being measured the display for residuals appears.

445 Residuals L2	
Nr.	vz [m]
1	0.016
e 2	-0.054

More ±BP Del New Cfg Rest L1-A

Display of residuals in Heightstationing. For analysis of the results use the same function keys as in Free Stationing.

Cfg Configuration Heightstationing

Standard deviation 1

Define distance range for weight $p = 1$.

Error limits 2

Define maximum deviation in height.

Heightstationing uses the principle of a weighted average according to the predefined weights (set in Configuration).

92141 Heightstationing Stand. Deviation	
c : <input type="text" value="30"/> m	Distance for Weight 1
Weight for $D > c$:	$p = c^2 / D^2$
Weight for $D \leq c$:	$p = 1$
If $c = 0$:	$p = 1 / D^2$

Exam.: up to 30 m distance $\rightarrow p = 1$
 from 30 m distance on $\rightarrow p = c^2 / D^2$
 $c = 0 \rightarrow p = 1 / D^2$

Entering a height value

Input of Height 2

You can manually enter the height of the station point. Then there is no measurement.

Input : Station Height
Z 80.088 m

After the height entry, Heightstationing is done.

Heightstationing

Results of the Heightstationing

Rslt Show result of Heightstationing

The height of your station and its standard deviation are displayed:

446 Heightstationing		
sz	0.029 m	Z 490.745 m
Press any key to continue...		

Esc When pressed in the display of the residuals: Heightstationing is finished and the result is checked in accordance with the preset error limit for the actual deviation in height. That error limit to be previously defined in Configuration.

417 Stationing OK?		
ih 1.750 m	Z 490.745 m	
8 0429 4032 HeightStation		Yes No

Check the results,

Yes to save the results, implement the Heightstationing and exit the program.

No Leave the Heightstationing without saving the results.


If Heightstationing was previously called from a stationing in the x-y plane, the program automatically returns to that stationing menu, to show the overall stationing results.

Eccentric Stationing

Stationing 4

Eccentric Station 3

If the detail points and the set out points cannot be measured from a station on a known point, it is feasible to set up the station on a unknown point close to the known point (the so-called center point).



- : $BP_{YX(Z)}$, $Center_{YX(Z)}$
- : $SDHzV_{Exz-Z}$, HzV_{Exz-BP}
- : $Ecc_{YX(Z)}$, Om

$2 \leq BP+CP \leq 20$

Measure directions to the BP's and combined distances and directions to the center point: With these data the coordinates of your station and the orientation **Om** of the horizontal circle are determined. Up to 20 BP's (including the center point) can be measured.

Stationing in the x-y plane and Heightstationing are done separately. In case of Heightstationing, you have to input instrument height and prism height.

431 Eccentric Station		Adr: 25
s	1.000000	
ih	1.750 m	
213 12 1962 Ecc. Station		
<---Pnr---><---Info---		
	Info	Mark Code SwtP

to confirm the entry of ecc. station


Then you can display the coordinates of the center point in the editor:

432 Center				PROJNAME
1	9	2714	0077	Backsight Pnt
2	9	2714	0061	Backsight Pnt
3	7	0429	4022	Backsight Pnt
4	8	0429	4032	Backsight Pnt
25	8	0429	5077	Center Pnt Z
Proj. Inpt				Edit. Srch Adr. Pnr Filt

Select the center point and press **Enter**.

all function keys please see *Free Stationing*

Measurement Eccentric Station



433 Measure to Center		Adr: 610
ih 1.690 m	SD 7.890 m	
th 1.560 m	HZ 205.3256 gon V1 97.7623 gon	
401313 Center Point		
<---PNr---><---Info--->		
R-M Ecc Inpt Code		→2

Measure SDHzV (Center) by or .

Then select and measure first BP in the measurement mode HzV:

435 Measure Backsight		Adr: 611
Nr. 2	SD 7.890 m	
ih 1.690 m	HZ 205.0000 gon V1 97.0000 gon	
th 1.560 m		
2000 Backsight		
<---PNr---><---Info--->		
R-M Inpt Code		→2



Free Stationing

Measurement Free Stationing

The display of the residuals is similar to the other types of stationing:

436 Residuals L2			s = fixed
Nr.	vl[m]	va[gon]	vq[m]
1	0.001	0.0000	0.000
2		0.0002	0.000
3		0.0003	0.002
More :BP Del New Cfs Sclt Rslt L1-A			→2

The adjustment is according to a weighted average.

More

More BP
Measurements

436 Residuals L2	
Additional Measurement	
Backsight	
Center	
More :BP Del New Cfs Sclt Rslt L1-A	
→2	

Backsight: Measure another BP


Center: Re-measure center point (optional).

Eccentric Stationing

Scale Scale factor

In Eccentric Stationing the scale factor **cannot be free**. However, you can enter any fixed scale factor, as long as it is in accordance with the pre-configured scale range.

Default: $s = 1.000000$


 all other function keys please see *Free Stationing*

Tip

Do not locate the eccentric station point too far away from the center point.

A feasible distance is 10 m.

For greater distances it is better to choose the regular Free Stationing, the center point then being used as one of several BP's.

 Free Stationing Results of Free Stationing

The Eccentric Stationing concludes in the same way as Free Stationing. You can then proceed with Heightstationing, if required.

417 Stationing OK?		
s 1.000000	Y 470732.639 m	
ih 1.750 m	X 1088228.358 m	
	Z 246.880 m	
213 12 1962 Ecc. Station		<input checked="" type="checkbox"/> Yes <input type="checkbox"/> No

Display of the results of Eccentric Stationing and Heightstationing.

Yes for storing the results and then finishing the Eccentric Stationing.

No Leave Eccentric Stationing without recording the results.

After a stationing in a higher-order coordinate system the program *Coordinates* follows with the measurement of detail points or the setting-out of points in this coordinate system.

Detail Points

Setting Out

Detail Points



Coordinates 5

Detail Points 1

Determination of the coordinates and heights of new points by distance and angle measurement in a higher-order coordinate system.

The actual stationing will be used by the *Detail Point* program (including the scale factor).

The program *Detail Points* is similar to the program *Measure in a Local System*.



Mode Selection of the measuring mode



Y X Z



SD Hz V



HD Hz h

R-MC Recording Mode:



R-M, R-C, R-MC



R-M



R-M, R-C, R-MC



Configuration

Instrument Switches

51 Detail Points			Adr: 613
s	1.000049	Y	3525614.133 m
ih	1.690 m	X	5389299.623 m
th	1.560 m	Z	429.741 m

20345 Detail Point	
<---PNr---	>---Info---

Mode Rec Io ff R-C Ecc. HidP Inpt Code D:N →2

← or ● to measure the point.

R-M for original measured data

R-C for computed data

R-MC includes R-M and R-C

It is possible to record oriented (by stationing, see figure) or not-oriented Hz-directions. For coordinate computation oriented Hz-directions will be used.

Detail Points

StCk Stationing Check, displays the actual Stationing.

Stationing		
S	1.000000	Y 564423.233 m
ih	1.750 m	X 403583.541 m
		Z 130.576 m
100558 Free Station		
<---Pnr---><---Info--->		
Press any key to continue...		

Indirect Survey



Ecc. Eccentricity / Intersection


Indirect Survey	
	Type : Eccenter
	Refl. Offset right 0.000 m
	Length Off
	Mode Off
	Height Off

toggle between options.

Type: Eccentricity


Type: Intersection

Eccentricity




Length $L < 100$ m


Reflector Offset:




right of




left of



front of



behind



slope (in sighting axis)

to the Center.

Indirect Survey	
	Type : Eccenter
	Refl. Offset right 2.000 m
	Length Once
	Mode On
	Height On

toggle between options.

Mode **Once** for a one off Measurement,

Mode **Perm** for a permanent eccentricity,


Mode **Off** to cancel.

Height **On** To use the height of the eccentric point in position left, right, front of or behind to the center. The center height is calculated for a slope eccentric.


Off no height coordinate.

Intersection


Case of measurement:




Angle/Dist.




perpend.



general



Eccentricity	
	Type : Intersection Case : Separated D Mode : Off

 toggling between options.

Mode **Once** for a one off Measurement,

Mode **Perm** for a permanent eccentricity,

Mode **Off** to cancel.

⚠ Attention !

If the height difference between the eccentric point in position left, right, front of or behind to the center is large, then set the height to **Off**.


The function **Ecc.** is not available during the Hidden Point Measurement.

Detail Point

Hidden Point Measurement




HidP Call Hidden Point



R2-P Distance of the reflector point R2 to the rod point

R1-R2 Distance of the reflectors R1 and R2 on the rod

Hidden Point	
	Mode : Permanent R2 - P : 1.115 m R1 - R2 : 3.500 m Tolerance : 0.003 m

Mode: similar to eccentric measure

Tolerance: permitted maximum value for accuracy of the R1-R2 distance.

Default value: 0.003 m

The program gives a hint, if the tolerance value is bigger than permitted.

Recording Modes HidP:









R-M



R-M, R-C, R-MC



R-M, R-C, R-MC


51 Hidden Point: Ref1 R1				Adr: 613	
R1	3.500 m	Y	3525614.133 m		
ih	1.690 m	X	5389299.623 m		
R2	1.650 m	Z	429.741 m		
27345 Hidden Point					
<----PNr-----><----Info---->					
Mode	Rec	Io+I	R-C	HidP	Imp:1
Code	D:1	N	→2		

The program defines the order of measuring R1 and R2 by the help of the display information.

The height Z_p will be computed from the station height $Z_{STATION}$, the instrument height **ih** and the **R1-R2-P** distance.

Detail Points

Object Height Measurement




ObjH After measurement to one reference point with modes



SD Hz V
HD Hz h
Y X Z

this function key is available.



The reference point defines the line Instrument-Reflector (I-R) and the vertical plane normal to I-R. Now it is possible, to measure object heights to points in that plane only by HzV angle measurement:

- HD** Horizontal distance I-R
- O** Orthogonal dev. L-R (90° to I-R)
- h** Object height to R (reference point)

51 Detail Points				Adr:	614
s	1.000049	Y	3525614.133 m		
ih	1.690 m	X	5389299.623 m		
th	1.560 m	Z	429.741 m		
345077 Reference Pn				*	
<---Pnr---><---Info--->				*	
Mode Rec Io ff R-C Ecc HidP Inpt Code L:N →2					

Measure in modes . Eccentric point measurement also possible.

51 Measure Object Height				Adr:	618
	HD	158.091 m			
	O	20.257 m			
	h	14.009 m			
346001 Object Height				*	
<---Pnr---><---Info--->				*	
Mode Rec Io ff R-MC Code →2					

to measure object height + orthogonal deviation with .

Mode Switches the display of HDOh, HzV ,SDHzV HD Hz h , Y X Z

Mode is a switch between the display of HD O h and HD Hz h. Recording with Rec.

Detail Points

- HD** Horizontal Distance I-L
- h** Height difference with respect to Station I

Vertikal Plane



ObjH After measuring to two reference points in Mode



D Hz V







E Hz h






y x z

is this function accessible.



Measuring  2 points P_E will define a vertical plane. Once the plane is established, points in the plane P_i can be measured only by the use of angles . There is no need to measure a distance. The coordinates of P_i are measured in the defined Coordinate System.

Messung Referenzpunkt mit   oder .



Mode Switches the display of HzV ,SDHzV HD Hz h , Y X Z

Toggle the **Mode** softkey to see **HD Hz h** and record with **Rec**:

- h** Height difference with respect to Station

Connecting Distances

P→P The connecting distance to the last measured point will be computed.

Rec To record the connecting distance

511 Connecting Dist.		Adr: 202
	SD 40.011 m	
	HD 39.842 m	
	h -3.681 m	
129000	Conn. Distance	
<---Pnr---	>---Info---	
Rec		

Press **Rec** to record the connecting distance.

← or **Esc** back to the measuring menu without recording.

2 Face Measurement

1Lg toggles between face 1 and
2Lg face 2.

51 Detail Points Face 1		Adr: 460
s 1.000000	SD 0.0000 m	
ih 1.5800 m	Hz 13.1134 gon	
th 1.5800 m	V1 101.0561 gon	
123456	Face 1+2	
<---Pnr---	>---Info---	
Stck	Del Edit +1 2Fce Mark Swtc SwtP +1	

After measurement in face 1 comes the request to turn the instrument in face 2. Turn the instrument through 180 degrees in Hz and V for measuring in face 2.

Configuration
Programs
General Functions
2-Face-Measurment.

The measurement values and mean values of measurement in face 1 and face 2 will be computed and stored as defined in the program configuration.

If the error limits are exceeded, comes

Error	Measure in 2 Faces	
	Limits Exceeded	
d1 =	0.0000 m	Measure Accept ?
dHz =	0.0000 gon	
dV =	-0.2400 gon	
		Yes No

Yes To accept and save the mean value.

No No saving. New measurement is possible.

Value Corrections



Configuration Instrument

The measured values will be subjected to the following corrections:

- Influence of Temperature and Pressure (SD)
- Prism Constant (SD)
- Inclination of the Vertical Axis (HzV)
- Horizontal Collimation + Vertical Index (HzV)
- Trunnion axis (Hz)
- Circle Eccentricity (HzV)
- FineLock Corrections (HzV)



Configuration Programs

The calculated values (HD, h, X, Y, Z) will be computed from the corrected measured values and are corrected by the following (selectable) influences:

- Scale factor from stationing
- Projection reduction (Gauss-Krueger or UTM)
- Height reduction
- Refraction and earth curvature
- Best-fit Adjustment



Annex Formulae

The exact formulae are given in the annex.



With this switch, One can toggle the various corrections **On** and **Off**.

9133 Correction Switches	
Tilt Compensation	On
Index Correction	On
Collimation Correction	On
FineLock Correction	On
Atmospheric Corrections	On

Toggle with  , Confirm with  .

After switching on the instrument all corrections are switched to **On**.



Compensator **On**

When the Compensator is switched on, the compensator symbol will be displayed.

Setting Out


Coordinates 5

Setting Out 2

Setting-out of coordinated points.

The actual stationing will be used by the *Setting Out* program (including the scale factor).

The *PositionLight* of the Trimble™ 3600 is very useful for setting out points and will drastically reduce the time needed to set out a point.



52 Setting Out	PROJECT
Coordinates	1
Stat. Check	3

Setting out menu.



Configuration

- Instrument
- Switches
- Reference System

It is possible to record oriented (by stationing) or not-oriented Hz-directions. For setting out parameter computation, oriented Hz-directions will be used.

Rectangular Coordinates

Rectangular Coord. 1

- ⇒ : S, P
- ⊕ : (SD, Hz, V)_{S-A}
- ⊞ : (dl, dq, dr)_{P-A}

Setting out using coordinates Y, X, Z with orthogonal corrections dl, dq, dr or coordinate corrections dy, dx, dz. After the call-up there is a selection of the set out points supported by a coordinate filter from the project file.

Setting Out

Inpt to enter a coordinate

Proj select another project

 **Data Management Editor**

Skip Call up a new point from project file without saving the last point measurement.

 **Trimble 3600 PositionLight**

520 Call Set Out Point		PROJECT
18	142278	Set Out Pnt 1
19	142279	Set Out Pnt 2
20	142280	Set Out Pnt 3
21	142281	Set Out Pnt 4
22	142282	Set Out Pnt 5

Proj Inpt Edit Srch Adr. PNr Filt

Recall the set out point from the project data. It is possible to recall points from another project, or input directly.


521 Setting Out		Adr: 50
s	1.000051	HD 36.068 m
ih	1.700 m	da 0.0000 son
th	1.750 m	

10013 Set Out Pnt() <---PNr---><---Info--->

Plot R-C Skip D:N Inpt Code →2

After selection the direction and distance to the set out point is displayed.

The prism should be aligned to the telescope direction. Use the PositionLight of Trimble 3600 for an optical aid for aligning the prism.

 measure the position of the prism and displays the setting out screen.

The Setting Out screen

522 Setting Out		Adr: 1277
dl	0.020 m	HD 65.358 m
da	-0.067 m	da -0.0655 son
dr	0.070 m	

126000 Set Out Point <---PNr---><---Info--->

Mode Plot R-C Skip D:N Inpt Code →2

Esc to save the set out coordinates and to select another point e.g. from another project file.

Pressing **Mode** will display other values:

Setting Out

Mode Selection of misclosures:
dl, dq, dr or
dy, dx, dz

dl, dq, dr length, cross, and radial misclosures
dy, dx, dz coordinate differences
HD Horizontal Distance
da Angle misclosure

If the error limits for a set out point are exceeded, then the display will show a star as a warning.

 PositionLight

D:T Distance: Tracking

D:N Distance: Normal

Setting out with Tracking

Using PositionLight and Distance Tracking together provides the fastest solution.

The distance softkey is used to turn the distance tracking on and off.


Recording of the set out point is only possible after a normal distance measurement

A single measurement is activated with

 or .

R-MC Record mode

Cfg Configuration
Recording

 **Configuration**
Program
Coordinates
Setting Out

Recording

The recording mode is set using the softkey **R-M**, **R-C**, **R-MC**. In the Configuration *Coordinates Setting Out Recording can be set*, which values should be registered.

Setting Out

Before recording, the error in the setting out is compared with the error limits set in the configuration.


If the error limits are exceeded:

Error	Setting Out Error limits exceeded!
Repeat Measurement ?	
Yes No	

Yes to repeat the measurement.

No Record and call the next point.

Plot Zooming the dl, dq display.

522 Setting Out		Adr: 124
dl	-0.387 m	
dq	-1.930 m	
87701 Set out Point		
<---PNr---><---Info--->		
Mode	Plot R-MR	Input Code Srch 52

Press **Plot** again for normal viewing.

Station Check

Stat. Check 3

This is used to check that the correct station coordinates are occupied, and that the orientation of the circle is correct for the coordinate system.

Stationing			
s	1.000000	Y	564423.233 m
ih	1.750 m	X	403583.541 m
		Z	130.576 m
100558 Free Station			
<---PNr---><---Info--->			
Press any key to continue...			



This chapter describes advanced applications in the daily surveyors practical work. This applications are implemented in the menu *Coordinates* and *Special* of the Elta® S software.

Point-to-Line Distance


Point-to-Line Distance

Special 6

Point to Line 2

Determination of Point-to-Line distances. The line is defined by angle and distance measurement of two points or the recall of these points from the project file.

6 Special	PROJEKT
Multiple Rounds 1	
Point to Line 2	
3D Plane 3	
Area Computation 4	
Connecting Dist. 1	



Survey by quasi-perpendiculars or staking out of points or profiles orthogonal to a line can be done by the help of this measuring method.

The line defining points P_1 and P_2 can be measured from a free selectable Station S .

For the point measuring P_i orthogonal to the line in a local system the x-axis will be defined by P_1P_2 with P_1 as the coordinate origin.

The heights refer to line point P_1 with height $z=0$ or a heightstationing.

Selection of measuring in a local system or a coordinate system.


61 Point to Line	PROJECT
Local System 1	
Coordinate System 2	

Point-to-Line Distance

Measuring in a local system




Local System 1



Yes The last measured line and their coordinates will be loaded by the program.

No Program goes further with.

Line measuring:



Zon Switch on and select the height reference


The height reference for defining the line can be selected by the Softkey **Zon**:

1. Height from P_1
2. Height from heightstationing
3. No height (**Zoff**)

Zoff No height

If no other height reference is defined, the height from P_1 is default

 or  to measure line point P_1



 or  to measure line point P_2


If P_1 and P_2 are identical, a message appears in the program.

Point-to-Line Distance

New New line measuring

6113 Result			s = fixed
s	1.000000	X1	0.000 m
		X2	219.764 m
ds	0.002 m	s	219.764 m
Line P1 P2			
<---PNr--->		>---Info---	
New	StCk		

Result of the measured line P_1P_2 . The x-axis is defined by both points with point P_1 as the coordinate origin.

 Accept the line measurement.

StCk Station check

To check the station coordinates referring to the coordinate system defined by the line.

Stationing			
s	0.999944	Y	51.194 m
ih	1.750 m	X	21.614 m
		Z	1.087 m
Station			
<---PNr--->		>---Info---	
Press any key to continue...			

Point-to-Line distance measurement

After defining the line, point P_i measuring can be done. The orthogonal position and the line distance of the points (y_i, x_i) to the line P_1P_2 will be computed:

Mode Switching the display to show $y\ x\ z$ or $y\ x\ Z$
HD Hz h
SD Hz V

6114 Measure Points			Adr: 229
s	0.999944	x	0.910 m
ih	1.750 m	y	7.262 m
th	1.650 m	z	1.589 m
5012 P2L No 12			
<---PNr--->		>---Info---	
StCk	Rec	Del	Edit
Ffce	Mark	Swtc	Swtp
→1			


 or  to measure the points P_i .

Zon Height on

Zint Interpolated height

Zoff No height

The heights h_i of the P_i can be interpolated to the defined line $P_1 - P_2$ by toggling the height softkey to **Zint**.



Measuring in a coordinate system



Coordinate System 2

A stationing must be done before measuring point-to-line distances in a coordinate system.

The program starts similar to the local system. You will be asked whether or not you wish to use the last line.

Line definition

can be done by

- Measuring both line points (similar to the local system),
- Call-up of both points from project file,
- Combination between measuring and call-up for both points.

In case of a new line definition the program leads automatically to the call-up (**Edit**) for the first point P_1 :

? Editor		PROJECT
2	37700	BP2
3	37089	BP3
4	37103	BP4
5	37702	Line Pnt1
6	37703	Line Pnt2

Proj. Inpt. Del. Edit. Srch. Adr. PNr. Repl. Filtr. →2

call-up the point P_1 from project file

or

Esc goes to the measurement menu:

6121 Measure Point P1			Adr: 225
s	0.999944	SD	257.235 m
ih	1.750 m	HZ	24.1245 gon
th	1.650 m	V1	100.0368 gon

1001	Line Point 1
<---PNr---	>---Info---

Stck. Rec. Del. Edit. 1Fce. Mark. Swt.C. Swt.P. →1

or to measure line point P_1

Measuring or calling-up of the second line points leads to the result display:

Edit Back to the Editor to call-up the line point from project file

Point-to-Line Distance

s Length of line


6123 Result		s = fixed
s 1.000000	X1 0.000 m	
	X2 219.764 m	
ds 0.002 m	s 219.764 m	
Line P1 P2		
<---PNr---><---Info---		
New		StCk

StCk Station check

The local Station coordinates referring to coordinate system defined by the line will be displayed (not the higher-order coordinates):


Stationing		
s 0.999944	Y 151.194 m	
ih 1.750 m	X 121.614 m	
Station		
<---PNr---><---Info---		
Press any key to continue...		

Display of the station coordinates.

 **Configuration**
 Programs
 Special
 Point to Line

Tip

To activate recording Grid Coordinates, switch **On** in the Configuration of Instruments (menu 92313).

 **Point-to-Line Distance**
Local System

Point-to-Line distance measurement

The measurement is similar to measuring in a local system.

This chapter describes the entry, transfer and storage of data.

Editor


Data Transfer

Data Format

Editor 7

For the entry of point information and coordinates.










Display and editing of the project file using selectable output filters.




The editor menu displays the addresses of the current project file and their contents in an abbreviated form (27 PI characters).

If an output filter has been set, this is indicated in the menu title bar.


Keys frequently used in the editor

-   Up and down cursor keys
-   Scrolling the display by four address items
-   Jump to the first and last addresses
-  Navigating between input fields
-  Recording entries
-  Quitting the editor

Quitting an input menu (Inpt, Edit)

 Quitting the current input menu. If any entries made have not been saved with

 the following enquiry appears:



 The change (entry) is saved.

 The change is not saved.

Entering a data record

Inpt Editor input menu

Select **Inpt** to get to the editor input menu:

72 Input		Adr :	87
	Y	224560.124 m	
	X	523587.359 m	
	Z	-9999.000 m	
1000 12 1356	Backsight Pn		
<---Pn	--->	<---Info	---
Mode	Ioff	Info	Mark Code

Entry of: **Point identification (PI)**
Coordinates
Directions and distances

Mode Switching between the entry of



Y X Z / y x z



SD Hz V



HD Hz h

Ioff Incrementation for the entry **off**

Ion Incrementation for the entry **on**

Mark Changing the marking

Code Calling the code-list



Measurement in a local System

Use of codelists

The **Mode** button permits you to switch between different input modes (corresponding to the measuring modes).

⚠ Attention !

In the YXZ mode, you have to enter the value **Z=-9999.000 m** for points of unknown height. The height **Z=0.000 m** is considered to be a known height and is used as such by the programs.

Recording the entry

The data line entered is saved at the end of the current project file at the address displayed in the address window.



For recording.

The line entered remains available in the display and can be edited for the next input line.

The memory address for the next input line is incremented by 1.



Quitting the input menu.

Editing a data record

Edit Editing a data record

Select a measured or entered record in the editor menu using the cursor buttons. Press the **Edit** button to have the complete record displayed.

74 Edit		Adr: 835
	Y 4429686.2921 m	
	X 5640475.3866 m	
	Z 270.5473 m	
201709	KT71	
<----PNr-----><----Info----->		
Rec	Srch	Adr. Mark Code

Mark Changing the marking

Only coordinates or values defined by input can be edited here in the displayed input mode. Original measured data cannot be edited.

Code Calling the code list

PgUp **PgDn** Selecting further records for displaying and (if possible) editing.

If you select a record to which attributes such as headers, scale, ih, project info line etc. have been assigned by the program, the record is displayed and the PI can be edited using **Edit**:

74 Edit		Adr: 535
This is a Project Info Line		
Rec	Srch	Adr. Mark Code

Display of an attribute line (e.g. Info Line).

 Save and Quitting the display


Rec Recording a record

The edited record is saved without the need to quit the editing function. The same address in the project data file is used for saving.

Srch Search for record

Searching for a record or address

Adr. or address

 Searching for records

Filtering of records

Filter Setting an output filter

For data transfer or deletion, it is often advisable to define a filter by combining several optional criteria. Only the relevant records are then displayed for further use in the editor.



Menu for the generation of filters. The filter currently selected is displayed. If no filter has been set, the input fields are blank.

Filter options

- Point identification (text or code blocks)
- Addresses from – to
- Point numbers from – to
- Attributes of values (Y-X-Z, SD Hz V, etc.)
- Combinations of these options

Filter effect

- If the PI is used for filtering, only the records with the selected marking are filtered.
- If other criteria are used for filtering, the filter applies to all markings
- With a combination of PI + other criteria, the selected marking applies.


Setting a filter

Press to activate the selected filter. After that, the filtered brief display appears again. The active filter is shown in the menu bar:



RSet Resetting an output filter

Resetting a filter



Yes All the data of a project is displayed.


Mark Activating or changing the marking

Point identification filter

Select **Mark** to activate the current marking or to change to a different marking.

Code Filtering acc. to coding with code-lists

If the marking defines code blocks, you can select these as filter attributes using **Code**.



Example: Filtering for records with "Spl" code and point numbers with the leading numbers 1013.

Enter your data in line with the format of the selected marking (blanks are significant).

A→A Address filter

Filtering according to address ranges

Set an output filter from address i to address j.

Default address range:
from: first address
to: last address



Example: Filtering for records in the address range 1 to 88 of the complete project file.

P→P Point number filter

Filtering according to point number ranges

Set an output filter from point number i to point number j.

79 Filter		PROJECT
Mode: Y-X-Z	Pointnumbers from: 8000 to: 8015	
????????????????????????????????		
<---PNr-----><---Info----->		
Mode	RSet	P→P A→A Mark Code

Example: Filtering of the point numbers 8000 to 8015 for data records which include the data attributes Y X Z for the selected marking.

Filtering according to point numbers is independent of the marking, unless PI is used as a filter criterion at the same time.

Other in-between records containing information (headers, text lines, etc.) are omitted.

Mode Filtering acc. to data attributes

Filtering according to data attributes

By default, all data attributes are accepted for filtering. The **Mode** input field shows **All** in this case.

79 Filter		PROJECT
Mode: Y-X-Z	from: to:	
1010????????????????????????????		
<---PNr-----><---Info----->		
Mode	RSet	P→P A→A Mark Code

The **Mode** softkey permits you to filter out the following 11 data combinations:

? is like a wildcard

All / SD-Hz-V / Hz-V / HD-Hz-h / y-x-z / y-x-? / ?-?-z / Y-X-Z / Y-X-? / ??-Z / HD-O-h

Tip

In this way, you can simulate coordinate files or measured data files, for example.

Searching for data records

Srch Calling up search

75 Searches				PROJECT	
?????850	Buil	Cor	??	??????	
ppppppp	Obje	Frm	Def	<Info>	
			?		Mark Code

Mask-oriented search for data lines according to different criteria. The output filter currently selected is effective.

- Search options:
- Point number**
 - Code or text**
 - Time (if incl. in marking)**
 - Combination of these options**

To enter the search criterion, proceed in the same way as for the setting of a PI filter.

If you have searched for a mask before, this mask is offered for editing or for continued search.

Tip

The search is only made in records with the selected marking.

The placeholders "?" in the mask permit the use of any character for the search, i.e. if no search is necessary in the PI position, "?" can be retained. Entered blanks are significant.

Mark Changing the Marking

When you select a different marking, the search mask is deleted. The layout of the placeholders "?" is automatically adapted to the new marking.

Code Calling the Code-list

If code fields have been defined in the selected marking, you can search the code from the associated codelist.



Search to file end



Search to file beginning



Starts the search.

The search starts at the current address and continues downwards to the file end. You can use the up and down keys **?↓** and **?↑** to change the search direction. If the search is not successful, the following message is displayed:

```

Error      Editor Search
           Not Found !
-----
???850 Buil Cor ??? ??????
ppppppp Obje Frm Def <Info>
-----
Press any key to continue...
    
```

If the search is successful, the cursor moves to the relevant record in the editor brief display.

Tip

Searching for PI in a large project file, it helps to save time if you start the search from an address near the PI required.



Search for/calling up addresses

```


7 Editor      PROJECT
Call
-----
Address :    585
-----
Proj Inpt Del Edit Srch Adr. PNr Repl Filt →2
    
```

Enter: **1 ≤ address ≤ n**
(n=last address used)

The last address **n** of the project file is always displayed by default.

The start and result of the search correspond to those of the **Srch** function. The output filter currently selected is effective.

PNr Search for/calling up point numbers




Enter: **Point number**

The start and result of the search correspond to those of the **Srch** function. The output filter currently selected is effective.

Tip

The search for an address and point number is made irrespective of the marking. The markings PI1, PI2 etc. used in the project file must be configured in the instrument.

Repl Search and replace



Mask-oriented search for and replacement of data lines in the same way as in the **Srch** function.

Enter: **Search mask** (-string)
Replacement mask (-string)



To entry of the replacement string




Start search / replace



Search direction

Confirmation of replacement:



No All strings conforming to the search criterion are replaced by the new string without prior enquiry.

Yes Each replacement is preceded by an enquiry, with a display of the data line found:

751 Replace?	Adr: 288
Yes No	
9600	Free StInt
<---PNR----->	<---Info----->

Yes The displayed data line is replaced by the new line.

No No replacement, search is continued.

After completion of the search / replacement, the result is displayed:

Search and Replace	
11	Lines Found!
Press any key to continue...	

Deleting data records

Del Deletes data records

This function deletes the data line marked by cursor in the project file:

7 Editor	PRR.1FKT
Delete	
Delete line ?	
Yes No	
Proj Inpt Del Edit Srch Adr. PNR Rept Filt →2	

Yes The record is deleted.

No No deletion, return to the editor menu

If an output filter is set, this function deletes all records set in the current output filter:




Yes All records in the current output filter are deleted.

The current output filter is then reset, and all undeleted data of the project file is displayed again.

No No deletion, return to the editor menu

After deletion, the data memory can be reorganized in the same way as by the **OrgP** function:



Yes Data memory reorganization.

Caution! This deletes the data for good!

No No data memory reorganization. Attention! Gaps in the addresses! But the data remains available in the project file!

Data recovery after deletion?

Yes, but be careful when using external editors !

⚠ Attention !

Only the reorganization of the data memory will physically delete the selected records in the project file. If this process has not yet been started, you can reactivate the address ranges selected for deletion by using an external editor and replacing the delete identifier "~" in column 119 of the record by a blank. Please note, however, that the record length of 121 bytes (characters) must not be exceeded!

After the deletion of records, you return to the editor menu (brief display).

Further function keys


Proj Project change

You can change the current project without having to quit the editor. When you quit the editor, the project originally selected is reloaded.

OrgP Data memory reorganization

Reorganizes the data memory in the current project.

This button is available if data has been deleted without subsequent memory reorganization, and if address gaps therefore exist in the project file.




Yes Data memory reorganization.

Caution! This deletes the data for good!

No No data memory reorganization. Attention! Gaps in the addresses! But the data remains available in the project file!

Data Transfer



↔ RS232C cable interface ↔ PC Cable Infrared


Data transfer can be done between Trimble™ 3600 by


This allows comprehensive yet easy data management and exchange. The software functionality for data transfer is the same on the instrument via radio


Data Transfer 8


8 Data Transfer		BIGLIST	
Send Data	1	Remote Control	6
Receive Data	2		
Send Data IR	3		
Receive Data IR	4		

Cable for data transfer using the Xon/Xoff protocol:

Instrument  PC
 Cable:
 Cat. No.
 708177-9470.000

 **Data Transfer**
 Zeiss Control Center

Data transfer Trimble 3600  PC

instrument  PC
 Connect both devices by a serial interface cable and start the necessary programs for data transfer.

Infrared data transfer at this menu level is not supported. A solution for infrared data transfer is given by the **Zeiss Control Center**.

 **Tip**


For data transfer of project files by cable to the PC, you can use e.g. the MS-Windows™ Hyperterminal Program. Connect the Elta® C with your PC station via serial interface cable and define the interface parameters in the Terminal Program as described in the next chapter.

For an easy data transfer via infrared or serial cable interface the PC Program **Zeiss Control Center** for Windows™95/98/NT will be needed. This optional program can be ordered under Cat.-No.: 708043.0000.000.

Hyperterminal Settings


Example Windows™ 95/98 or Windows™ NT Hyper-Terminal Program:

The COM port settings can be switched in the Hyper-Terminal Program of Windows™ 98 or Windows™ NT under *File > Properties > Configuration* as follows:



Tip: for a much faster data transmission switch off the "local echo" in the Hyper-terminal ASCII-Configuration.

To send or receive a project file, select for transfers "Send text file" or "Receive text file":



Data transmission

Send Data 1

For the transmission of data files.

Send D:\DATEN\			
NONAME	7502	OBJH	363
AMT_HH2	26499	PROJECT	64735
AREA	20933	TRAVERSE	46222
BA-K-NEG	27951	AMT_HH	6776
KLEINPKT	6897	THIEL	14157

Send

Send Transmits data file

Use the cursor keys to select the project file required and transmit it with **Send**.

Cfg Configuration of interface parameters

9151 Edit Parameters			
Baudrate	19200	Data bits	8
Parity	None	Stop bits	1
Protocol	Xon-Xoff	Interface	Cable

Configuration of interface parameters. The same parameters has to be set on the external device (PC e.g.).

Baudrate: 2400 / 9600 / 19200 (default)
38400 / 57600 / 115200

Parity: no / odd / even

Protocol: Xon-Xoff / Ln-Ctl / Rec500

Data bits: 8 / 7

Stop bits: 1 / 2

Interface: Cable / Infrared



to select parameters,



to accept.

Tip

The instrument or program at the receiving end must be set to the receive mode before you can transmit the project file.

Data reception

Receive Data 2

For receiving data files.

Target File	
Name	Project
Rece	Cfs

Enter the new file name.

Rece to enter the target file name



to accept sets the instrument in the receiving mode.

The instrument is now waiting for the file from the transmitting end:

Target File	
Receiving	
Name	Please Wait...
Cancel with ESC	
Rece	Cfs

Esc to continue after receiving the data.

Target drive on the Instrument: D:\DATEN

Cfg Configuration of interface parameters

Configuration of interface parameters is similar to Send Data.

Tip

Time-out occurs after 45 seconds without data communication.


The message "Data format error" indicates a data error. The program returns to the data transfer menu.

Zeiss Control Center

Runs under
Windows™95/98/NT

PC program for data transfer via serial interface.
With Trimble 3600 Zeiss Elta software release
V1.04 or higher the instrument communicates via
infrared interface to the Zeiss Control Center on a
PC.


Trimble 3600
System Controller:




Start Remote Service (Cable or Infrared) in the
system control menu on the instrument.



Automatic scan of all serial interface ports (cable
or infrared) on PC for a connected instrument.



The files selected on PC or instrument will be cop-
ied to the target directory displayed on the other
window.

For further information: 
for
Center.

User Manual for
Zeiss Control
Center.

M5 data format

Project file <NAME>.DAT
<NAME> Project name

When you set up a new project, an ASCII project file is created whose records conform to a predefined format.

M5 record format

The Trimble 3600 uses the Zeiss M5 data format which is the common standard for all current Zeiss surveying systems.

1 Address block
1 information block
3 numerical data blocks

All 5 data blocks are preceded by a type identifier. The 3 numerical data blocks have a standard layout comprising 14 digits. In addition to the decimal point and sign, they accept numeric values with the specified number of decimal places. The information block is defined by 27 characters. It is used for point identification (PI) and text information (TI e.g.). The address block is comprised of 5 digits (from address 1 to 99999).

M5 data line

The data line of the M5 format has a length of 121 characters (bytes). The multiplication of this figure by the number of addresses (lines) stored gives you the volume of the project file in bytes.

Blanks are significant characters in the M5 file and must not be deleted.

The example describes an M5 data line at address 176 with coordinates (YXZ) recorded in unit **m**. The point identification of marking 1 is **DDKS S402 4201**. Column 119 includes a blank (no error code).

The end of the line has CR, LF (columns 120 and 121, shown here as **<=**).

Explanations to the data line

Abbr.	Description	Digits	Characters	Meaning
For	Format identifier	3	alpha	Elta® Format
	Format type	2	alpha	5 meas. data blocks
Adr	Address identifier	3	alpha	Value1
	Value1	5	numeric	Memory address
T2 a	Type identifier	2	alpha	Value2 (Pla ,TI, TO...)
	Marking Value2	1	numeric	a=1, 2, 3 ,..., 9, 0
		27	alpha	PI or TI
T3 dim3	Type identifier	2	alpha	Value3
	Value3	14	numeric	14-digit value
	Unit	4	alpha	4-digit unit
T4 dim4	Type identifier	2	alpha	Value4
	Value4	14	numeric	14-digit value
	Unit	4	alpha	4-digit unit
T5 dim5	Type identifier	2	alpha	Value5
	Value5	14	numeric	14-digit value
	Unit	4	alpha	4-digit unit
?	Identifier	1	alpha	CZ code, or ■
Special characters			ASCII code	Hex code
	Separator	1	ASCII 124	Hex 7C
■	Blank	1	ASCII 32	Hex 20
<	CR (Carriage Return)	1	ASCII 13	Hex 0D
=	LF (Line Feed)	1	ASCII 10	Hex 0A

The instrument adjustment defines all corrections and correction values for the Trimble™ 3600 Zeiss Elta, which are required to ensure optimum measuring accuracy.

Adjusting V-Index / Hz-Collimation

Adjusting Compensator

Adjusting DR EDM System

Adjustment methods

Increased strain placed on the instrument by extreme measuring conditions, transportation, prolonged storage and major changes in temperature may lead to misalignment of the instrument and faulty measuring results. Such errors can be eliminated by instrument adjustment or by specific measuring methods.

Adjustment 2

The menu item *Adjustment* offers the following adjustment programs:

2 Adjust	PROJECT
Standard	1
Compensator	2

Adjustment menu.

Instrument Corrections
Standard

Determination of the vertical index correction (V index) and sighting axis correction (Hz collimation).

Compensator

Determination of the compensator run center.

⚠ Attention !

Before starting any adjustment, allow the instrument to adapt to the ambient temperature and make sure it is protected against heating up on one side (sun radiation).

Adjustment

Instrument errors and their correction

i Vertical index correction

The vertical index error is the zero point error of the vertical circle with respect to the vertical shaft.

c Sighting axis correction


The sighting axis error is the departure from right angles between the trunnion axis and sighting axis.

k Trunnion axis correction

The trunnion axis error is the departure from right angles between the trunnion axis and vertical shaft. It is determined at the works and its correction is stored in the instrument.

Further errors are:

Compensator run center error



Adjusting V-Index / Hz-Collimation

The vertical index and sighting axis corrections should be recomputed after prolonged storage or transportation of the instrument, after major temperature changes and prior to precise height measurements.

Tip

Before starting this procedure, precisely level the instrument using the electronic level.

To determine the corrections, sight a clearly visible target in **Hz** and **V** from a distance of approx. 100 m. The sighting point should be close to the horizontal plane (in the range $V = 100^{\text{grads}} \pm 10^{\text{grads}}$).

Standard

1

Determination of the sighting axis and vertical index corrections, or setting the values $c = i = 0$.

211 Instr. Corr. Standard		
c	0.0008 gon	
i	0.0008 gon	
New Calculation		1
Set: c=0,i=0		2

The current **c** and **i** values are displayed in the readings window.

- c** sighting axis correction
- i** vertical index correction

New Calculation

1

Determination of the **c** and **i** values by measurement in two faces.

212 Instr. Adj. Face 1		Adr: 478
Sight with:	Hz 134.3246 gon	
Cross Hairs	V1 100.0450 gon	
1000		
c / i Measur		
<---PNr---><---Info---		
	R-MC	Mark Code

for measurement in face 1.

Then turn the instrument through 180 degrees in Hz and V in face 2. Sight the same point again.

for measurement in face 2.

Adjustment

The new vertical index and sighting axis corrections are computed automatically.

214 Instr. Corr.: Select			
Old		New	
c	0.0000 gon	c	0.0004 gon
i	0.0000 gon	i	-0.0004 gon
Apply			
Yes No			

Yes The new values are saved.

No The old values are retained.

Technical

During the computation of the vertical index and sighting axis correction, the program also determines the compensator run center.

Tolerance exceeded

If either the **c** or **i** value exceeds the admissible range of ± 50 mgrads, the following error message appears:

Error	Instr. Corr. Standard Limits Exceeded
Index Correction i > 50 mgon	
Press any key to continue...	

The values are not saved, and the menu for new calculation is displayed again.

Attention !


If the values remain outside the tolerance range, despite accurate sighting and repeated measurement, you should have the instrument checked by the service team.

Set: c=0, i=0

2

Setting the **c** and **i** values to zero.

Adjusting Compensator



The Trimble 3600 features a dual-axis compensator which compensates any vertical shaft inclinations remaining after instrument levelling both in the sighting and trunnion axis directions.

To check the compensator, its run center should be determined at regular intervals and in particular prior to precise height measurements.

Compensator 2

Determination of the compensator run center and checking of the instrument levelling.

251 Center point of Comp.		
	sz	0.0021 gon
	sk	0.0001 gon
New Calculation		1
Check Levelling		2

The current run center values for **sk** and **sz** are displayed in the readings window

- sk** component in trunnion axis direction
- sz** component in sighting axis direction

New Calculation 1

Determination of the new run center components **sk** and **sz**.

In New Calculation wait for the request to turn the instrument in Hz-direction to 0 degrees.

Turn Hz to 0 !
200.0000
Then continue with <Return>

to continue displays the results of the automatically computed center point:

253 Center point of Comp.		
Old	New	
sz	sz	0.0020 gon
sk	sk	0.0000 gon
Apply		
Yes No		


- Yes** The new values are saved.
- No** The old values are retained.

⚠ Attention !

For the accurate determination of the run center, it is essential that the liquid in the compensator is allowed to settle, i.e. any vibration of the compensator must be avoided.

Check Levelling 2

Calling up the "Electronic level" display for levelling the instrument.



The signs of the inclination values in position 1 have to be interpreted as follows:

<i>Inclination</i>	<i>Trunnion axis</i>	<i>Sighting axis</i>
positive value:	to the right	to the front
negative value:	to the left	to the back





First Steps Before Measurement

Use the tribrach footscrews to set the inclination values roughly to zero. More precise levelling is not required if compensation has been activated. At any rate, the residual inclinations should be within the compensator working range (± 0.092 grad).

🔧 Tip

Precise levelling is advisable if the compensator needs to be deactivated due to vibrations.

The electronic level can be called up at any point of the program using the  hotkey. 

The system

The red laser beam used for measuring without reflector is arranged coaxially with the line of sight of the telescope, and emerges from the objective port. If the instrument is well adjusted, the red measuring beam will coincide with the visual line of sight. External influences such as shock or large temperature fluctuations can displace the red measuring beam relative to the line of sight.

⚠ Attention !

Before starting adjustment, allow the instrument to adapt to the ambient temperature.

Inspection the Direction of the Beam:

Check the system at regular intervals in order to avoid faulty measurements. A target foil is provided. Set it up between 25 and 50 metres away facing the instrument. Move the telescope to face it. Switch on the red laser beam by activating the laser-point function. Use the telescope crosshair to align the instrument with the centre of the target plate, and then inspect the position of the red laser spot on the target plate. If the spot lies outside the limits of the cross, the direction of the beam needs to be adjusted

Tip

The direction of the beam should be inspected before precise measurement of distances is attempted, because an excessive deviation of the laser beam from the line of sight can result in imprecise distance measurements.

Adjusting the Direction of the Beam:

Pull the two plugs out from the adjustment ports on the top and the front side of the telescope housing. To correct the height of the beam, insert the alan key into the front side adjustment port and turn it. To correct the beam laterally, insert the alan key into the top side adjustment port and turn it. Throughout the adjustment procedure, keep the telescope pointing to the target plate..

Technical

At first the adjusting screws are of a high tension as they are selfblocking. The screws will tighten automatically after the adjustment.

Attention !

After adjustment, replace the plugs in the adjustment ports to keep out damp and dirt.



With the configuration, you can adjust the Instrument to all measurement conditions and requests taking into account an optimum of operator convenience.

Configuration Instrument


Configuration Programs

Configuration Markings

Configuration Codelists

Configuration Update

Configuration 9



9 Configuration		PROJECT
Instrument	1	
Programs	2	
Markings	3	
Code lists	4	
Update	5	

and or with keys **1** to **5** for a directly menu selection.

Generally, the settings of the configuration are stored permanently. Exceptional cases (temporary storage) are indicated in the description.

Operation in the submenus

For the setting of switches or input of information and data, resp., the handling of the menus of the configuration is based on a common concept. The following keys are frequently used:

- Tab** Cursor positioning
- 0** - **9** Keys for direct selecting of submenus
- Toggling in selection fields
- Confirming entrance and quitting
- Esc** Quitting of submenu;
when settings have been changed,
the following question is asked prior to
quitting:

911 Instrument Tune	
Configuration	
Typ	Save Changes ?
Ser	Yes No

- Yes** Change accepted
- No** No change of settings

This user information is a pre-requisite for the following descriptions.



Trimble™ 3600
System Operation

Configuration Instrument

Configuration 9

Instrument 1


Setting and checking of all switches, parameters and options necessary for best operation of the instrument.

91 Instrument			
Instrum.-Typ	1	Clock	6
Distance Calib	2	On/Off-Config	7
Switches	3	Language	8
		Batteries	9
		Default Setting	0

Menu of the instrument configuration.

↓ and ← or with keys 0 to 9 for a directly menu selection.

Overview Instrument Configuration



91 Configuration Instrument

- 911 Instrument Type
- 912 External Distance Calibration
- 913 Switches
 - 9131 Illumination
 - 9132 Peripherals
 - 9133 Adjustments
 - 9134 Units / Decimal
 - 9135 Reference
 - 9136 Recording
 - 9137 Error
 - 9138 Operation
- 916 Clock
- 917 On/Off-Configuration
- 918 Language
- 919 Batteries
- 910 Default

Instrum.-Type 1

Definition, whether measuring with instrument or by manual input.



911 Instrumenten-Typ	
Type	: Trimble 3600
Type-ID	: 702735-9821-100
Instr. Ser.Nr.	: 100000
Instr. SW-Ver.	: 1.10
PC-Version	: 1

- Type: Trimble 3600
Manual Input
- Type-ID: Cat. Number
- Ser. Number: Instrument serial number
- SW Version: Installed Software Release.
- PC Version: Display of PC Type
1 = 8086 Processor
2 = 486 Processor

Calibration 2

Display and input of calibration scale and addition correction for supplementary correction of distance measurement.

912 EDM Calibration	
Calibration Scale :	1.000000
Additionskorrektur :	0.0000 m

- Calibration scale: Default = 1.000000
 0.995000 < Km < 1.005000
- Addition correction: Default = 0.0 mm
 -10.0 mm ≤ Ac ≤ 10.0 mm

⚠ Attention !

Both values influence the measured distance directly! Therefore, they must have been determined by means of an accurate calibration.

Configuration Instrument

Switches 3

Switching instrument functions and their parameters on and off.

Switches 3

Illumination 1

Switching on and off and adjusting the illumination available in the instrument.


 Cross Hair **on**

 Display **on**

Switches 3

Peripheries 2

Switching sensors and actuators on and off.

 PositionLight **on**

 Laserpointer **ON**

Laserpointer OFF:

Once - after each measurement or 2 min

10 min -after 10 min

Off - pointer On always

913 Switches			
Illumination	1	Recording	6
Peripheries	2	Error Limits	7
Adjustments	3	Operation	8
Units	4	Alpha Input	0
Reference System	5		

Menu Switches for instrument configuration.

9131 Illumination Switches			
Cross Hair	On	Brightness:	Normal
Display	On	Contrast :	8

Cross Hair: on / off



and the switches for the display illumination:

Display: on / off

Brightness: low / normal / high

Contrast: 0 (low) to 10 (high)

Tip





The illumination can also be switched on and off using the Hotkey  .

9132 Periphery Switches			
PositionLight	OFF		
EDM Mode	PR	Laserp.Off	Once
		Sound	On
Thermometer	On	Laser Plunnet	Off

 Toggling all switches **On ↔ Off.**

Tip

The PositionLight and the Laserpointer can also be switched on and off using the Hotkey

  and  

Switches 3

Adjustments 3

Activating and deactivating corrections to the measured bearings and distances.



Compensator **On**



Annex
Glossary

Switches 3

Units 4

Modification of display of measuring units and number of decimal places.

9133 Correction Switches	
Tilt Compensation	On
Index Correction	On
Collimation Correction	On
Atmospheric Corrections	On

On ↔ **Off**.

Default: all switches **On**.

Tip

After instrument startup all switches are again in position **On**.

9134 Units + Decimal Points			
Distance	:	m	3
Angles	:	gon	4
Temperature	:	°C	0
Pressure	:	hPa	0

Distances: m ft
 Decimal places: 1-4 1-4

Angles: grads DMS deg mil
 Decimal places: 1-5 0-1 1-5 1-4

Temperature: °C °F
 Decimal places: 0-1 0-1

Pressure: hPa Torr inHg
 Decimal places: 0-1 0-1 1

Tip

The number of decimal places is not related to the internal data storage, but only to the appearance of the data on the display.

Configuration Instrument


Switches 3

Reference System 5

Modification of display of coordinate systems and definition of angles and bearings.

9135 Switch Reference System	
Axis Definit. :	Y-X
Display :	Y-X
Height :	Z
Hz-Direction :	Orientated
Vert.Orient :	Zenith Angle

Assignment of coordinates:




Indication sequence: Y-X / X-Y E-N / N-E

Height: Z EI


Vertical reference system:



Zenith angle



Vertical angle




Examples

1: Zenith angle
unit 400 grads


2: Vertical angle
unit 360°



Height angle



Slope [%]



Examples

3: Height angle
unit 6400 mil

4: Slope [%]
unit %

Switches 3

Recording 6



Recording On

Cfg Configuration of interface parameters

Hz-Direction:

absolute: recording of the absolute (original) Hz circle reading.

orientated: recording of the oriented (by stationing) Hz direction.

9136 Recording Switch	
Recording	On
Destination	Internal
Format	Rec E
Cfs	

Switches the data storage **On** or **Off**.

Default value: Recording **On**

Target Drive: **Internal** (A:\ or D:\DATEN)
External (RS232C)

Format: **Rec E** (M5, internal + external)
Rec500 (only external)

9151 Edit Parameters			
Baudrate	19200	Data bits	8
Parity	None	Stop bits	1
Protocol	Xon-Xoff	Interface	Cable

Configuration of interface parameters. The same parameters has to be set on the external device (PC e.g.).

Baudrate: 2400 / 9600 / 19200
38400 / 57600 / 115200

Parity: no / odd / even

Protocol: Xon-Xoff / Ln-Ctl / Rec500

Data bits: 8 / 7

Stop bits: 1 / 2

Interface: Cable / Infrared

Configuration Instrument

Switches 3

Error Limits 7

Error limits **Off**

Error limits **On**

Switches 3


Operation 8

Defines the position of the motion knobs for right-handed or left-handed operation in face 1 in instruments with 2 control units.

Switches 3


Alpha-Input 0

Configures the key press frequency for alphanumeric input.




Default value: Error limits **On**

Switches the error limits set in the configuration of the programs **On** or **Off**.



Operation in face 1:

righthanded / lefthanded



Selection of a value 1-5. This value defines the time until the cursor goes automatically one position to the right in the alphanumeric input field. During this time the dual assignment swichover for the alpha-letter selection can be done.

(Value 1 = 1.3 sec , ... , Value 5 = 0.7 sec)

Clock 6

Modification of date and time display.

916 Clock Configuration		
Time Format	:	24.HH:MM
Date Format	:	DD.MM.YY

Time format:

24.HH.MM	24 Hours:Minutes
24.HH:MM:SS	24 Hours:Minutes:Seconds
12.HH:MM	12 Hours:Minutes
12.HH:MM:SS	12 Hours:Minutes:Seconds

Date format:

TT.MM.JJ	Day.Month.Year
MM.TT.JJ	Month.Day.Year
JJ.MM.TT	Year.Month.Day

Ctrl T Hotkey for input of time and date in each program level:

- Time** for time input
- Dat** for date input
- Cfg** Configuration display time / date

9161 Time and Date		
Time	:	08:31
Date	:	29.01.98


Time Dat Cfg

After having pressed the switches **Time** or **Date** the input of time or date can be done in the configured format.

On/Off Config 7

Configuration of functions to be executed after booting or before loading the application.

917 On/Off Configuration		
Levelling	:	On
Station Input	:	On

 Toggling of switches **On ↔ Off**.

Levelling: Display levelling menu after starting the Elta® C.

Station Input: Input of station information before start measuring in a local system.

Station Input

Before measuring in a local system a point information and further station parameters (th, ih, Reflector Type etc.) can be entered. This will be stored in the project file as like a header for the following measurement values.

Language

8

Configuration of the language, in which the software appears on the display.

918 Language Configuration	
Language Version :	english

Here, existing and integrated language versions are offered for activation.



Batteries

9

Management and checking of the batteries connected and their capacities.

919 Battery Management	
Tot. Stat. Intern. :	100 %

Display of the remaining battery capacity of the internal or external battery.

  Hotkey for activating the battery manager (in every menu available).


Tip

For switchover between internal and external battery connect the full battery and take the empty battery off from the instrument. The power supply will be stable then.

For changing batteries of the same type, close the application, switch off the instrument and change the battery.

Default Setting 0

Resets the complete configuration of the instrument to the default values defined in the program.




- No** back without modification.
- Yes** reset of all parameters of the instrument configuration to their default values.

Configuration Programs

Configuration 9

Programs 2


Setting and checking of all switches, parameters and options required for the application programs



Menu of the program configuration.

↓ and ← or with keys 0 to 5 for a directly menu selection.

Overview Configuration Stationing



921 Configuration Stationing

- 9211 Free Stationing
 - 92111 Adjustment Type
 - 92112 Standard Deviations
 - 92113 Error Limits
 - 92114 Adjustment
 - 92115 Reductions
 - 92116 Scale Range
- 9212 Stationing on a Known Point
 - 92121 Standard Deviations
 - 92122 Error Limits
 - 92123 Adjustment
 - 92124 Reductions
 - 92125 Scale Range
- 9213 Eccentric Stationing
 - 92131 Standard Deviations
 - 92132 Error Limits
 - 92133 Reductions
- 9214 Heightstationing
 - 92141 Standard Deviations
 - 92142 Error Limits

Configuration Programs

Stationing 1

Setting and checking of error limits, standard deviations, scale ranges and reduction parameters.

921 Stationings	
Free Stationing	1
Stat. Knwn. Pnt	2
Ecc. Station	3
Heightstation.	4

Menu for the configuration of the stationing.

Free Stationing 1

in analogy to that

Stat. Knwn. Pnt 2

Eccentric Station 3

9211 Free Stationing			
Adjustment Type	1	Scale Range	6
Stand. Deviation	2		
Error Limits	3		
Adjustment	4		
Reductions	5		

Configuration menu free stationing.

The configuration of free stationing includes all possible settings of the configuration of stationing on a known point and eccentric station.

Free Stationing 1

Adjustment Type 1

Definition, if and how the type of computation and the scale are set as standard in the free stationing.

92111 Free Station. Adjustment Type	
Calculations	: Single Point Adjustment
Change	: On
Scale	: free
Change	: On

The setting entered correspondes to the type of computation displayed first in the program.

Computation: Single point adjustment / Helmert transformation

Scale: free / fixed

Change: On

Type of computation and scale can be changed during the free stationing.

Off

Given type of computation and scale setting cannot be changed.

Configuration Programs

Free Stationing 1

Stand. Deviation 2

Definition of standard deviations of observations and centering for the weighting in the single point adjustment.

- ✎ $0.0001 \leq sr < 1 \text{ grad}$
- $0.001 \leq sdc < 1 \text{ m}$
- $0 \leq sdl < 1000 \text{ ppm}$
- $0.000 \leq sz < 1 \text{ m}$

92112 Single Point Adjust.			
Orientation	:	0.0003	gon
Distances constant	:	0.003	m
Distances linear	:	0	ppm
Levelling	:	0.000	m

Input of values in given measuring units.

Default values:

Bearings: **sr = 0.0003 grad**

Distances constant: **sdc = 0.001 m**
(constant part)

Distances linear: **sdl = 0 ppm**
(linear part)

Target centering: **sz = 0.000 m**
(centering accuracy reflector above target)

Tip

A specification of 0.0 results in remaining this parameter without influence on the weighting.

Free Stationing 1

Error Limits 3

Definition of error limits for the results of the free stationing.

- ✎ $0.000 \leq va < 1 \text{ grad}$
- $0.000 \leq vr/vq/vl < 1 \text{ m}$

92113 Free Stat. Error Limits				
		s=fix	s=free	
Linear Dev.	vr	0.040	0.030	m
Angle Dev.	va	0.0050	0.0050	gon
Orthog. Dev.	vq	0.030	0.020	m
Lateral Dev.	vl	0.030	0.020	m

Input of values in given measuring units.

Default values: **s=fix** **s=free**

Linear dev. **vr:** **0.040** **0.030 m**

Bearing dev. **va:** **0.0050** **0.0050 grad**

Transv. dev. **vq:** **0.030** **0.020 m**

Long. dev. **vl:** **0.030** **0.020 m**

Configuration Programs

Free Stationing 1

Adjustment 4

Activation and deactivation or weight definition, resp., of best-fit adjustment.

Free Stationing 1

Reductions 5

Activation and deactivation of projection reductions.

Free Stationing 1

Scale Range 6

Definition of the admissible scale range.

$\neq -9999 \leq SR \leq 9999$

92114 Stationing Adjustment	
Mode	: Weight by distance
Weight exponent n	: 2.0 $p=1/D^n$

Mode: Distances / Off

Weight exponent: 0.5 / 1 / 1.5 / 2
For distributing the residuals according to distances by means of the arithmetic mean.

Default Mode: **Off**

92115 Reductions	
Height	: On
Projection	: Gauss-Kruger

Height reduction: On / Off

Projection: Gauss-Krueger / UTM / Off

Default reduction: **Off**

The reductions act (when activated) parallel to the existing scale factor s on the distances measured.

92116 Stationing Scale range	
Scale Range : ±	1500 ppm

Scale range: Input in [ppm]


Default value: ± 1500 ppm

Tip

With a value of 0 ppm, the scale range will not be checked.

Heightstationing 4

Definition of standard deviations and error limits of the height stationing.




Menu of the configuration height stationing.

Heightstationing 4

Stand. Deviation 1

Definition of the distance section, for which $p = 1$ is applied.

$0 \leq c \leq 9999 \text{ m}$



Input distance c in [m].

Default: $c = 30 \text{ m}$

Example:

up to 30 m distance

$\rightarrow p = 1$

from 30 m distance onwards

$\rightarrow p = c^2 / D^2$

$c = 0$


$\rightarrow p = 1 / D^2$

Heightstationing 4

Error Limits 2

Definition of the max. admissible height deviation.


$0 \leq v_z \leq 1 \text{ m}$



Input height deviation v_z in [m].

Default: $v_z = 0.030 \text{ m}$

Overview Configuration Coordinates



922 Configuration Coordinates


- 9221 Detail Points
 - 92211 Verification Points
- 9222 Setting Out
 - 92221 Error Limits
 - 92222 Recording
- 9223 Traverse
- 9224 Intersections
- 9225 Transformation
 - 92251 Distance Deviation
 - 92252 Scale Range
- 9226 Helmert-Transformation
 - 92261 Error Limits
 - 92262 Adjustment
 - 92263 Scale Range

Coordinates 2

Setting and checking of error limits, admissible differences and ranges in the coordinate programs.

922 Coordinate Programs	
Detail Points	1
Setting Out	2
Traverse	3
Intersections	4
Transformation	5
Helmert Transf.	6

Menu configuration coordinate programs.

 Trimble® 3600 Manual Special/Professional

The Verification Point Configuration for Detail Point Measurement will be described Manual Part for the program packages *Special* and *Professional*.

Configuration Programs

Coordinates 2

Setting Out 2

Setting out configuration

9222 Setting Out	
Error Limits	1
Recording	2

Menu of the setting out configuration.

Setting Out 2

Error Limits 1


Admissible deviations for the definitive coordinates of the setting-out point.

92221 Setting Out Error Limits			
Linear Dev.	dr :	<input type="text" value="0.030"/>	m
Height Dev.	dh :	<input type="text" value="0.030"/>	m

Default value:

Linear deviation dr: 0.020 m

Height deviation dh: 0.020 m

 $0 \leq dr/dh < 1 \text{ m}$

 **Tip**


If one value is set to 0, this error limit will not be checked.

Setting Out 2

Storage 2

Activation or deactivation of the storage of setting out results.


92222 Setting Out Recording	
Lateral, Orthog. Dev	<input checked="" type="checkbox"/> On
Coord.-Diff.	<input type="checkbox"/> Off
Actual Coordinates	<input type="checkbox"/> Off

 **Toggle of switches On ↔ Off.**

 **Tip**

The description of further coordinate program configuration (Traverse etc.) will be done in the part of the manual *Special and Professional*.

Overview Configuration Special



Special 3

Point to Line 1

Configuration of the Point-to-Line Distances program.

Distance Deviation 1

Scale Range 2

Definition of the admissible scale range.

$$\text{✂} \quad -9999 \leq SR \leq 9999$$

Recording 3

To activate recording
Grid Coordinates

923 Special Programs
Point to Line 1
Multiple Rounds 3

Menu Configuration of Special Programs.

This manual describes the Point-to-Line Distances configuration. All the other special programs and their configuration will be explained in the part of the manual Special/Professional.

9231 Config. Point to Line Dist.
Dist. Deviation 1
Scale Range 2
Recording 3

↑ ↓ + ← to select.

92311 Point to Line - Deviation in dist
Max. distance ds = a + b*s² + c*s
a : 0.040 s[m]
b : 0.0080 ds[m]
c : 0.00030

Input of parameters for computation of the maximum distance deviation.

92312 Point to Line Scale Range
Scale Range : ± 1500 ppm

Scale Range: Input in [ppm]

Default Value: ± 1500 ppm

92313 Point to Line Recording
Grid Coordinates : OFF

Overview Configuration General Functions



924 Configuration General Functions

- 9241 Constants
- 9242 2-Face Measuring
 - 92421 Recording
 - 92422 Error Limits
- 9243 Control Point
- 9244 Distance Measuring
- 9245 Point Identification

General Functions 4

Configuration of general functions and constants.

924 General Functions	
Constants	1
2-Face Measuring	2
Control Point	3
Distance Meas.	4
Identical Point	5

Menu of the configuration of general functions.

General Functions 4

Constants 1

Modification of the constant parameters earth radius and refraction coefficient relevant to reductions and corrections.

9241 Constants	
Earth Curvature	: 6370000 m
Refractions Coefficient:	0.13

Input in the predefined measuring units of

Earth radius R: Default value 6370000 m

✎ $6300000 \text{ m} \leq R \leq 6400000 \text{ m}$

Refraction coefficient k: Default value 0.13

✎ $-1.00 \leq k \leq 1.00$

General Functions 4

2-Face Measuring 2

Configuration of the recording and error limits for points measured in two faces.

2-Face Measuring 2

Recording 1

9242 2-Face Measurement	
Recording	1
Error Limits	2

Menu of the configuration measurement in 2 faces.

92421 2-Face Measurement Recording	
Single Values	Off
Middle	On
Differences	Off



Toggle switch **On ↔ Off**.

Default switch: as shown in the screen shot.

Single values: Recording the single values from both faces.

Mean: Recording the mean from both faces.

Differences: Recording the differences between both faces measurements

Tip

For various recording modes the following is applied:

R-M Recording of the original measurements or the mean, resp., and/or the differences between them.

R-C Recording of the respective computation values in the same way.

R-MC Recording of measurement and computation values in the same way.

Configuration Programs

2-Face Measuring 2

Error Limits 2

Input of the error limits for the measurement in 2 faces.

- ✎ $0.0000 \leq da \leq 1 \text{ grad}$
- $0.000 \leq dq/dl/dh \leq 1 \text{ m}$

92422 2-Face Measure. Error Limits			
Angle Dev.	da :		0.0050 gon
Orthog. Dev.	dq :		0.020 m
Lateral Dev.	d1 :		0.020 m
Height Dev.	dh :		0.020 m

Input in the predefined measuring units of Default value:

Bearing deviation da: **0.0050 grad**

Transverse deviation dq: **0.020 m**

Longitudinal dev. dl: **0.020 m**

Height deviation dh: **0.020 m**

Tip

If one value is set to 0, this error limit will not be checked.

General Functions 4

Control Point 3

Input of the error limits for the control point measurement.

- ✎ $0.0000 \leq da \leq 1 \text{ grad}$
- $0.000 \leq dr/dq/dl \leq 1 \text{ m}$

9243 Control Point Error Limits			
Linear Dev.	dr :		0.030 m
Angle Dev.	da :		0.0050 gon
Orthog. Dev.	dq :		0.020 m
Lateral Dev.	d1 :		0.020 m

Input in the predefined measuring units of Default value:

Linear deviation dr: **0.030 m**

Bearing deviation da: **0.0050 grad**

Transverse deviation dq: **0.020 m**

Longitudinal dev. dl: **0.020 m**

Tip

If one value is set to 0, this error limit will not be checked.

Configuration Programs

General Functions 4

Distance Measurement 4

Configuration measurement functions for Distance

Distance Measurement 4

Precision Mode (Prism) 1

Configuration multiple measurements for distance meter mode N

Multiple Mode (DR) 2

Configuration multiple measurements for distance meter mode N

Humidity 3

Humidity - configuration and correction

9244 Distance Measurement	
Precision mode (Prism)	1
Multiple mode (DR)	2
Humidity	3
Tracking Data recording	4

92441 Precision Mode (Prism)	
Standard deviation	: 0.0006 m
Number of shots	: 3

Setting the standard deviation and/or a number of shots

92442 Multiple Mode (DR)	
Maximum variation Limit	: 0.0100 m
Number of shots	: 3

Setting a limit between the shots and/or a number of shots

92443 Humidity	
Input mode	: Off
Default humidity	: 60 %

Input Mode:

OFF (Default with 60%) the key in default value is used as standard.

Wet Temperature Input of the Wet Temperature with **Inpt**

Rel.Humidity (%) Input of the rel. Humidity with **Inpt**

Default humidity: Input the value in %

Configuration Programs

General Functions 4

Identical Points 5

Input of a linear deviation for decision of identical points.

$0 \leq dr \leq 1 \text{ m}$



Input in the predefined measuring unit of Default value:

Linear deviation dr: **0.020 m**

Tip


When setting the value for **dr** to **0**, then the default value is used internally.

Configuration Standard Settings


Programs 2

Default Settings 0

Setting of standard values for all program configurations..



Select with or .



Yes For setting default (standard) values.

No No default settings, back to menu Configuration Programs.

Configuration 9

Markings 3

```
123456789-123456789-1234567
<---PNr-----><---Info----->
C                T
<pppppppppppp><eeeeeeeeee>
```



Generating and processing markings for the point identification.


The 27-digit point identification (PI) can be occupied with different blocks:

- Point number block <ppp...>
<nnn...>
- Text block <eee...>
<###...>
- Code block <ccc...>
- Time block <ttt...>
- Spaces block >---...<

A multiple definition of text and code blocks is possible.

Only one point number block and one time block can be defined at a time.

A maximum of 10 markings can be entered.

 1 ≤ number ≤ 10

Marking No. 1 is the standard marking.

Tip

The instrument is delivered with a standard setting of marking No. 1 which can be overwritten by another marking.

As pre-requisite for the storage of a marking, at least one point number block must be set.

Esc for escaping the *Configuration Markings*.

 Store marking

Configuration Markings

Processing of set markings



Legend of the lines:


- 1 Action
- 2 Operation
- 3 Ruler
- 4 Field label
- 5 Control character
- 6 Block marking


After calling up the *Configuration markings*, the first marking which has been set is shown in the display:


1	93 Marking list		Nr.	1/5
2	---			
3	123456789-123456789-1234567			
4	<---PNr-----><---Info---			
5	E T			
6	<pppppppppppp><eeeeeeeeeee>			
	New	Del		Edit


Nr. 1/5 indicates the consecutive number (**1**) of the displayed marking out of all defined markings (**5**).


  Scrolling in the marking list (endless)


 Display of the first marking

 Display of the last marking set

 Back to menu *Configuration*


 generate new marking


 delete displayed marking

 edit displayed marking

Delete marking

93 Marking list		Nr.	1/3
Delete Marking ?			
123			Yes No
<--			
C			
<pp			
New	Del		Edit

 Marking is deleted, renumbering of the remaining markings.

 Back, without deletion of marking.

 similar to **No**.

Edit marking in analogy to *Marking New*



Generating new Markings

New Select in the display of the marking list

931 Marking definition			Nr.	4/4
123456789-123456789-1234567			End:	Esc

Tab	Curs	List	PNr	Code
Time	Del			

Menu for generating new markings. The cursor is placed in column 1 of the field label (line 4).

  go to input position

 cursor jump to column 1

 cursor jump to column 27

The field label is an information which can be entered in addition to the blocks set.

Input of the field label

For the input, all alphanumeric characters, including special characters, are available. Special characters (like <, >, _ , & etc.) will be displayed by multiple pressing (scrolling) of the decimal point key.

931 Marking definition			Nr.	4/4
123456789-123456789-1234567			End:	Esc

<Point No><Code><Descriptn>				

Tab	Curs	List	PNr	Code
Time	Del			

 usable for deleting signs.

The code field is stored with the marking.

Tip

In a measuring program, the field label is used as orientation for the blocks set. Consequently, it should be entered in that way.

PNr Set point number block

Setting the point number block

Go with the cursor control keys to the initial position of the point number block.

931 Marking definition		Nr.	2/2
		Point number	
123456789-123456789		Alpha-Numeric	
<---PNr---><Code><		Numeric	

Tab	Curs	List	PNr Code Time Del

Selection type of point number (numeric or alpha-numeric point number).

For entering a point number in the measurement menu then will be defined:

Numeric only numbers in the block ,

Alpha-Numeric all signs allowed.

 +  to select.

<p> alpha-numeric

Via **alpha-numeric** selection the block is marked with **<p>** in line 6 (block marking), beginning at the current cursor position.

Point number field		Nr.	2/2
End position: + +		End:	←
123456789-123456789-1234567			
<---PNr---><Code><			
C			
<pppppppp>-----			

Tab	Curs	List	PNr Code Time Del

<n> numeric

Via **numeric** selection the block is marked with **<n>** in line 6 (block marking), beginning at the current cursor position.

Point number field		Nr.	2/2
End position: + +		End:	←
123456789-123456789-1234567			
<---PNr---><Code><			
C			
<nnnnnnnn>-----			

Tab	Curs	List	PNr Code Time Del

 **Tip**

The characters < > belong to the block, therefore, the minimum size <p> or <n> comprehends 3 characters.

As proposal, the default cursor position (**C** in line 5) is set on the first place within the PNr block, but that can be changed any time with **Curs**.



go to final position of the PNr block.



$3 \leq \text{PNr block} \leq 14$

A maximum of 14 characters can be set for the PNr block.



Accept point number block.

 **Tip**

When pressing PNr then at another place of the PI, the old entry in the block marking is deleted and set again at the new position.

Setting a text or code block

A maximum of 5 blocks can be defined as text or code blocks. There is as well a numerical or an alphanumerical selection possible.



Configuration Codelists

When entering the PI, a *codelist* can be accessed within the code blocks.

Code

Set text or code block

Go with the cursor control keys to the initial position of the text or code block.

Text and Code field End position: + →	Nr. 4/4 End: ↩
123456789-123456789-1234567 <Point No><Code><Descriptn> C T <pppppppp><eeee>-----	
Tab. CURS	List. PNR Code Time Del.

Via **Code**, the block is marked with <> in line 6 (block marking), beginning at the current cursor position. This is the minimum size of a text or code block. Each alphanumerical code block is being marked as block <eeee...>, each numerical as block <#####...>.

Tip

As proposal, the default tabulator position (T in line 5) is set on the first place within the text or code block, but that can be changed any time with **Tab**.



go to final position of the text or code block.



2 ≤ text block ≤ 24

A maximum of 24 characters can be set for a text or code block.



Accept text or code block.

Allocating a codelist


It is possible to allocate a codelist to a text block set, converting thus the text block into a code block.


Set the cursor on the text block destined to become the code block.

List Allocating a codelist

931 Marking definition		Nr.	4/4
Select with spacekey			
123456789-123456789		* Roadlines	
<Point No><Code><De		Backsights	
C		Points	
<pppppppp><eeee><ee		Buildings	
Tab	Curs	List	PNR
Code	Time	Del	

With **List**, all selectable codelists are offered. If no codelist has been defined yet, the softkey **List** has no effect.

 for selection (also various codelists).

 Allocation of all marked codelists and back to the menu.

931 Marking definition		Nr.	4/4
		End:	Esc
123456789-123456789-1234567			
<Point No><Code><Descriptn>			
C			
<pppppppp><cccc><eeeeeeee>			
Tab	Curs	List	PNR
Code	Time	Del	

The block marking <eee...> has now been replaced by the block marking <ccc...>.

Tip

It is also possible to allocate a codelist subsequently in a marking that has already been generated.



Configuration Instrument / Clock

Time Set time block

Setting a time block

In this field, the system time is automatically stored in the time format specified. A time block cannot be set within another block.

Select with the cursor control keys the initial position of the time block.

931 Marking definition		Nr.	4/4
		End:	Esc
123456789-123456789-1234567			
<Point No><Code><Time><Txt>			
C	T	T	
<pppppppp><cccc><ttt>-----			
Tab	Curs	List	PNr Code Time Del

Via **Time**, the block is marked with `<ttt>` in line 6 (block marking), beginning at the current cursor position.

Tip

If the space available between the initial position and the marking end or the next block is not sufficient for the configured time format, the softkey **Time** has no effect.

<pppp>-----<cccccc>
 ↙
 space block

Setting a space block

At the beginning of a marking definition all places of the marking are occupied by forced blanks (----- in the block marking, line 6). By specifying blocks, these blanks are occupied accordingly.

With the initial positioning of blocks, blanks can be set between the blocks which are then locked when entering the PI and for tab stops.

Del Deleting blocks

Further function keys

Set the cursor into the block range and delete the block with **Del** (attention, without enquiry!).

Tip

For changing initial positions, the blocks are first to be deleted.

Tab Setting tab stops

Tab stops can be set at any position (exception: forced blanks). A tab stop can be set in each defined input block. When entering the PI, the cursor jumps to this position by means of the

Tab key.

Go to the target position using the cursor control keys and set a tab stop with **Tab**s. A **T** will appear in line 5 (control characters). The tab stop can be deleted again with the **Del** softkey.

Curs Setting a default cursor position

The default cursor position can be set at any position (exception: forced blanks). For each marking, only one default cursor position can be set. The cursor jumps automatically to this position after a measurement for entering or editing the PI.

Go to the target position using the cursor control keys and set the position with **Curs**. A **C** will appear in line 5 (control characters). If a tab stop **T** has been set at the same place, this will be overwritten by **C**. The cursor position is of equal importance to the tabulator.

Tip

When setting **Curs** at another place, the old **C** is being deleted.

Store marking

Esc for quit in the menu of the *Configuration markings* leads to the enquiry:

Marking definition	Nr	4/4
		Esc
123	Save Changes ?	
<Po	Yes No	
C		
<pp		

Tab: Curs List PNr Code Time Del

Yes Acceptance of the marking with consecutive number, continues with display of the renumbered markings.

No Marking is not accepted, the old status of the marking list is being re-established. Back to the display of the markings.

Esc Back to the definition of the new marking.


Technical Info

The markings will be stored in file Marko.txt in the directory D:\ELTAC\INIT.

Configuration Codelists

Configuration 9


Codelists 4



For objects of everyday surveying, coded point information can be managed in the form of code-lists.

Thus, they can be allocated quickly and simply to a code block of the marking and, consequently, to the PI during the measurement.

After being called up from the configuration menu, the codelists already generated are displayed:



New Creating a new codelist

A maximum of 16 lists can be stored. Having reached this number, the functions **New** and **Copy** are no longer available.

The number of codes per list depends on the available memory.

Processing codelists

Del Delete a codelist



Yes Deletion of selected codelist.


No (or Esc) Back, without deletion.

Conn Connecting two codelists

Select the first codelist with the cursor control keys, then, select **Conn** in order to connect the first with a second list out of the remaining code-lists.

Confirm the selection of the second codelist with





Example:

First codelist: *Backsights*

Second codelist: *Points*

Yes List *Points* is added to the list *Backsights*. The added list *Points* is deleted and does no longer appear.

No **Esc** Back to menu *codelists*.

Copy Copying the selected codelist

Name Renaming the selected codelist

Select codelist with the cursor control keys, select then **Copy** oder **Name** in order to copy or rename the list.



Name: Data string with a maximum of 18 alphanumeric characters.

↵ List is copied with new name or renamed.

Esc Back to menu *Codelists*.

Tip

Codelists cannot be copied or renamed using the same name with the same ASCII characters.

But a difference is made between upper-case and lower-case letters, i.e. names like *LIST* and *List* are different.

Generating new codelist

New Creating a new codelist



Name: Data string with a maximum of 18 alphanumeric characters.



List is generated with the name, at the same time a check is carried out with regard to names of the same ASCII strings already assigned.



Back to menu *Codelists*.

Editing codelist

Edit Editing an existing codelist

Set the cursor at the codelist to be edited and select **Edit**:



Example: Editing the codelist *point type*.

Code: A maximum of 10 alphanumeric characters.



Meaning: Description of the code with a maximum of 20 alphanumeric characters.


Tip


In the application program, the **Code** is transferred into the code block allocated to the list.


Admissible keys for editing codelist

    Scrolling in the codelist.


  Jump to the first or last position of the input field.

 Changing the input field between code and meaning.

 Accepting code input in list.

 Escape editing of codelist.

New Entering a new code



Entering a code and its meaning.

Del Delete code

Set cursor onto the code line and delete code with **Del** (attention, no enquiry!).

By this function, the selected code line is deleted immediately and copied in a buffer memory.


Ins Inserting a code line

Inserts the code line saved in the buffer memory, in front of the marked code line.

Tip

Consequently, with the functions **Del** and **Ins**, also code lines can be copied and relocated.

Srch Searching a code line



Search for code **or** meaning, also of partial strings. No attention is paid to upper-case or lower-case letters.



Search is carried out from the cursor position downwards. If the search is successful, the cursor jumps to the respective code position.



Without search back to the editing menu.

?↓ Continuing search for a code line

If the code line found is not the one searched for, the search downwards can be continued immediately by means of this function.


Technical Info

The codelist will be stored in file Koco.txt in the directory D:\ELTAC\INIT.

Configuration Update


Configuration 9

Update 5



For activation of the software-packages it is necessary, to enter a code generated by Trimble for the instrument.


There is one authorisation code for each software package. After input you get access to the software.



Menu Update Configuration.


Input Authorisation Code 1

Code Input for each software package.



Select the software-package by cursor-keys.

Edit For code input / change



Input of the authorisation code.

to confirm the code input.

Esc abort input.

⚠ Attention !

The authorisation code is the same for the Trimble 3600 as for the ReLink and has to be entered on the Trimble 3600 instrument.



The annex contains a compilation of symbols, keys, formulae and constants as well as explanations of concepts used for the Trimble™ 3600.

Furthermore, it gives an overview of the technical data and instructions for maintenance and care of the instrument. Important certificates are also attached.

Symbols and Keys

Geodetic Glossary



Technical Data

Formulae and Constants

Further available Documentation

Status Symbols

The instrument displays status symbols to show internal instrument settings.



Symbols for Measure Mode

SD Hz V HD Hz h Y X Z Hz V

EDM Mode

Direct Reflex* Prisma Prisma Direct Reflex*

Vertical Reference System

Zenith Vertical Height Slope [%]

Error Limits

switched off switched on

PositionLight*

PositionLight on

Illumination

Display on Cross hairs on




















Recording switched on



Compensator switched on

* Option

Symbols and Keys







Keys and Function

Escape		Quitting program levels
Shift		Dual assignment switchover
Tabulator		Selector and tab key
Caps		Upper-case and lower-case letters
Softkey Activation		Control and hotkeys
Softkeys		Softkeys 1-6 and instrument control
Space key		Space and selector key
Cursor keys	 	Positioning the Cursor up/down
Cursor keys	 	Positioning the Cursor to the left/right
Numeric block	 	Numeric input function and Softkeys 7-10
Enter key		Confirmation + measurement triggering
Power key		Switching the instrument on
Page Up		Scrolling up
Page Down		Scrolling down
Home		Cursor at the start of line or list
End		Cursor at the end of line or list

- Backspace  Delete a sign to the left
- Additional trigger key  Trigger key located on the right-hand side of the instrument, particularly useful when measuring in the reverse position.

Instrument Control

The yellow signed symbols above the function keys 1-6 are used for controlling of significant instrument switches and parameters and can be activated pressing Shift + function key:

-  Illumination Crosshair + Display On / Off
-  Instrument Levelling
-  Battery Control
-  PositionLight On / Off
- Help** Online-Help
-  EDM Mode
-  Laser Pointer

A

Addition correction Correction of the addition value ("additive constant") of the distance measuring instrument

B

Backsight point A point with known coordinates used for the station point determination and/or for *orientation*.

Bearing angle Hz bearing orientated to a reference bearing (generally to grid north)

Bearing (Hz) Value read in the horizontal circle of the instrument, whose accidental orientation is determined by the zero position of the graduated circle.

C

Calibration scale influences systematically the distance measurement. Best possible adjustment to 1.0 by the manufacturer. Without influence on all other scale specifications

Code, code lists Reference number for the point description, characterizes certain point types, compilation and explanation in *code lists*

Compensation Mathematical consideration of the *vertical axis inclinations* measured with the *compensator*, in Hz and V angle measurements

Compensator run center electronic center of the clinometer in sighting and trunnion axis directions

Configuration Basic settings of the instrument (e.g. measuring units, coordinate system etc.). Proceeding from the respective measuring program, it is possible to access locally the relevant configuration. The configuration can be transmitted to other instruments/computers.

Connecting distance Spatial distance, plane distance and height difference between 2 target points

Geodetic Glossary

Control point	Point for checking the <i>orientation</i> of the instrument. It is defined at the beginning of a measurement and can be measured any time for checking.
Coordinates, global	higher-order coordinate system (e.g. Gauss-Krüger)
Coordinates, local	Zero of this coordinate system is the station point of the instrument with the coordinates (0,0,0). The <i>orientation</i> is determined by the zero direction of the Hz circle
D	
Distance measuring method	Variable measuring time (and with it measuring accuracy) in accordance with the purpose of application: Normal D:N , Tracking D:T
Dual Control	Sighting process in the instrument and measurement from the target;
E	
Eccentricity = eccentric target measurement	The reflector is not set up right in the target point, but in a defined position to it.
Eccentricity mode	Switch for toggling <i>eccentric target point measurement</i>
Eccentric station	Program for an <i>eccentric stationing</i> , if the position of the center is unfavourable for the backsight measurement or for the following survey or setting out
Error limits	Limit values which can be set by the user for certain measuring values or results

F

Free Stationing Free choice of the station. The measurements to known *backsight points* are taken as starting point for computing the station coordinates, the *scale* and the orientation of the graduated circle by *single point adjustment* or *Helmert transformation*

H

Height stationing The height of the station point is derived from measurements to known height points

Helmert transformation *Transformation* (similarity transformation) named after Helmert, between two rectangular coordinate systems, *free stationing*

Hidden point reflector rod Reflector rod with 2 reflectors arranged in a fixed distance to each other; for the position and height determination of inaccessible points such as channels, shafts, room corners; can be held also in oblique position to the point to be measured

H_z collimation correction (also correction of collimation or sighting axis)
Correction of the deviation of the sighting axis from its required position at right angles to the trunnion axis. Determination by measurement in two positions, automatic correction in measurements in one position

I

Incrementing Input of an interval (increment), by which the point number is automatically counted

Instrument height Height of the telescope trunnion axis above the station height (ground point)

Interface Contact point between 2 systems or system areas, in which information is interchanged according to defined rules

L

- L1 Norm** Adjustment in which the sum of the absolute corrections is turned into the minimum, for recognizing outliers with special accuracy. In all adjustments, an L1 adjustment can be additionally calculated.
- L2 Norm** Adjustment in which the sum of the correction squares is turned into the minimum (adjustment according to the method of least squares)

O

- Object height** Determination of the height of points to which a direct distance measurement is impossible, by means of a pure angle measurement
- Orientation** When orientating the instrument, the *bearing angle* of the zero of the graduated circle Omega (Ω_m) is calculated. For this, measurements to one or various *backsight points* can be made or the *bearing angle* of a known point can be entered.

P

- Point Identification** Identification of the measuring point by a maximum of 27 characters for the point number and up to 5 code fields; data record format M5
- Point number** Numerical or alphanumerical part of the point identification
- PositionLight** Quick optical sighting aid for setting out; visualization of the sighting line for the reflector porter so that he can orientate himself independently and quickly with reference to the sighting line
- Project** Quantity of data sets, which are combined under one name into an independent unit within the database
- Projection reduction** Reduction into the projection plane

R

Radio data transmission module	Radio communication between station and target for transmitting data and information, Observe announcement.
RecLink	Alphanumeric computer with radio data transmission module for controlling the measuring process from the target point
Recording mode	Switch in all measuring programs for controlling, which data are to be recorded: measuring values, computing values or both types
Reference Point	used here as reflector station for the indirect height determination
Refraction coefficient	Measure for the light-beam refraction in the atmosphere; can be set by the user
Residual	Difference between nominal and transformed coordinates
Run center	see <i>Compensator run centers</i>
<h2>S</h2>	
Scale	With a <i>scale</i> , the measured distance is varied proportionally to the length and can thus be adapted to certain marginal conditions. There exist a series of direct and indirect scale effects: <i>calibration scale</i> , <i>weather correction</i> , <i>projection reduction</i> , height reduction, reticle scale
Single point adjustment	Method for computing a <i>free stationing</i> by adjustment of all distance and bearing observations according to the method of least squares.
Softkey	Function key which has different functions in dependence on the program
Standard deviation	Statistical value for the accuracy of a computed value

Standard project	Project implemented by the manufacturer (project name: NONAME), which can be used without project definition
Standard settings	Values set by the manufacturer, for all configuration parameters
Stationing	Station point determination and/or calculation of the orientation of the graduated circle: stationing on a known point, free stationing and off-center station, height stationing (height only)
Stationing on a known point	Given: Station point coordinates / backsight bearing. The <i>scale</i> and the <i>orientation</i> of the graduated circle are derived from the measurements to known <i>backsight points</i>

T

Time	The time can be displayed and recorded together with the measuring values in the <i>point identification</i>
Tracking	Continuous measurement of the angles and distances. Generally, Hz and V values are always measured and displayed; set permanent measurement for distance measurements
Transformation	Computing program for converting point coordinates between different coordinate systems. At least 2 identical points have to be known in both systems.

V

Vertical axis inclination	The inclinations of the vertical axis of the instrument in sighting axis direction and trunnion axis direction are measured with the <i>compensator</i> . Digital and analog representation of the inclinations on the display.
---------------------------	---

W

Weather correction

Correction of the distance measurement by values for temperature and air pressure which deviate from the standard values


Weighting specifications

For the adjustment, a certain influence (direct or indirectly by specifying *standard deviations*) on the total result can be assigned to the measuring values (stationing programs)

External Interface Port

The external interface port is a 8-pin plug (female) referring DIN 41524.

This port is used for data transfer and power supply by external battery. The port is fixed on the slip ring of the instrument.



PIN Location
(seen from the outside)

PINs

Pin	Signal	In/Out	Function
1	RTS	Output	Ready To Send
2	GND		Ground
3	CTS	Input	Clear To Send
4	TD	Output	Send
5	RD	Input	Receive
6	VCC	Input	Power Supply
7	VCC	Input	Power Supply
8	GND		Ground

Cable Connection

For data transfer via cable the serial interface cable with ordering number 708177-9460 or 708177-9470 can be used.

For external power supply and data transfer a special cable („Y-cable“) with ordering number 701520-9186-000 must be connected to the instrument.

Computations formulae for angle measurement

V angle measurement

$$V_k = V_O + V_1 + V_2 + i + nz$$

V_O = uncorrected V circle reading

V_1 = correction due to V circle eccentricity

$$V_1 = A_V \cdot \sin(V_O - \phi_V)$$

A_V = amplitude

ϕ_V = phase

V_2 = V circle orientation

i = index correction

$$i = \frac{1}{2} (400 - V_I - V_{II})$$

nz = current vertical axis inclination in the sighting direction

Hz bearing measurement

$$Hz = Hz_O + Hz_1 + Hz_2 + Hz_3 + Hz_4 + A$$

Hz_O = uncorr. Hz circle reading-(absolut)

Hz_1 = corr. due to Hz circle eccentricity

$$Hz_1 = A_{Hz} \cdot \sin(Hz_O - \phi_{Hz})$$

A_{Hz} = amplitude

ϕ_{Hz} = phase

Hz_2 = due to collimation correction

$$Hz_2 = c / \sin V_k$$

$$c = - \sin(V_{II}) \cdot \frac{dHz}{2}$$

$$dHz = (Hz_{II} - Hz_I + 200)$$

$$Hz_{II}, Hz_I = Hz \text{ in Lage 1,2}$$

c = collimation error

Hz_3 = due to current nk vertical axis inclination in the tilting axis direction

$$Hz_3 = nk / \tan V_k$$

Hz_4 = corr. due to tilting axis error k

$$Hz_4 = k / \tan V_k$$

A = circle orientation, e. g. Hz setting
(necessary for computations of coordinates)

Formulae and Constants

Computations formulae for distance measurement

Internal correction formulae (with correction from external calibration)

- $D_{c1} = D_u \cdot m_{cal} + Ak_{cal}$
 D_u = uncorrected measured distance
 m_{cal} = scale from external calibration
 Ak_{cal} = addition constant from external calibration

Weather correction formulae with additional constants.

- $D_{c2} = D_{c1} (1 + K_W 10^{-6}) + A_c + T_r$
 carrier wavelength 0.66 μm
 precision scale 0,5 m
 D_{c1} = corrected distance
 A_c = addition constant
 K_W = weather correction
 T_r = threedimensional eccentricity (value input in menu 912)

The weather correction K_W is computed as follows:

$$K_W = 278.8 \cdot \left[\frac{0.29527}{1 + \alpha t} P - \frac{4.126 \cdot 10^{-4} h}{1 + \alpha t} E \right]$$

- p = air pressure in hPa
 t = temperature in degrees Celsius
 h = relative humidity in %
 α = coefficient of vapour pressure correction 1/273,16
 E = saturation air pressure to Magnus Tetens
 $E = 10^{\frac{7.5 \cdot t}{t+237.3} + 0.7857}$

In case of standard atmospheric conditions with $p = 1013,25$ hPa, $t = 20$ °C und $h = 60\%$ the correction K_W disappears. The basic value of $h = 60\%$ for the relative humidity is fixed. When the conditions are very extremely (humid and hot) the deviation of weather correction is maximal 2 ppm.

Formulae and Constants

Reduction formulae

V angle measurement

Refraction correction of the V angle measurement

$$V' = V_k + \frac{\delta}{2} = \frac{D_{k2}}{2R} \cdot k_L \cdot \rho$$

Distance measurement

Horizontal distance in the instrument horizon

$$E = \frac{R}{\rho} \cdot \arctan \frac{D_{k2} \cdot \sin V'}{R + D_{k2} \cdot \cos V'} \quad \rho = \frac{200}{\pi}$$

Height difference

included are corrections of refraction, earth curvature, instrument- and reflector height

$$dh = D_{k2} \cdot \cos V_k + \frac{1 - k_L}{2R} \cdot E^2 + ih - th$$

V_k = corrected V circle reading

k_L = influence of refraction,
Default: 0.13

R = mean earth radius in the field,
Default: 6 370 000 m

ih = instrument height

th = reflector height

Horizontal distance with scale correction

$$E_m = E \cdot m$$

E = horizontal distance in the instrument horizon

E_m = horizontal distance with scale corr. m
= scale (e.g. from Free Stationing)

Height reduction

Reduction of horizontal distances from instrument horizon into the used projection horizon (e.g. NN)

$$E_o = E_m \cdot \frac{R}{R + H}$$

E_m = distance in the instrument horizon [m]

E_o = distance in the used projection horizon [m] R

= mean earth radius in the project [m]

H = mean height in the project [m]

Reduction into the projection plane

The distance is reduced into the projection plan with the mean distance from the main meridian.

1. Gauß - Krüger -Projection

$$E_{\text{GK}} = E + k_{\text{GK}} \quad k_{\text{GK}} = E \cdot \frac{Y_m^2}{2R^2}$$

$$E_{\text{GK}} = E \left(1 + \frac{Y_m^2}{2R^2} \right) = E + E \cdot \frac{Y_m^2}{2R^2}$$

with:

- E = Distance between two points
- E_{GK} = distance in the Gauß-Krüger-Plane
- Y_m = mean distance from the main meridian
- R = earth radius

2. UTM - Projection

$$E_{\text{UTM}} = E \cdot 0,9996 \left(1 + \frac{Y_m^2}{2R^2} \right)$$

Note:

Distances used in stationing and e.g. in a subsequent polar survey must be treated identically. If, for example, no height and projection reductions have been applied in stationing, this must also not be done in the polar survey. In this case, the corresponding reduction is incorporated in the randomly selected scale or in the stationing corrections, if a given scale is used. In the latter case, it is always advisable to perform a best-fit adjustment if major corrections are involved.

Verifying on Calibration Distances


Basically, all measured distances are corrected with reference to:
the entered scale
the entered additive constant
the influence of pressure and temperature
internal influencing variables.

⚡ Attention!

Prior to the practical realization of the calibration measurement, the current values of the parameters additive constant, pressure and temperature are to be entered. Projection reduction and height reduction are to be deactivated and the scale is to be set to default: 1.000000, as the test distances normally are not referred to sea level. This is to secure that all corrections are made completely and perfectly. Furthermore, this allows a direct comparison of nominal and actual values.

If a weather correction is to be carried out externally, the temperature must be set to 20°C and the air pressure to 1013.25 hPa. Then, the internal correction goes to zero.

Total Station Trimble 3600 Zeiss Elta



User Manual Trimble 3600 Zeiss Elta,
Part 2 for program packages

Special and Professional

Cat-No.: 1073.496
(702722-7044-004)

Total Station Trimble 3600 Zeiss Elta

API

Application Programming Interface

Programming Manual for the
Trimble 3600 Zeiss Elta TS.

The Trimble 3600 Zeiss Elta is programmable in several programming languages. This Manual describes the programming interfaces and functions at the hand of many source code examples. A diskette with the necessary programming tools and source codes is given with the programming manual.

Order.-Code.: CAPI_E.DOC V1.10





ZSP Geodetic Systems GmbH
Carl-Zeiss-Promenade 10
D-07745 Jena
Germany

Phone: +49 3641 64-3200
Fax: + 49 3641 64-3229
email: surveying@zspjena.de
www.trimble.com