| 1 | Introduction                | Dear Customer1-1   |
|---|-----------------------------|--|
|   |                             | The system philosophy1-1   |
|   |                             | Use of this manual1-2  |
|   |                             | Important notes1-3   |
| 2 | Zeiss Elta®<br>Control Unit | Control Unit Description2-2QWERTY keyboard2-2Graphic display2-4Attaching/Detaching the Control unit2-5Software overview2-6Modular structure of the system software.2-7 |
|   |                             | Operation2-9   |
|   |                             | Switching the instrument on and off2-9   |
|   |                             | Servo control2-14  |
|   |                             | Autolock <sup>™</sup> (only for servo instruments)2-15   |
|   |                             | Tracker (only for servo instruments)2-16   |
|   |                             | TrackLight <sup>®</sup> 2-18   |
|   |                             | Basics   |
|   |                             | Conventional surveying with Autolock <sup>™</sup>  |
|   |                             | (only servo)   |
|   |                             | Remote surveying   |
|   |                             | Robotic Surveying (only servo)2-36<br>Distance Mode Direct Reflex (Option)2-53   |
|   |                             | EDM Mode and reflectortyp2-56  |
|   |                             | When using EDM Modes?  |
|   |                             | Direct Reflex Distance Measurement2-59   |
|   |                             | Menu guidance2-63  |
|   |                             | Help function2-65  |
|   |                             | Zeiss Elta <sup>®</sup> CU and Radio 2-66  |
|   |                             | Zeiss Elta <sup>®</sup> CU2-66   |

| Safety Notes | 2-72 |
|--------------|------|
| Risks in use |      |

# 3 **First Steps** Before Measurement 3-2 Project Management ...... 3-6 Delete, Rename, and Copy a Project......3-7 Measuring in a Local System ...... 3-8 Input of the Point Identification PI ......3-11 Prism Search and Prism Tracking (RMT)...3-12 Motorised Directions and Hz-Circle Orientation 3-17 Further Switches and Technical Matters...3-19

4

| Stationing | Free Stationing4-2                         |
|------------|--|
|            | Free Stationing Measurement                |
|            | Adjustment Procedure4-6                    |
|            | Configuration of Free Stationing4-9        |
|            | Neighbourhood principle and                |
|            | Distance Reductions                        |
|            | Error Handling4-12                         |
|            | Heightstationing4-13                       |
|            | Results of the Free Stationing4-14         |
|            | Stationing on a Known Point                |
|            | Orientation through Backsight              |
|            | Measurement4-16                            |
|            | Orientientation through input and          |
|            | measurement of a bearing4-17               |
|            | Results of Stationing on a Known Point4-18 |
|            | Heightstationing 4-19                      |
|            | Measurement and Adjustment                 |
|            | Entering a height value4-20                |
|            | Results of the Heightstationing4-21        |
|            | Eccentric Stationing 4-22                  |
|            | Measurement Eccentric Station              |


| 5 | Coordinates  | Detail Points5-2                      |
|---|--------------|---------------------------------------|
|   |              | Eccentric Measuring / Intersection5-3 |
|   |              | Hidden Point Measurement5-6           |
|   |              | Object Height Measurement5-7          |
|   |              | Connecting Distances5-8               |
|   |              | 2 Face Measurement5-8                 |
|   |              | Distance and FineLock Tracking5-9     |
|   |              | Value Corrections5-10                 |
|   |              | Setting Out5-12                       |
|   |              | Rectangular Coordinates5-12           |
|   |              | Station Check5-15                     |
| 6 | Advanced     | Point-to-Line Distance                |
|   | Applications | Measuring in a local system           |
|   |              | Measuring in a coordinate system6-5   |

| 7 | Data<br>Management | Editor7-2Entering a data record7-3Editing a data record7-4Filtering of records7-5 |
|---|--------------------|---|
|   |                    | Searching for data records  |
|   |                    | Deleting data records   |
|   |                    | Further function keys7-13   |
|   |                    | Data Transfer7-14   |
|   |                    | PC Terminal settings7-16  |
|   |                    | Elta <sup>®</sup> CU Data transmission7-18  |
|   |                    | Data reception7-20  |
|   |                    | Data Format 7-21  |
|   |                    | M5 data format7-21  |
|   |                    | M5 data line7-21  |
|   |                    | PCMCIA Card Data Memory   |
|   |                    | PCMCIA cards7-24  |
|   |                    | PCMCIA drives7-25   |
|   |                    | Formatting a PCMCIA card7-26  |
| 8 | Adjustment         | Adjustment8-2   |
|   |                    | Adjustment methods8-2   |
|   |                    | Instrument errors and their corrections8-3  |
|   |                    | Adjusting V Index/Hz collimation  |
|   |                    | Adjusting Tracker Unit8-6   |
|   |                    | Adjusting Compensator8-8  |

| 9 | Configuration | Configuration9-1                       |
|---|---------------|--|
|   |               | Operation in the submenus9-2           |
|   |               | Configuration Instrument               |
|   |               | Overview Instrument Configuration9-3   |
|   |               | Configuration Programs                 |
|   |               | Overview Configuration Stationing9-13  |
|   |               | Overview Configuration Coordinates9-18 |
|   |               | Overview Configuration Special9-20     |
|   |               | Overwiev Configuration                 |
|   |               | General Functions9-21                  |
|   |               | Configuration Standard Settings9-24    |
|   |               | Configuration Markings                 |
|   |               | Processing of set markings9-26         |
|   |               | Generating new Markings9-27            |
|   |               | Store marking9-34                      |
|   |               | Configuration Codelists                |
|   |               | Processing codelists                   |
|   |               | Generating new codelist                |
|   |               | Editing codelist9-37                   |
|   |               | Configuration Update                   |

| Annex | Symbols and keys10-2   |  |
|-------|--|--|
|       | Keys and Function10-3  |  |
|       | Hotkeys and Function10-4   |  |
|       | Geodetic Glossary 10-6   |  |
|       | _ Technical Data 10-13   |  |
|       | Electromagnetic Compatibility (EMV) 10-13  |  |
|       | Zeiss Elta <sup>®</sup> Control Unit10-14  |  |
|       |  |  |
|       | Formulae and Constants 10-16   |  |
|       | Computations formulae for angle  |  |
|       | Computations formulae for angle<br>measurement10-16  |  |
|       | Computations formulae for angle<br>measurement10-16<br>Computations formulae for distance  |  |
|       | Computations formulae for angle<br>measurement10-16<br>Computations formulae for distance<br>measurement10-17                            |  |
|       | Computations formulae for angle<br>measurement10-16<br>Computations formulae for distance<br>measurement10-17<br>Reduction formulae10-18 |  |
|       | Computations formulae for angle<br>measurement   |  |
|       | Computations formulae for angle<br>measurement10-16<br>Computations formulae for distance<br>measurement10-17<br>Reduction formulae10-18 |  |
|       | Computations formulae for angle<br>measurement   |  |

#### Main Menu and Pages



#### **Dear Customer**

By purchasing a Zeiss Elta® CU from Trimble AB you have opted for a leading-edge product in the field of surveying instruments.

We congratulate you on your choice and would like to thank you for the trust placed in our company.

## The system philosophy

Surveying today is no longer confined to the measurement of angles and distances. A demand now exists for complex measuring systems which not only meet the increasing requirements for automatization, digital data processing and last but not least efficiency in everyday surveying, but which also set new standards in technology and operating convenience.

The Zeiss Elta® CU is part of a complete range of surveying instruments from Trimble. Data interchange between all the instruments is ensured by a common data format and by the use of the PCMCIA memory card.

The operating convenience that is offered by the Zeiss Elta® CU hardware is unique. The large graphic display and the appropriately adapted PC keyboard give the user a high degree of flexibility for the processing of the wide information variety in the measurement dialog.

The modular software structure meets all requirements from "Basic" to "Special".

# Use of this manual

|                    |   | The manual is divided into 10 main chapters.<br>The subchapters have not been numbered. Clarity<br>and convenience are provided by a maximum of 3<br>structural levels, e.g.   |  |
|--------------------|---|--|--|
|                    |   | 4 Stationing   |  |
|                    |   | Free Stationing  |  |
|                    |   | Adjustment methods   |  |
|                    |   |  |  |
|                    |   | The pages are divided into two columns:  |  |
| Functi             | onal text for:  | Principal text including   |  |
| Station<br>Free st |   | <ul> <li>Descriptions of measuring processes / methods</li> <li>instrument operation and keys</li> <li>Zeiss Elta® CU display graphics</li> <li>drawings and large graphics</li> <li>tips, warnings and technical information</li> </ul> |  |
| Mode               | Softkeys and their functions                            | 🖝 Tip  |  |
| Q                  | Cross-references to other chapters                      | For hints, special aspects and tricks<br><b>Attention!</b>   |  |
| Æ                  | Ranges for values                                       | For risks or potential problems  |  |
|                    | to be entered or<br>pre-set                             | Technical For technical background information   |  |
|                    | '<br>Status symbols in<br>the Zeiss Elta® CU<br>display | For technical background information<br>Measuring tasks are defined by symbols:  |  |
| <b>~</b>           | Keys / Hotkeys  | <ul> <li>➡ : given values</li> <li>⊕ : measured values</li> <li>➡ : required/computed values</li> </ul>  |  |
|                    | Small graphics  | You will find a list of terms and an index in the annex (Geodetic Glossary, Index).  |  |

1-2

#### **Important notes**

## Attention!

Please read the safety notes in chapter 2 carefully before starting up the instrument.

The instrument was manufactured with tested methods and using environmentally compatible quality materials.

The mechanical, optical and electronic functions of the instrument were carefully checked prior to delivery. Should any defects attributable to faulty material or workmanship occur within the warranty period, they will be repaired as a warranty service.

This warranty does not cover defects caused by operator errors or improper handling.

Any further liabilities, e.g. for indirect damages, cannot be accepted.

| Zeiss Elta <sup>®</sup> CU<br><u>User Manual Part1<sup>st</sup></u><br>Program Packages <i>Basic</i> and <i>Expert</i> |  |  |  |
|--|--|--|--|
| 04.06.2001   |  |  |  |
| V1.40  |  |  |  |
| 571 702 031  |  |  |  |
|  |  |  |  |

Subject to change.

# CE

# Introduction



# 🕿 Tip

The type label and serial number are provided on the left-hand side and underside of the instrument respectively. Please note this data and the following information in your user manual. Always indicate this reference in any inquiries addressed to our dealer, agency or service department:

Instrument:

- □ Trimble 5600 Series
- Zeiss Elta<sup>®</sup>Control Unit (Elta CU)

Serial numbers:

If you have any software-related questions, please also state the version of the relevant software package installed in your instrument:

Software version: Package:

|  | Basic    |
|--|----------|
|  | Expert   |
|  | Profess. |
|  | Special  |

Please note your autohorisation code for the software packages::

Basic

Þ

Expert

| rotessional |  |
|-------------|--|

| Special |  |
|---------|--|
|         |  |
|         |  |

Protessional Plus!

We would like to wish you every success in your work with your Zeiss Elta<sup>®</sup> CU. If you need any help, we will be glad to be of assistance.

Yours



Trimble AB P.O. Box 64 S-182 11 Danderyd Phone: +46 8 622 10 00 Telefax: +46 8 753 24 64 E-Mail: info@trimble.se http://www.trimble.com

# Introduction

This chapter gives you an overview of the hardware and software.

It describes the operation and controls of the Elta CU as well as the sensors and peripheries which are a special feature of the Trimble 5600 Series total stations.

# **Control Unit Description**

# Operation

Zeiss Elta CU and Radio

# Safety Notes

## **QWERTY** keyboard



The key assignment and symbols are mostly identical to a normal PC keyboard.

Dual assignments have been implemented in the numeric block (9) and cursor keys (8) and can be activated with the shift key (2).

# Keys and their functions

| Esc  | 1 Escape   |
|------|--|
|      | Quitting program levels  |
|      | <b>2 Shift</b><br>Dual assignment switchover                         |
|      | <b>3 Tabulator</b><br>Selector and tab key                           |
| Ţ    | <b>4 Caps</b> Upper-case and lower-case letters                      |
| Ctrl | 5 Control  |
|      | Control and hotkeys  |
| F10  | <b>6</b> Function keys<br>Softkeys activation (in the display above) |

|     | 7 Space key<br>Space and selector key              |
|-----|--|
| Î   | 8 Cursor keys                                      |
|     | Cursors positioning                                |
| 3   | 9 Numeric block                                    |
|     | Numeric entries and dual assignment                |
|     | 10 Enter key                                       |
|     | Confirmation and triggering of measurement         |
| PWR | <b>11 Power key</b><br>Switching the instrument on |
|     |  |

# Hotkeys

In addition, hotkeys are provided which permit you to directly activate a function at any point in the program. For activation press

Further keys and hotkeys:

**Ctrl** + the appropriate character:

Annex

Symbols and keys

- Ctrl B Battery display
- Ctrl H Help
- Ctrl I Illumination
- Ctrl L Levelling (compensator)
- Ctrl P Tracklight<sup>®</sup> on / off
- Ctrl R Direct Reflex Mode ON / OFF\*
- Ctrl O Laser Pointer ON / OFF\*
- Only active with Trimble 5600 DR200+!

# Additional trigger key

| PWR   | Additional<br>trigger key | The power key can be used as an additional trig-<br>ger.  |
|-------|---------------------------|---|
| Graph | nic display               |   |
|       |                           | The display is a LCD screen with 320 x 80 pixels in the display window. To control the full display area, use |
|       |                           | $[Ctr][Alt] + [\uparrow] ] \longleftrightarrow \longrightarrow$   |
|       |                           | This allows you to see the full virtual screen area e.g. in the MS-DOS $^{\ensuremath{\mathbb{R}}}$ mode.     |
|       |                           | ☞ Tip   |
|       |                           | If the cursor appears in the MS-DOS <sup>®</sup> mode, press  |
|       |                           | <b>Ctrl</b> Alt +<br>To scroll down the display until the cursor will be seen blinking.                       |
|       |                           |   |

**Configuration** Instrument Switches You can switch on the display and the crosshair illumination using either the illumination switch or the hotkey

### Ctrl

Contrast variation is also possible. Therefore select the configuration of the instrument.

Ш

# Attaching/Detaching the Control unit




Attaching/Deattaching the Elta CU to the Trimble 5600 Series total station.

# **Control Unit Description**


#### Software overview





# **Control Unit Description**

#### Modular structure of the system software



The Zeiss Elta<sup>®</sup> CU modular software comprises four packages. Thanks to the full MS-DOS<sup>®</sup> compatibility of the Zeiss Elta<sup>®</sup> CU PC, you can integrate your own software while making allowance for the programming interfaces.

The *Basic* package provides the basis for *Expert*; i.e. *Expert* enhances the functionality.

The *Basic* software is standard in all hardware packages and offers the following functions:

- Project management
- Adjustment
- Measurement in a local system
- Editor
- Data transfer
- Configuration

The software with the basic functions for surveying in coordinates.

- Stationing
  - Free Stationing
  - Stationing on a known point
  - Eccentric Stationing
  - Heightstationing
- Coordinates
  - Detail Points
  - Setting Out
- Special
  - Point-to-line distance

Expert

Basic

# **Control Unit Description**

| Professional       | Professional surveying with  |  |
|--------------------|--|--|
|                    | Coordinates  |  |
|                    | - Traverse<br>- Transformation<br>- Intersection of Lines<br>- Intersection of Arcs  |  |
|                    | • Special  |  |
|                    | - Area calculation<br>- Connecting distances   |  |
| Professional Plus! | The Plus! Package in Detail Points program, which<br>allows making Verification Points by either point<br>number or position. It's a great tool for control-<br>ling the quality of surveys. |  |
| Special            | For special tasks in surveying such as   |  |
|                    | Coordinates  |  |
|                    | - RoadLine Lite  |  |
|                    | • Special  |  |
|                    | - Multiple Rounds<br>- 3D Plane  |  |

# Switching the instrument on and off

|                             |   | Switching the instrument on  |
|-----------------------------|---|--|
|                             | ect<br>/stemsw.<br>mble 5600"                                 | Press the PWR key and the start menu is<br>displayed unless any other application in the start<br>menu is configured and activated.  |
| -Display                    | Search for<br>active<br>COM-Port3                             | Auto Detect<br>Running auto detect on COM3<br>Press ESC to terminate auto detect<br>Press ENT to search on next COM-port   |
| -Display                    | Instrument<br>found at<br>COM-Port3                           | Auto Detect<br>Instrument found on COM1<br>Press ESC to terminate auto detect<br>Press ENT to search on next COM-port  |
| -Display                    | Instrument<br>connected<br>at COM3                            | Auto Detect<br>Instrument connected on COM1<br>Press ESC to terminate auto detect<br>Press ENT to search on next COM-port  |
| - Instrumen<br>- Serial no. | tartup logo with<br>It type<br>Zeiss Elta® CU<br>release data | Trimble System 5600         69010006           Version         1.40           Date         Feb 14 2001           Time         11:20:14           (c) ZSP Geodät.Systeme GmbH         1997 - 2001 |

Switching the instrument on

|     | <b>Configuration</b><br>Instrument  | The instrument configuration permits you to define which functions should be executed after the PC is booted or which menu the program should directly access. |
|-----|---|--|
|     |   | If no PCMCIA card was inserted, the following message appears:   |
|     |   | The PCMCIA drive is the expected drive starting the Elta <sup>®</sup> CU.  |
| Rej | Deat Insert the<br>PCMCIA<br>card and<br>get access<br>to the<br>PCMCIA<br>drive A:\          | Main Menu<br>Drive not ready<br>REPEAT - again with A:<br>IGNORE - change to D:<br>Repeat<br>Ignore  |
| Ign | ore Data<br>storing on<br>the internal<br>drive<br>D:\DATEN<br>of the<br>Elta <sup>®</sup> CU |  |

|  | sation compensator<br>neck levelling | 251 Tilt Compensation         Status :         Initialisation necessary         Compensator initialisation         Check Levelling         2 |
|--|--------------------------------------|--|
|  | Adjustment of compensator.           | 251 Tilt Compensation         Status :         Initialisation necessary         Compensator initialisation         Check Levelling         2 |
| Display<br>- Adjustment of<br>compensator is running |                                      | Adjust Compensator   |
| Display<br>-Comp                                     | ensator adjusted                     | 251 Tilt Compensation         Status :         o.k.         Bompensator initialisation         Check Levelling         2                     |

2 or




"Check Levelling"

| 251 Tilt Compensation                         |        |
|---|--------|
| Status :                                      |        |
| o.k.  |        |
| Compensator initialisation<br>Check Levelling | 1<br>2 |
|   |        |

Display

instrument is levelled



## Display

- Main menu of the Elta<sup>®</sup> CU software
- The project last processed is loaded.

Main MenuSWMENUEProje Management 1Special6Adjustment2Editor7Measure3Data Transfer8Stationing4Configuration9Coordinates5Remote Control0

If there is no project stored on the actual drive, a project "NONAME" will be automatically opened.

#### Display - The project "NONAME" is loaded. Main Menu Proj. Management 1 Special 6 Adjustment 2 Editor 7 Measure 3 Data Transfer 8 Stationing 4 Configuration 9 Coordinates 5 Remote Control 0

Zeiss Elta Control Unit V1.01




Configure Start menu select "Sytemsw. Trimble 5600"



Display

- "X" marks application for Auto Start.






#### Hard- and Software Scan

Starting the program checks automatically for all necessary Hard- and Software Components are rightly installed and set. If not, a message appears:

E.g.: Missing configuration data. Default values will be set.

#### Switching the instrument off

**Esc** in the main menu to quit the program after answering the inquiry:



#### 🕿 Tip

To get back to the application enter **START** from the MS-DOS<sup>®</sup> prompt D:>.

#### Servo Controls


The servo is manually controlled by the two motion knobs for Hz and V located at the side of the instrument.

Motorized coarse drive

The motion knobs are sensitive in four steps so that the more you turn the knob the faster the servo will rotate the instrument.

Motorised slow-motion drive

If you want to switch to fine mode adjustment when operating a motion knob, turn the knob in the opposite direction and fine adjust.



Manual motion

Although the servos are always active the instrument can turned manually. Therefore touch the body of the instrument or the telescope anywhere and just turn it.

Friction clamp

In turned on state, with the motors active a friction system assumes clamp function in Hz and V.

# Autolock<sup>™</sup>(only for servo instruments)

| - <del> </del> |   | The AutoLock <sup>™</sup> functionality is based on the<br>Tracker unit in combination with the RMT<br>(Remote Target). This enables the instrument<br>automatically to lock on to the center of the RMT<br>and to automatically follow it as it moves. |
|----------------|---|---|
| Ĥ              | Measure in a local<br>System                                  | The following AutoLock <sup>™</sup> Switches are possible<br>for each measurement in all application programs<br>using the softkey <b>Srch</b> (F9):  |
| Srch           | Off   | AutoLock™ OFF.  |
|                | On  | AutoLock™ ON: Target search and automatic target aim.   |
|                | Tracking  | AutoLock <sup>™</sup> Tracking: Instrument is following the RMT while it is moving.   |
|                |   | AutoLock™ tracking is optimized for fast and efficient operation.   |
| Ш<br>Д         | Configuration<br>Instrument / Prism<br>Sensors /<br>AutoLock™ | If you pass the prism behind an object the instru-<br>ment will loose the target. Now the TrackLight <sup>®</sup><br>will be switched on, is flashing slow (this helps<br>realignment with the Tracker) and the<br>tracking lost symbol will flash.     |
|                |   | If you are stationary and an alstant parameter function   |

If you are stationary and an object passes in front of the prism, then the total station will remain stationary until the prism is reacquired.

## Tracker (only for servo instruments)



Trimble 5600 series can be equipped with a Tracker unit, which is needed when using the system for robotic surveying or when performing conventional surveying with Autolock<sup>™</sup>. The Tracker has control over the instrument's servos and aims the instrument correctly towards the target, which in these cases must be an RMT

The RMT is sent out a signal, and when captured from the Tracker the instrument is orientated in vertical and horizontal axis to the target.

## **Calling Tracker operation**

Calling the instrument search is available in all measure programs via the **Srch** softkey and is activated with Softkey **Find**. This method is identical on both the operations at the instrument and the RCU.

The Tracker can operate in different search modes. Setting and activating the modes press the Softkeys Cent and Win

Srch Find

#### All measure programs

Srch

## **Tracker Range**

⊯ Tracker < 1000m

The maximum range of Tracker is an circular area around the station of about  $< 3\ 000\ 000\ m^2$ 

#### **Tracker and Prism Tracking**

Using the Tracker in combination with AutoLock<sup>™</sup>-Tracking provides the user with a very comfortable one-man operation. If the prism is lost during Prism Tracking, using the comfortable search

functionality will quickly allow the instrument to snap back onto the prism, ready for further tracking.

#### **TrackLight**<sup>®</sup>

| TrackLight <sup>®</sup> is the optical aid for aligning the prism |
|---|
| in setting out, which enables the staffman to                     |
| position the prism on the correct bearing. It is                  |
| standard equipment for all the Trimble 5600 in-                   |
| struments with Tracker. TrackLight <sup>®</sup> helps to find     |
| the setting out position by optical                               |
| illumination signals.   |

Seen the TrackLight from the prism pole means:

green flashing: left from the point

red flashing: right from the point


If the setting out direction (da=0) is reached, the green light and the red light are merging.

If the setting out direction (da=0) is reached, it means the RMT is in the sight line of the instrument, the TrackLight<sup>®</sup> goes off.

The TrackLight<sup>®</sup> is white flashing with the doubled frequency when only the prism is to be seen.

In the left figure the setting out positions 1-4 will be shown on the prism pole as follows:

- 1 green light
- 2 red light
- 3 in sight line in front of the point, no light
- 4 in sight line behind the point, no light
- P set out point plus prism, no light



#### Basics

This chapter will describe the different ways of working with Trimble 5600 series. First of all you can work conventionally with the system. Since the instrument is equipped with servo drive, you'll find that the system is very easy to handle, when setting out you can with a touch of a single key aim the instrument towards the set out point.

#### Conventional surveying with servo

If your instrument is equipped with servo drive, this means a lot of advantages: In e.g. setting out you only need to give the point number. The instrument will calculate and aim automatically towards the pre-calculated direction.

During manual aiming, the servo assists the horizontal and vertical adjustments. All that's needed is a light circular movement of the adjustment screw with your fingertip.

Thanks to servo-drive, adjustment screws have no end positions. That means no unnecessary interruptions, when aiming.

# Autolock<sup>™</sup> (only servo)




Secondly you can equip your instrument with a tracker unit and take full advantage of the feature we call Autolock<sup>™</sup>, this enables the instrument to lock on to a RMT and automatically follow it as it moves. This means that there is no need for fine adjustment or focusing.

## Remote Surveying



With an instrument, a telemetric link and an ordinary prism you can work with remote surveying which enables you to have the control over the measured data from the point.

## Robotic Surveying (only servo)



With a tracker unit and a telemetric link plus an RMT you can work with robotic surveying. This means that you can take over the control of the whole measurement from the point, i.e. you have a one-person system. On the following pages we will describe the different measuring techniques with Trimble 5600 series.

# Conventional surveying with Autolock™ (only servo)

With the feature Autolock  $^{\rm TM}$ , you do no longer have to fine adjust or focus, since this is taken care of by the system.

- To upgrade a base unit to Autolock<sup>™</sup>, you'll only need to add a Tracker unit and a RMT target. It is also possible to measure in a conventional way without Autolock<sup>™</sup> using an ordinary reflector.
- When setting out, you'll only need to supply a pre-stored point and the system will calculate the necessary data for setting out. Then, position the instrument with the positioning key. When the staffman, guided by the builtin (2.5m/100m), the instrument locks onto the RMT automatically. You're now able to fully concentrate on the information in the display (radial/right angle offset) and direct the

staffman to the setting out point.

## Important information when measuring with high accuracy (and using the instrument's Tracker)

To achieve the highest accuracy when measuring distances shorter than 200 meters and using the Tracker unit you need to be aware of the following:

Always use the Miniature Prism (Part no. 571 126 060) mounted on your RMT. If you use a large reflector like the Super Prism (Part no. 571 125 021), reflections from the Tracker unit may have influence on the measured distance. The error can vary from 0 to 3 mm. This error doesn't occur using the Miniature Prism.

### How to work with Autolock<sup>™</sup>


First switch on your instrument activate compensator, check levelling and set all the required parameters like PPM-factor etc.

|   | Main Menu   | NONAME   |
|---|---|----------|
| <b>3 4 5 6</b><br>Select any application, e.g.<br>measure | Proj. Management 1<br>AdjustmentSpecial<br>EditorAdjustment2<br>EditorMasure3<br>StationingStationing4<br>CoordinatesCoordinates5   | ation 9  |
| Srch Select AutoLock™                                     | 3 Measure           s         1.000000         BD         m           in         0.000 m         Hz         45.5341 son           th         0.000 m         V1         97.8452 son             PNr>           Model Rec         10++f         R=N         Ecc.         Hid2         Inpt | Adr: 3   |
| Display<br>– menu AutoLock™                               | AutoLock : [  | ff       |
|   | Find  | Win SwtP |
| Activate AutoLock <sup>™</sup>                            | Press spacebar to activate AutoLock   | ς™.      |
| Display   | AutoLock  |          |
| - Autolock <sup>™</sup> activated                         | AutoLock : 🛾  | n        |
|   | Find Cent   | Win SwtP |



Confirm setting

Display -AutoLock<sup>™</sup> active, Status symbol -------G shown Jump back to selected application



The instrument is now set-up for Autolock<sup>TM</sup>. A search function can be added as an option. With this option both sector control and search control can be used. For more information, follow this chapter.

### Measuring towards an ordinary prism

If you aim towards an ordinary prism with the Autolock  $^{\rm \tiny M}$  option on and press the

Enter key, you will be prompted:


| Error AutoLock            |  |
|---------------------------|--|
| Target not found          |  |
| Press any key to continue |  |

Now please switch off Autolock  $^{\mathsf{TM}}$  and start measurement again!


### <u>Aiming</u>

The adjustment between the two optical axes, i.e. the Telescope and the Tracker, may differ. The difference will make it seem like the instrument does not point towards the centre of the prism, when using Autolock<sup>™</sup> (see fig. below). This is not a problem since the two axes have their own collimation data. It is however important to make collimation test for both axis.

Without Autolock<sup>™</sup>.



Manual aiming



With Autolock™

### How to check

You can check how good the instrument is calibrated yourself, by measuring towards the same prism with and without Autolock<sup>TM</sup> and compare the displayed angles:

| Without Autolock <sup>™</sup> : | The instrument shows the angles for the tube.    |
|---------------------------------|--|
| With Autolock™:                 | The instrument shows the angles for the tracker. |

If the angle deviations are large you should calibrate both the tube (Menu 2 Standard Adjustment and Tracker Unit Adjustment), see chapter 8.

### **Remote surveying**

Remote surveying means the instrument operator's job is to aim the instrument toward the reflector. The most experienced member of the survey crew is out at the measuring point taking care of the qualified work of checking, coding, registering etc.

Remote surveying gives you the ability to access the information where it's most needed. Because it's out at the measuring point itself you most often discover how to achieve the best results.

## Important information when measuring with high accuracy

To achieve the highest accuracy when measuring distances shorter than 200 meters and having the Tracker unit installed on your instrument you need to be aware of the following:

If you use a large reflector like the Super Prism (Part no. 571 125 021) or the Tiltable Reflector (Part No. 571 126 110) you need to cover the tracker aperture before you measure the distance. Otherwise reflections from the Tracker unit may have influence on the measured distance. The error can vary from 0 to 3 mm. If you use a Miniature Prism (Part no. 571 126 060 or 571 126 100) this error doesn't occur.

#### Equipment:


To be able to work with remote surveying you'll need a control unit at the point. You will also need to equip your instrument with a radio side cover (see chapter 1.1) and to connect an external radio to the Elta<sup>®</sup> CU. The control unit, the prism and the external radio will hereafter be called RPU.

#### Radio communication:

In order for the instrument and the RPU to be able to communicate you will have to set the same radio channel at the instrument and at the RPU. Select a channel with regard to other radio systems that might be in operation in your immediate area. If radio disturbances occur, e.g. if Info 103 is displayed, try another channel.

#### How to work with remote surveying

First switch on your instrument activate compensator, check levelling and set all the required parameters like PPM-factor etc.






Define Search Window Activate Autom. Center

Display

| - | Define | Search | Window |
|---|--------|--------|--------|
|---|--------|--------|--------|

| Channe l        | 1 |  |
|-----------------|---|--|
| Station address | 1 |  |
| Remote address  | 1 |  |

| Define Search Wind  | low                     |
|---------------------|-------------------------|
| Search window       | Off                     |
| Autom. Center       | Off                     |
| Point A (left, top) | Point B (right, bottom) |
| Hz 34.4423 gon      | Hz 45.0762 gon          |
| V1 88.4558 gon      | V1 100.2535 gon         |
| SetA                | SetB                    |



For setting a Search Window select one of two variants.


#### Variant A:

Turn the instrument and the telescope one after another.

| SetA                               | left corner | Define Search Window                                    |  |  |
|------------------------------------|-------------|---|--|--|
|                                    |             | Search window<br>Autom. Center                          | Off<br>Off   |  |
| SetB                               |             | Point A (left, top)<br>Hz 34.4423 son<br>V1 88.4558 son | Point B (right, bottom)<br>Hz 45.0762 gon<br>V1 100.2535 gon |  |
| Aim to lower/upper<br>right corner | SetA        | SetB  |  |  |
|                                    |             | Define Search Winds                                     |  |  |

Activate Search Window

| Define Search Winde               | DW   |
|-----------------------------------|--|
| Search window<br>Autom. Center    | On<br>Off  |
| Point A (left, top)<br>Hz 34.4423 | Point B (risht, bottom)<br>Hz 45.0762 son<br>V1 100.2535 son |
| SetA                              | SetB   |



 Imemote Control

 Channel
 1

 Station address
 1

 Remote address
 1

 Cent
 Win
 CONN

menu

Remote Control

from instrument

| Cent              | Turn instrument<br>to new<br>Window Centre<br>and<br>Set<br>new direction | Remote Control         Channel       1         Station address       1         Remote address       1         Cent       Win       CONN |
|-------------------|---|---|
| Conn              | Activate RCU mode   | Remote ControlChannel1Station address1Remote address1CentWinCONN  |
| Display<br>-Prepa | ration RCU mode   | Preparing for robotic mode,<br>please wait  |
| Display<br>Press  | any key to turn off   | System is now ready for robotic.<br>Press any key to turn off system.<br>Remove control unit from instrument<br>and connect to radio.   |
| Detach            | Elta <sup>®</sup> CU  | Instrument prepared for Remote Control Mode   |

PWR

Power On

### Activation of the RPU

Attach the Elta<sup>®</sup> CU at the prism pole holder. Connect Elta<sup>®</sup> CU with radio via serial cable when using control unit holder (Artikel-Nr. 571 224 030).

Switch on Elta<sup>®</sup> CU.

| - | Select<br>"Systems.<br>Trimble 5600" | Zeiss Elta Control Unit V1.01<br>OFF<br>Systemsw. Trimble 5600<br>Systemsoftware Trimble 5600 |
|---|--------------------------------------|---|
|   |                                      |   |

| Display | splav Search for    | Auto Detect   |
|---------|---------------------|---|
|         | active<br>COM-Port? | Running auto detect on COM3<br>Press ESC to terminate auto detect<br>Press ENT to search on next COM-port |

| -Display Instrument | Auto Detect           |  |
|---------------------|-----------------------|--|
|                     | found at<br>COM-Port1 | Instrument found on COM1<br>Press ESC to terminate auto detect<br>Press ENT to search on next COM-port |

| -Display | Elta <sup>®</sup> CU | Auto Detect  |
|----------|----------------------|--|
|          | connected<br>at COM1 | Instrument connected on COM1<br>Press ESC to terminate auto detect<br>Press ENT to search on next COM-port |

### 🕿 Tip :

Depending on used holder the Elta<sup>®</sup> CU can be connected with radio via COM1/3/4!

| Display<br>Initialisation Compensator<br>-Check Levelling |                                | 251 Tilt Compensation<br>Status :<br>Initialisation necessary<br>Compensator initialisation<br>Check Levelling | 1<br>2              |
|---|--------------------------------|--|---------------------|
| Ţ   | Adjustment of compensator.     | 251 Tilt Compensation<br>Status :<br>Initialisation necessary<br>Compensator initialisation<br>Check Levelling | 1.<br>2             |
|   | tment of<br>ensator is running | Adjust Compensator<br>Please Wait  |                     |
| Display<br>-Comp  | ensator adjusted               | 251 Tilt Compensation<br>Status :<br>o.k.<br>Compensator initialisation<br>Check Levelling                     | 1                   |
| 2<br>, Check  | or<br>Levelling"               | 251 Tilt Compensation<br>Status :<br>o.k.<br>Compensator initialisation<br>Check Levelling                     | 1<br>2              |
| Display<br>– Instru                                       | ment is levelled               | Levelling<br>0.0025<br>(    •••••   )<br>Trunnion  | -0.0028<br>Sighting |
|   |                                | Main Menu  | NONAME              |

|  | Aim, Measure, Register  |
|--|---|
| PWR Power On                                       | Switch on Elta <sup>®</sup> CU, activate compensator, check levelling and set all the required parameters like PPM-factor etc.  |
|  | Main Menu NONAME  |
| 3 4 5 6<br>Select any application, e.g.<br>measure | Proj. Management 1Special6Adjustment2Editor7Measure3Data Transfer8Stationing4Configuration9Coordinates5Remote Control0  |
|  |   |
| Srch Select AutoLock™                              | 3 Measure         Adr: 3           \$ 1.000000         \$ 50         \$ m           ih         0.000 m         \$ Hz         45.5341 son           th         0.000 m         \$ 97.8452 son         \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ |
|  | <>Nr> <info>    └┘<br/>Mode Rec Ioff R-M [Ecc. HidP Inpt Code Srch →2</info>  |
| Display<br>– menu AutoLock™                        | AutoLock : Off  |
|  | Find Win SwtP   |
|  |   |
| Activate AutoLock™                                 | Press spacebar to activate AutoLock™.   |
| Display  | AutoLock  |
| - Autolock™ activated                              | AutoLock : Un   |

Find

Cent

Т 

Win SwtP

| Find Search RMT                  | AutoLock  |             |
|----------------------------------|---|-------------|
| Search Min                       | AutoLock : 🖸  |             |
|                                  |   | Win SwtP    |
| Display                          | Tracker   |             |
| - Instrument searches RMT        | Searching target<br>Press (Esc) to abort !  |             |
| Display<br>-Instrument found RMT | 3 Measure         \$ 1.000000         ih       0.000 m         Hz       208.1576 son         Hz       208.1576 son         V1       107.7950 son         PNr>         Mode       Rec       Ion       R-M         Ecc.       HidP       Inpt | Adr:     20 |
|                                  |   |             |

Enter PI, aim, measure and record

| ЗМ            | leasure                        |                |                              |     | Adr: | 21 |
|---------------|--------------------------------|----------------|------------------------------|-----|------|----|
| s<br>ih<br>th | 1.000000<br>0.000 m<br>0.000 m | SD<br>Hz<br>V1 | 6.204<br>19.6917<br>100.0390 | gon | すか   | Ļ  |
|               |                                |                |                              |     |      |    |

൙ Tip:

After recording the memory address is incremented by one.

### **Robotic Surveying (only servo)**

By equipping the instrument with a tracker unit, even aiming can be done from the measuring point. The entire measurement is performed from the point, with the same access to all functions of the total station as if you were standing beside it.

Robotic surveying means higher production capacity. During setting-out, it's best with two people: one to handle the measuring with the RPU, and one to mark the points. Of course, one person can perform the entire job.

The unique search function makes robotic surveying extremely efficient 24 hours a day.

## Important information when measuring with high accuracy

Important information when measuring with high accuracy (and using the instrument's Tracker):

To achieve the highest accuracy when measuring distances shorter than 200 meters and using the Tracker unit you need to be aware of the following:

If you use a large reflector like the Super Prism (Part no. 571 125 021) on your RMT, reflections from the Tracker unit may have influence on the measured distance. The error can vary from 0 to 3 mm. If you use the Miniature Prism (Part no. 571 126 060) instead this error doesn't occur.

### Equipment:

To be able to work with robotic surveying you'll only need one control unit, which you after station establishment etc. disconnect from the instrument and bring to the point. You will also need to equip your instrument with a radio side cover a tracker unit, a RMT (Remote Target) and an external radio connected to the Elta<sup>®</sup> CU. The Elta<sup>®</sup> CU, the RMT and the external radio will hereafter be called RPU.

### Radio communication:

In order for the instrument and the RPU to be able to communicate you will have to set the same radio channel at the instrument and at the RPU. Select a channel with regards to other radio systems that might be in operation in your immediate area. If radio disturbances occur, e.g. if Info 103 is displayed, try another channel.

| PWR      | Power On   | Switch on Elta <sup>®</sup> CU, activ<br>levelling and set all the re<br>PPM-factor etc.      |   |
|----------|--|---|---|
| 0        | Activate<br>Remote Control                                       | Main Menu<br>Proj. Management 1<br>Adjustment 2<br>Measure 3<br>Stationing 4<br>Coordinates 5 | NONAME<br>Special 6<br>Editor 7<br>Data Transfer 8<br>Configuration 9<br>Remote Control 0 |
| <b>(</b> | Select<br>(Radio) Channel,<br>Station address,<br>Remote address | Remote Control<br>Channel<br>Station address<br>Remote address<br>Cent                        | 1<br>1<br>1<br>Win CONN   |
|          | Toggle<br>Channel, addresses                                     | Main MenuProj. Management 1Adjustment 2Measure 3Stationing 4Coordinates 5                     | NONAME<br>Special 6<br>Editor 7<br>Data Transfer 8<br>Configuration 9<br>Remote Control 0 |
| Win      | Define<br>Search Window<br>Activate<br>Autom. Center             | Remote Control<br>Channel<br>Station address<br>Remote address<br>Cent                        | 1<br>1<br>1<br>Win CONN   |


How to work with robotic surveying

Õ

Display

– Define Search Window

| Define Search Window |                         |  |
|----------------------|-------------------------|--|
| Search window        | Off                     |  |
| Autom. Center        | Off                     |  |
| Point A (left, top)  | Point B (right, bottom) |  |
| Hz 34.4423 gon       | Hz 45.0762 gon          |  |
| V1 88.4558 gon       | V1 100.2535 gon         |  |
| SetA                 | SetB                    |  |



(right, bottom) type Hz/V-angle

Point B

For setting a Search Window select one of two variants.

### Variant A:

Turn the instrument and the telescope one after another.


| SetA     | Aim to upper/lower | Define Search Windo                                      | off  |
|----------|--------------------|--|--|
|          | left corner        | Autom. Center<br>Point A (Left, top)                     | Off<br>Point B (right, bottom)                               |
| SetB     | Aim to lower/upper | Hz 34.4423 gon<br>V1 88.4558 gon                         | Hz 45.0762 son<br>V1 100.2535 son                            |
|          | right corner       | SetA   | SetB   |
|          |                    | Define Search Windo                                      | w  |
|          | Activate           | Search window<br>Autom. Center                           | On<br>Off  |
|          | Search Window      | Point A (left, top)<br>Hz 34.4423 9on<br>V1 88.4558 9on  | Point B (right, bottom)<br>Hz 45.0762 gon<br>V1 100.2535 son |
|          |                    | SetA   | SetB   |
|          |                    |  |  |
|          |                    | Remote Control   |  |
|          | Jump back to       | Channe l   | 1  |
|          | menu               | Station address<br>Remote address                        | 1  |
|          |                    | nemote auuress   | 1  |
|          | Remote Control     | Cen  | t Win CONN   |
|          |                    |  |  |
|          |                    | Variant B:   |  |
|          |                    |  |  |
| <b>,</b> | +                  | Define Search Windo                                      |  |
|          | Select             | Search window  | Off  |
|          | Point A            | Autom. Center  | Off  |
|          | (left,top)         | Point A (left, top)<br>Hz 50.0000 son<br>V1 101.0000 son | Point B (risht, bottom)<br>Hz 55.0000 son<br>V1 99.00000 son |
|          | type Hz/V-angle;   | SetA   | SetB   |
|          | type nz/v-angle,   |  |  |

|         |                      | Define Search Windo                                      | ω   |
|---------|----------------------|--|---|
|         | Activate             | Search window<br>Autom. Center                           | On<br>Off   |
|         | Search Window        | Point A (left, top)<br>Hz 50.0000 gon<br>V1 101.0000 gon | Point B (right, bottom)<br>Hz 55.0000 gon<br>V1 99.0000 gon |
|         |                      | SetA   | SetB  |
|         |                      |  |   |
|         |                      | Define Search Windo                                      | ω   |
|         |                      | Search window<br>Autom. Center                           | On<br>On  |
|         | Select               | Point A (left, top)<br>Hz 50.0000 gon                    | Point B (right, bottom)<br>Hz 55.0000 gon                   |
|         | Autom. Center        | V1 101.0000 son<br>SetA                                  | V1 99.0000 son  |
|         | Activate             |  |   |
|         | Autom. Center        |  |   |
|         | human haale ta       | Remote Control   | 1   |
|         | Jump back to<br>menu | Station address<br>Remote address                        | 1   |
|         | Remote Control       | nemote address   | 1   |
|         |                      | Cent   | Win CONN  |
|         |                      |  |   |
| Cent    | Turn instrument      | Remote Control   |   |
|         | to new               | Channel<br>Station address                               | 1   |
|         | Window Centre        | Remote address   | ĩ   |
|         | and                  | Cent   | Win CONN  |
|         | Set                  |  |   |
|         | new direction        |  |   |
|         |                      |  |   |
| Conn    | Activate RCU mode    | Remote Control   |   |
|         |                      | Channel<br>Station address                               | 1<br>1  |
|         |                      | Remote address   | 1   |
|         |                      | Cent   | Win CONN  |
|         |                      |  |   |
| Display |                      |  |   |
|         | ration RCU mode      | Preparing for rob  | otic mode.  |
|         |                      | please wait  |   |
|         |                      |  |   |
|         |                      |  |   |

| Display<br>Press any key to turn off                     | System is now ready for robotic.<br>Press any key to turn off system.<br>Remove control unit from instrument<br>and connect to radio. |
|--|---|
| Detach Elta <sup>®</sup> CU<br>from instrument           | Instrument prepared for Remote Control Mode<br><u>Search Window</u>   |
| Win Define<br>Search Window<br>Activate<br>Autom. Centre | Remote ControlChannelStation addressStation addressRemote address1CentCent  |
| Display  | Define Search Window  |

Display – Define Search Window

| Define Search Window |                         |  |  |
|----------------------|-------------------------|--|--|
| Search window        | Off                     |  |  |
| Autom. Center        | Off                     |  |  |
| Point A (left, top)  | Point B (right, bottom) |  |  |
| Hz 34.4423 9on       | Hz 45.0762 gon          |  |  |
| V1 88.4558 9on       | V1 100.2535 gon         |  |  |
| SetA                 | SetB                    |  |  |



For setting a Search Window select one of two variants.

### Variant A:

Turn the instrument and the telescope one after another.

| SetA | Aim to uppor/lower                | Define Search Window   |
|------|-----------------------------------|--|
|      | Aim to upper/lower<br>left corner | Search window Off<br>Autom. Center Off   |
| SetB |                                   | Point A (left, top)         Point B (risht, bottom)           Hz         34.4423 son         Hz         45.0762 son           V1         88.4558 son         V1         100.2535 son         |
|      | Aim to lower/upper                | SetA   |
|      | right corner                      |  |
|      |                                   | Define Search Window   |
|      | Activate                          | Search window On<br>Autom. Center Off  |
|      | Search Window                     | Point A (left, top)         Point B (right, bottom)           Hz         34.4423 son         Hz         45.0762 son           V1         88.4558 son         V1         100.2333         son |
|      |                                   | SetA SetB  |
|      |                                   | Remote Control   |
|      | Jump back to                      | Channel 1<br>Station address 1   |
|      | menu                              | Remote address 1   |
|      | Remote Control                    | Cent Win CONN  |
|      |                                   | <u>Variant B:</u>  |
|      | $\downarrow$                      | Define Secure Hinder   |
| -    | Select                            | Define Search Window Off   |
|      | Point A                           | Auton. Center         Off           Point A (left, top)         Point B (right, bottom)  |
|      | (left,top)                        | Hz 50.0000 son Hz 55.0000 son V1 101.0000 son V1   |
|      | type Hz/V-angle;                  | SetA SetB  |
|      | Point B                           |  |
|      | (right, bottom)                   |  |
|      | type Hz/V-angle                   |  |
|      |                                   |  |
|      |                                   | Define Search Window   |
|      | Activate                          | Search window On<br>Autom. Center Off  |

Search Window

| Define Search Window                                     |   |  |  |  |
|--|---|--|--|--|
| Search window On<br>Autom. Center Off                    |   |  |  |  |
| Point A (left, top)<br>Hz 50.0000 gon<br>V1 101.0000 gon | Point B (right, bottom)<br>Hz 55.0000 gon<br>V1 99.0000 gon |  |  |  |
| SetA   | SetB  |  |  |  |

|                   |   | Define Search Windo   | ω   |
|-------------------|---|---|---|
| <b>,</b>          |   | Search window<br>Autom. Center  | On<br>On  |
|                   | Select<br>Autom. Center<br>Activate<br>Autom. Center                      | Point A (Left, top)<br>Hz 50.0000 son<br>V1 101.0000 son<br>SetA<br>Remote Control      | Point B (risht, bottom)<br>Hz 55.0000 son<br>V1 99.0000 son |
|                   | Jump back to<br>menu<br>Remote Control                                    | Channel<br>Station address<br>Remote address  | 1<br>1<br>1<br>Win CONN                                     |
| Cent              | Turn instrument<br>to new<br>Window Centre<br>and<br>Set<br>new direction | Remote Control<br>Channel<br>Station address<br>Remote address                          | 1<br>1<br>1<br>Win CONN                                     |
| Conn              | Activate RCU mode   | Activation of the RCU<br>Remote Control<br>Channel<br>Station address<br>Remote address | L<br>1<br>1<br>Win CONN                                     |
| Display<br>-Prepa | ration RCU mode   | Preparing for robo<br>please wait   | otic mode,  |

Display .-Press any key to turn off

System is now ready for robotic. Press any key to turn off system. Remove control unit from instrument and connect to radio.

Detach Elta<sup>®</sup> CU from instrument

Instrument prepared for Remote Control Mode

|         |                                      | <u>Aim, Measure, Registe</u>  | <u>r</u>  |
|---------|--------------------------------------|---|---|
| PWR     | Power On                             | Switch on Elta <sup>®</sup> CU, acti<br>levelling and set all the r<br>PPM-factor etc.  | vate compensator, check<br>equired parameters like                              |
|         |                                      | Main Menu   | NONAME  |
|         | 4 5 6<br>any application, e.g.<br>re | Proj. Management 1<br>Adjustment 2<br><u>Measure 5</u><br>Stationing 4<br>Coordinates 5 | Special 6<br>Editor 7<br>Data Transfer 8<br>Configuration 9<br>Remote Control 0 |
|         |                                      |   |   |
| Srch    | Select AutoLock™                     | 3 Measure   | Adr: 3  |
|         |                                      | s 1.0000000 SD<br>ih 0.000 m Hz<br>th 0.000 m V1  | 45.5341 son   |
|         |                                      | PNr> <i< td=""><td>====ja ⊿  </td></i<>   | ====ja ⊿  |
| Diaular |                                      | Mode Rec Ioff R-M Ecc.<br>AutoLock  | HidP Inpt Code Srch →2  |
| Display | ⁄<br>u AutoLock™                     | AutoLock  | : Off   |
| – ment  | AUTOLOCK                             | Find Cent   | Win SwtP  |
|         | Activate AutoLock™                   | Press spacebar to activat   | te AutoLock™.   |
| Display | 1                                    | AutoLock  |   |
|         | ock™ activated                       | AutoLock  | : On  |
|         |                                      | Find Cent   | Win SwtP  |
|         |                                      |   |   |

| Find Search RMT                      |   | n<br>Win SwtP |
|--------------------------------------|---|---------------|
| Display<br>- Instrument searches RMT | Tracker<br>Searching target<br>Press (Esc) to abort !   |               |
| Display<br>Instrument found RMT      | 3 Measure<br>5 1.000000 m<br>ih 0.000 m<br>th 0.000 m<br>V1 107.7750 son<br>V1 107. |               |

Enter PI, aim, measure and record

| 3 Measure     |                         |      |                |                              | Adr: | 21        |    |
|---------------|-------------------------|------|----------------|------------------------------|------|-----------|----|
| s<br>ih<br>th | 1.00000<br>0.00<br>0.00 | 00 m | SD<br>Hz<br>V1 | 6.204<br>19.6917<br>100.0390 | 90n  | ナタ        | ļ  |
| 1000          |                         |      |                |                              |      |           |    |
| Mode          | e Rec                   | Ion  | R-M            | Ecc. HidP I                  | npt  | Code Srch | +2 |

൙ Tip:

After recording the memory address is incremented by one.


|         |                              |                                     | Establishing contact from a detached<br>control unit (Activation of the RPU)  |  |  |
|---------|------------------------------|-------------------------------------|---|--|--|
|         |                              |                                     | Attach the Elta <sup>®</sup> CU at the prism pole holder.<br>Connect Elta <sup>®</sup> CU with radio via serial cable when<br>using control unit holder (Artikel-Nr. 571 224<br>030). |  |  |
| PWR     | Power                        | On                                  | Switch on Elta <sup>®</sup> CU.   |  |  |
|         | Select<br>"Syster<br>Trimble | nsw.<br>e 5600"                     | Zeiss Elta Control Unit V1.01<br>OFF<br>Systemsw. Trimble 5600<br>DOS<br>Systemsoftware Trimble 5600  |  |  |
| Displa  | У                            | Search for<br>active<br>COM-Port?   | Auto Detect<br>Running auto detect on COM3<br>Press ESC to terminate auto detect<br>Press ENT to search on next COM-port  |  |  |
| -Displa | ау                           | Instrument<br>found at<br>COM-Port1 | Auto Detect<br>Instrument found on COM1<br>Press ESC to terminate auto detect<br>Press ENT to search on next COM-port   |  |  |

| -Display   | Elta <sup>®</sup> CU | Auto Detect   |  |  |
|--|----------------------|---|--|--|
| . ,  | connected            | Instrument connected on COM1  |  |  |
|  | at COM1              | Press ESC to terminate auto detect<br>Press ENT to search on next COM-port                  |  |  |
|  | ·                    |   |  |  |
|  |                      | ☞ Tip :   |  |  |
|  |                      | Depending on used holder Elta <sup>®</sup> CU can be connected with radio via COM1 or COM3! |  |  |
|  |                      |   |  |  |
|  | ation Compensator    | 251 Tilt Compensation<br>Status :<br>Initialisation necessary                               |  |  |
| -Check I   | evelling             | Compensator initialisation 1<br>Check Levelling 2   |  |  |
|  |                      |   |  |  |
|  | Adjustment of        | 251 Tilt Compensation   |  |  |
|  | compensator.         | Initialisation necessary  |  |  |
|  |                      | Bompensator initialisation 1<br>Check Levelling 2   |  |  |
|  |                      |   |  |  |
| Display  | ·                    | Adjust Compensator  |  |  |
| <ul> <li>Adjustment of<br/>compensator is running</li> </ul> |                      | Please Wait   |  |  |
| <b>D</b> ' 1   |                      | 251 Tilt Compensation   |  |  |
| Display<br>-Compe  | nsator adjusted      | Status : o.k.   |  |  |
|  | -                    | Compensator initialisation 1<br>Check Levelling 2   |  |  |



"Check Levelling"

Display – Instrument is levelled







Return to main menu

| Main Menu  |               | NONAME  |                       |
|------------|---------------|---|-----------------------|
| Stationing | 1<br>234<br>5 | Special<br>Editor<br>Data Transfer<br>Configuration<br>Remote Control | 6<br>7<br>8<br>9<br>0 |

# Switch to measurement towards an ordinary prism

If you, during a robotic measurement wish to measure towards an ordinary prism (e.g. when you wish to measure outside the range of the tracker), you can deactivate the function AutoLock<sup>TM</sup> at the RCU in any application menu.

| Measure              |  |
|----------------------|--|
| Display              |  |
| -AutoLock™ active,   |  |
| Status symbol        |  |
| <br>Generation Shown |  |

3 Measure Adr: 37 SD Hz V1 6.102 m 169.3138 зоп 100.0622 зоп 1.000000 s - Þ7 i h th 0.000 m 0.000 m Θ P 1 -PNr----><---Info-< Mode Rec Ioff R-M Ecc. HidP Inpt Code Srch +2

3

| Srch               | Select AutoLock™                   | 3 Measure<br>s 1.000000 SD 6.102 m  | Adr: 37                |
|--------------------|------------------------------------|---|------------------------|
|                    |                                    | in 0.000 m Hz 169.3138 son<br>th 0.000 m U1 100.0622 son<br><pnr>XInfo&gt;<br/>Mode Rec 1044 R=K ECC. Hidp Inpt</pnr>   |                        |
| Display<br>– menu  | AutoLock <sup>™</sup> active       | AutoLock : I  |                        |
|                    | Deactivate<br>AutoLock™            | Press spacebar to deactivate AutoLo   | Win SwtP<br>DCk™.      |
| Display<br>– AutoL | ock™ deactivated                   | AutoLock : []<br>AutoLock : []  | <b>ff</b><br>Win  SwtP |
| ,€                 | sc Jump back<br>to menu<br>Measure | 3 Measure           S         1.000000           ih         0.000 m           Hz         169.3139 son           th         0.000 m           V1         100.0622 son           PNr>           Model         Rec           Inst         Inst | Adr: 37                |

### Switch back to robotic surveying

If you wish to switch back to robotic surveying from measuring towards an ordinary prism, you can activate the function AutoLock<sup>™</sup> at the RCU in any application menu.

| Measure           | 2                | 3 |
|-------------------|------------------|---|
| Display<br>-AutoL | ock™ inactive    |   |
| Srch              | Select AutoLock™ |   |

| 3             | Measure                                       |  |     | Adr: | 37 |
|---------------|---|--|-----|------|----|
| s<br>ih<br>th | 1.000000<br>0.000 m<br>0.000 m                | SD 6.102 r<br>Hz 169.3139 s<br>V1 100.0619 s       | 90n | 17   |    |
| <b>X</b>      |   | > <info< th=""><th></th><th></th><th></th></info<> |     |      |    |
| Mo            | Mode Rec Ioff R-M Ecc. HidP Inpt Code Srch +2 |  |     |      |    |

| ЗМ            | leasure                    |    |                |                               |     | Adr:      | 37 |
|---------------|----------------------------|----|----------------|-------------------------------|-----|-----------|----|
| s<br>ih<br>th | 1.000000<br>0.000<br>0.000 | пп | SD<br>Hz<br>V1 | 6.102<br>169.3139<br>100.0622 | gon |           |    |
| >             |                            |    |                |                               |     |           |    |
| Mode          | e Rec Io                   | 4  | R-M            | Ecc. HidP I                   | npt | Code Srch | →2 |

Display – AutoLock™ deactivated

| AutoLock |      |   |       |      |
|----------|------|---|-------|------|
| AutoLock |      | : | Off   |      |
|          |      |   |       |      |
|          |      |   |       |      |
|          |      |   |       |      |
| Find     | Cent |   | Win S | 5wtP |

Activate AutoLock™

Press spacebar to activate AutoLock<sup>™</sup>.

Display

– AutoLock<sup>™</sup> activated

| AutoLock |               |
|----------|---------------|
| AutoLock | : On          |
|          |               |
|          |               |
|          |               |
| Find     | Cent Win SwtP |



Jump back to menu Measure

| ЗMe   | easure                         |                |                               |          | Adr:      | 37 |
|---|--------------------------------|----------------|-------------------------------|----------|-----------|----|
| S<br>ih<br>th                                 | 1.000000<br>0.000 m<br>0.000 m | SD<br>Hz<br>V1 | 6.102<br>169.3138<br>100.0622 | gon      | Ĵ ŀ∕      |    |
|   |                                |                | Info                          |          |           |    |
| Mode Rec Ioff R-M Ecc. HidP Inpt Code Srch →2 |                                |                |                               |          |           |    |
| Auto  | oLock™ ac                      | tive, St       | atus symbo                    | <br>⊖ lc | <br>showr | n. |

### Search functions in robotic surveying

### Find Cent Win

AutoLock™ Search Window Autom. Centre When you are surveying with Trimble 5600 series in robotic mode there is a number of search functions that can be very useful depending on actual application. These functions are described below.

Search Window: OFF Autom. Centre: OFF Find Start search Instrument searches 360 degrees.

Search Window: OFF Autom. Centre: On Find Start search Instrument searches in the area the RMT were lost.

Instrument searches 360 degrees if the RMT couldn't be find in the area the RMT were lost.

Search Window: On Autom. Centre: OFF Find Start search

Instrument searches in the pre-selected window.

Search Window: On Autom. Centre: On Find Start search Instrument searches in the area the RMT were lost.

<sup>ce</sup> Tip : If the instrument in Tracking mode looses lock of the target (RMT) it automatically locks on to the target as soon as it is visible again. This function is useful if you, for example, are measuring in heavy traffic with cars temporarily blocking the measuring beam.

### **Distance Mode Direct Reflex (Option)**

First switch on your instrument activate compensator, check levelling and set all the required parameters like PPM-factor etc.



Select any application, e.g. Measurement

| Main Menu  |               | NONAME  |       |
|--|---------------|---|-------|
| Proj. Management<br>Adjustment<br>Measure<br>Stationing<br>Coordinates | 12<br>34<br>5 | Special<br>Editor<br>Data Transfer<br>Configuration<br>Remote Control | 67890 |

Ctrl, R Direct Reflex Mode

| 3 Measure                               |                                |                | Adr:                          | 330             |    |   |
|---|--------------------------------|----------------|-------------------------------|-----------------|----|---|
| S<br>ih<br>th                           | 1.000000<br>0.000 m<br>0.000 m | SD<br>Hz<br>V1 | 232.881<br>79.9920<br>99.0034 | m<br>90n<br>90n | ▶* |   |
| ₹                                       |                                |                | Info                          | ->              |    | ۲ |
| Mode Rec ObjH Info Zon D:N DSet CtrP →3 |                                |                |                               |                 |    |   |

Switch ON / OFF Distance Mode "Direct Reflex".



Direct Reflex mode. The "reflectorless" mode.

In measurement menu the actual settings are displayed in the instrument status window.



The following EDM modes are possible:




Direct Reflex mode. The "reflectorless" mode.



Direct Reflex mode. The reflector "Weak signal" mode. This means lower accuracy.



Prism mode. The reflector mode.



Switch ON / OFF Laser Pointer.

\* Activate Laser Pointer

#### 👁 Note

Laser Pointer and EDM mode switches via Hotkey is only possible in the measurement menus.

Default EDM Mode: Prism Mode

#### Note

After instrument start the EDM Mode is set to Prism Mode PM.

Dset Configuration-Instrument-EDM-Setting

SwtP Configuration-Instrument-Periphery-Switches.

#### Standard Deviation

Set accuracy

EDM Mode:

DR = Direct Reflex Mode PR = Prism Mode

Dist interval max.

Set sightdistance to max.

Dist interval min

Set sightdistance to min

Pointer

Laser Pointer ON / OFF

Weak Signal

Set for weak reflected signal


Laserp.OFF (switch off time)

OFF=Pointer always ON Once=Pointer OFF after trigger instrument

10 min=Pointer OFF after 10 minutes

### Switches


In the Configuration Menu the EDM functions can also be switched ON or OFF. Enter to configuration menu 915 or **9132** or use the softkey Dset or **SwtP** in the measurement menus:



#### plus

| EDM Settings       |            |
|--------------------|------------|
| Standard deviation | : 0,0003 m |
| EDM Mode           | : DR       |
| Dist interval max. | : 500 m    |
| Dist interval min. | : 2 m      |
| Pointer            | : Off      |
| Weak signal        | : Off      |

or



#### plus

| 9132 Periphery Switches |     |  |  |
|-------------------------|-----|--|--|
| Tracklight              | Off |  |  |
| Laserp.Off              | Off |  |  |
| Sound                   | On  |  |  |
| Signal Volume           | O   |  |  |

Use space key to toggle

Press **I** to save settings.

In measurement menu the actual settings are displayed in the instrument status window.

In measurement menus the EDM Mode can be switched using the hotkey

In measurement menus the EDM Mode can be switched using the hotkey

The Laser Pointer can be switched ON/OFF using the hotkey



### EDM Mode and reflector type

The EDM modes are combined with reflector types set in the **Input Menu** of the measurement program. To enter this menu, press **Functionkey** F7 to activate **Inpt**:

Inpt Input Menu

| Input of Parameters                            | 5                  |                   |
|--|--------------------|-------------------|
| R.Type: <mark>Normal</mark><br>Refl. : 1.300 m | Темр. :            | 6 °C              |
| Inst. : 1.705 m                                | Press :<br>PrismC: | 969 hPa<br>-30 mm |
| Scale : 1.000000                               | ppm :              | 0                 |


Use space key to toggle between reflector types Normal Prism, 360° round Prism, Foil and None Reflector.

Press loss to save settings.

#### 🕿 Note

If Prism Mode is set, only one of the three reflectors can be selected. A "None reflector" type can be activated only in EDM DR mode.

The last used mode will be stored and activated again after reload the program.



### When using EDM Modes?

| •                | Direct Reflex Mode (reflectorless)   |  |  |  |
|------------------|--|--|--|--|
|                  | When measuring without prisms or other reflec-<br>tors. The prism constant and reflector height is set<br>to zero (default). If needed both values can be<br>changed in the Input Menu for the "None" reflec-<br>tor type. |  |  |  |
| Measuring Range: | Kodak grey 200m  |  |  |  |
|                  | Kodak white >600m  |  |  |  |
| &                | Prism Mode   |  |  |  |
|                  | When measuring to prisms or other reflectors like<br>foil. The prism constant and reflector height refers<br>to the actual selected reflector type and can be<br>changed in the Input Menu.                                |  |  |  |
| Measuring Range: | 2- 5500 m (for one prism)  |  |  |  |
|                  | 2 – 800 m (for foil reflector)   |  |  |  |

### 👁 Note

Prisms should be measured in **Prism Mode**, because the EDM is then not so sensitive to disturbing influences and has the highest accuracy.



### Direct Reflex Mode (weak signal)

When measuring in direct reflex mode you may need to activate the weak signal if it isn't possible to measure the object.

# Operation

#### **Direct Reflex Distance Measurement**


Appendix Technical Data

EDM Modes:



- The values given in the technischen Datenblatt concerning accuracy, range and measurement time depend on the following effects:
- Atmospheric influences (sight conditions, rain, wavering heat)
- Radiation of the sun at the aim
- Disruption of the beam by moving objects

The range of unambiguity of an indicated measurement covers up to 5,5 km using Prism Mode.




When measuring in Direct Reflex Mode the fol-

## Attention !

When using Direct Reflex Mode avoid any interruptions of the beam. If the beam is interrupted while measuring (e.g. shortly by moving objects) the mesured distance has to be checked by remeasuring.

DSet Activation of Distance intervall max., min. You can avoid incorrect distance measurement by activating Distance interval (max., min.) e.g. in the measurement program. This is especially advisable when measuring across roads with havy traffic.



## 🖝 Tip

To seperately measure angle and distance or indirectly determine points – "Eccentricity".

When measuring greater distances the accuracy of the distance measurement depends on the correction of the atmospheric influences such as temperature pressure and humidity. In order to restrict the atmospheric correction to exactly 1ppm (mm/km) temperature has to be determined up to 1°C, pressure up to 4hPa and humidity up to 20% along the measuring section.

Appendix

Formulas and constants The correction formulas are given in the appendix.


### 🕿 Tip

Using Direct Reflex Mode be aware of a minimum distance of 2 m. If there are unfavourable conditions you cannot fall short of this minimum distance.

## Menu guidance


Menus support the user at any stage of the program.

#### **Options menu**



To select an option, use either the selection cursor plus or the appropriate hotkey for the option number.

#### Measurement menu



**F1** to **F10** for function keys.

In the measurement menu, you can navigate between the input fields for point identification and reflector height using


🔄 and 🚺.


or the special trigger key **PWR** to start the measurement.

#### Key:

- 1 Menu number
- 2 Menu title
- 3 Project name or address
- 4 Selection cursor
- 5 Option + number
- 6 Additional data
- 7 Meas./comp.values
- 8 Marking
- 9 Point identification
- 10 Function keys
- 11 Status symbols
- 12 Next row of function keys

#### Input menu





ends the entry.

## Switch menu


| 15                       | 16         |
|--------------------------|------------|
| /                        | /          |
| 9132 Periphery           | ∫ Swi‡ches |
| Tracklight<br>Laserp.Off | Off<br>Off |
| Sound<br>Signal Volume   | 0n<br>0    |

Key:

- 13 Input option
- 14 Input field cursor
- 15 Switch
- 16 Switch field
- 17 Error number
- 18 Error type
- 19 Error information



#### Error messages in the display




# Operation

Lists

Key:

| 20 | List | curso | r |
|----|------|-------|---|
|    | _    |       |   |

21 Function keys



**F1** to **F10** for function keys.

## Quitting the menu

You can quit all menus with **Esc**. If any entries have been made or edited, an inquiry is first displayed as to whether the changes should be saved.

## **Help function**

The integrated on-line help is available in all program parts. The help function will be called using the hotkey


| Ctrl H | at any point of the program. |  |
|--------|------------------------------|--|
|--------|------------------------------|--|

Help

5 Coordinates – 51 Detail Points

52 Setting Out

# Zeiss Elta<sup>®</sup> CU and Radio



RCU is the unit for radio remote control of the Trimble 5600 series.


RCU comprises the components:

- Zeiss **Elta<sup>®</sup> CU** (1) (486 compatible processor), 33 MHz, 8MB Flash)
- **Georadio** (2) (radio module,  $\lambda/4$ - $\lambda/2$  antenna)
- Elta<sup>®</sup> CU holder, (Option: data cable)

#### Attention!

Be careful opening the lid for removing the PCMCIA card!

## Zeiss Elta<sup>®</sup> CU



Esc Escape



Ceiss Elta<sup>®</sup> CU Operation The unit can be used with or without a PC card.

#### 🕿 Tip

For a more comfortable triggering of the measurement use the **PWR** key.

## Special Notes for Elta<sup>®</sup> CU

Elta<sup>®</sup> CU is normally meant to be used whilst connected to the Georadio – and takes its power from Georadio battery (operation time on one battery is between 6-10 hours depending on temperature and use of display illumination etc.).

The unit has an internal backup battery, which will allow a stand-alone operation for up to 2 hours. At low radio battery a warning comes up. Now the user can safely shout down the Elta<sup>®</sup> CU.

The Elta<sup>®</sup>CU module can also be connected to a 220V office power unit or to a Cigarette lighter outlet 12V car adapter.

## Elta<sup>®</sup> CU on-line and off-line mode

| on-line (Radio) | Full software functionality via radio link to the |
|-----------------|---|
|                 | Trimble 5600 instrument.                          |
|                 |   |


- **On-line (Instrument)** Full software functionality when Zeiss Elta<sup>®</sup> CU is attached on the Trimble 5600 instrument.
  - off-linePower from an external battery (3,5Ah or 6,6Ah).Access to all menus in off-line mode.Measurement value entering manually.Data transfer via PCMCIA-card or RS232C cable.

## Interface ports



Serial interface COM1.

Connect the Georadio for remote mode or PC for data transfer to the serial interface of the  $\text{Elta}^{\circledast}$  CU.



Serial interface COM3 and COM4.

Connect the Elta<sup>®</sup> CU via COM3 or COM4 with the holder for keyboard unit.

# Zeiss Elta<sup>®</sup> CU and Radio

**Data Transfer** PCMCIA Card Data Memory

#### Using a PC card



Zeiss Elta<sup>®</sup>CU card slot

The Elta<sup>®</sup> CU provides 8 MB of internal storage capacity. However, a PC card can also be used, and allows the easy transportation of data from the instrument to the Elta<sup>®</sup> CU.

# Zeiss Elta<sup>®</sup> CU and Radio

#### **Battery ports**



#### Annex

Ш

Technical Data Zeiss Elta<sup>®</sup> CU- Information for first use

## Charging the backup battery

- (1) Connect the power supply.
- (2) Charging time is about 70 minutes.

#### Radio

The Trimble 5600 has the Georadio that can work with the system. The Georadio has a removable battery and the ability to select channels should the radio signal be disturbed.

### Attention

Please be sure that you have the appropriate license for using the Georadio before using the data radio. It is the responsibility of the user to ensure that this license is arranged.

## Attention

If there should arise questions with reference to the application of the radio data transmission module please contact the trader in your country.

## 🕿 Tip

Set the Data Radio as high as possible on the prism pole. Radios that are set too low will limit the range over which the instrument is operable.

## **Safety Notes**

#### **Risks in use**



Instruments and original accessories from Trimble AB must only be used for the intended purpose. Carefully read the manual before the first use and be sure to comply with the safety notes.

# Attention!

• Don't make any changes or repairs on the instrument and accessories. This must be done only by a service team or by authorised technical staff.

• Do not point the telescope directly at the sun.

• The instrument is equipped with servomotors. Operate the instrument as described in this manual to avoid your fingers being caught between the handle and the telescope body or between the telescope and the uprights. The forces occurring lie below the threshold for potential injury. The motors can be immediately stopped in a hazardous situation by separating the batteries from the instrument (loss of data!).

• Do not operate the battery charger and PC card reader in humid conditions (risk of electrical shock). Do not use instruments while they are wet.

## **Safety Notes**



# Attention!

• The magnetic PC card cover should always be closed to stop environment damage (water, dust).

• Check that the instrument has been correctly set up and the accessories are properly secured.

• Take the necessary precautions at your measuring site in the field; note the relevant traffic rules.

• Check your instrument at regular intervals in order to avoid faulty measurements, especially after it has been subjected to shock or heavy punishment.

• The instrument and accessories must only be opened by a service team or by authorised technical staff.

• Remove the batteries in case of unloading or a longer time without using the instrument.

• Properly dispose of the batteries and equipment taking into account the applicable national regulations.

• Do not use destroyed plugs and cables for accessories with the instrument.

• Do not use the instrument and accessories in rooms with danger of explosion.

## 2-74

The first steps cover the set-up and check of the instrument. The data is stored project wise, and is controlled via the *Project Management*.


In the Program *Measuring in a Local System*, one can measure using all functions of the Trimble 5600 series Total Station.

**Before Measurement** 

Project Management

Measuring in a Local System

## Set Up and Centring



#### Attention!

In order to guarantee the stability of measurement we recommend the use of a Heavy Duty Tripod.

### Set-up:

Fix the tripod legs (1) over the required point using the tripod locking screw (2). Screw the instrument tribrach to the tripod head (3).

#### Centring:

With the tripod set over the station point, look through the optical plummet (5) and position the centre over the station point using the tribrach screws (4).

## Attention!

For precise measurement it is necessary to control the tribrach-instrument connection.

- 1. Make sure, that the tribrach is stable and OK.
- 2. Set the instrument on the tribrach correctly.
- 3. Lock the tribrach screw strong enough.

## **Levelling and Fine Centring**



Adjustment

Compensator

Configuration Instrument

Ш

#### Coarse Levelling:

Level the Circular Bubble (6) by adjusting the tripod legs (1).

## Fine Levelling:

The digital fine levelling is accessed using the

Ctrl L hotkey:




The inclination values displayed are in the same unit as set in instrument configuration.

Position the instrument parallel to two of the tribrach screws. Turn the two tribrach screws together in opposite directions, and the third alone. Level the instrument in the Trunnion Axis (1) and Sighting Axis (2). Turn the instrument to check the verticality of the instrument. The levelling error should be within the working range of the compensator.

After adjustment press **Esc** to return to the program screen.

## Fine Centring:

Check the final position over the point. Move the instrument on the tripod head and repeat the fine levelling if necessary.



#### **Telescope Focussing**

#### Focussing the Cross Hairs:

With the telescope focussed on Infinity, bring the cross hairs into focus.

### Attention!

Do not use the telescope to look at the sun or other bright and concentrated light sources or you risk permanent eye damage.

### 👁 Tip

Check the telescope Parallax: Move the position of your eye slightly whilst looking through the telescope. If the cross hairs are not correctly focussed they will appear to move. If this occurs, refocus the crosshairs as above.

## Check-List

|              |  | Before measuring, it is a good idea to check the<br>status of the instrument. You will find the sym-<br>bols in the display are very helpful. It will also be<br>useful to use the following CheckList: |
|--------------|--|---|
| 1.           | Set Up ok. ?   | Levelling, Centring   |
| 2.           | Adjustment ok. ?   | <ul><li>V-Index- and Hz-Collimation</li><li>Compensator run centre point</li><li>FineLock</li></ul>   |
| 3.           | Data ok. ?   | <ul> <li>PC Card is in?</li> <li>Control RCU) ok. ?</li> </ul>  |
| 4.<br>strume | Switches ok. ?<br>Configuration / In-<br>nt / Switches / | <ul> <li>Compensation activated ?</li> <li>Units / Decimal Points are set?</li> <li>Measure system ?</li> <li>Recording ?</li> <li>on?</li> </ul>   |
| 5.           | Battery ok. ?  | • Battery Strength , use Ctrl B   |
| 6.           | Project ok ?   | • Is the current Project ok. ?  |

## **Create a New Project**

| ProjMa  | anagement 1                     | 1 Project  | Management                               |   | ZOTTELST                                 |
|---------|---------------------------------|--|--|---|--|
|         | or <b>1</b> to select           | PROJ_F<br>BACKLEBN<br>TAMBACH<br>GESTERN<br>10_02_97 | 9801<br>18029<br>43681<br>11011<br>28677 | 11_02_97<br>12_02_97<br>NONAME<br>JENA<br>ZOILIELST | 12826<br>9922<br>20086<br>16940<br>19481 |
| New     | to create a new<br>project. In- | The Projects a project scree                         |  |   |  |
| put a n | ew<br>project name and          |  |  |   |  |
|         | to confirm.                     |  |  |   |  |

## Select an existing Project

| Ļ | Select the Project<br>with the cursor<br>keys. | <ul> <li>Tip</li> <li>Scroll with PgUp, PgDn, Home, End . Edit</li> <li>Project data with the Edit softkey.</li> </ul> |
|---|--|--|
|   | to confirm as the<br>current Project.          |  |

## **Connect Projects**

Conn to connect one Project with another.

| Project TAMRAPH combine with |                      |  |
|------------------------------|----------------------|--|
| HO Project                   | TAMBACH combine with |  |
| PR<br>BA<br>GE<br>10         | JENA<br>Yes No       |  |

## Attention!

After connection, the Project ("JENA") will be completely integrated and still exists on as a separate project file.

# **Project Management**

### **Edit a Project**

 Edit
 to call the editor
 7 Editor
 HOCHTIEF

 Image: Data Management Editor
 1 DDKS 9303 4104
 2 DDKS 9303 4104

 Image: Data Management Editor
 3 DDKS 9303 41012
 4 DDKS 9303 41012

 Image: Data Management Editor
 5 DDKS 9303 41016
 5 DDKS 9303 41012

 Image: Data Management Editor
 6 Edit Srch Adr. ENF Rept Fitt 52

Editor Menu.

### Delete, Rename, and Copy a Project

Name Rename Project

Copy Copy Project

| 1 P: | roject Management HOCHTIEF         |   |
|------|------------------------------------|---|
| на   | Copy Project =                     | = |
|      | A:\TAMBACH.DAT<br>Project exists ! |   |
| ĬĔ   | Press any key to continue          |   |
| New  | Del Conn Copy Name Info Edit       | _ |

#### Attention!

It is not possible to rename or copy a Project if the same name exists.

## **Project Information**

| Info | Input the Project | 18 Edit Pr  | oject Info   | ZOTTELST |
|------|-------------------|---|--|----------|
|      | Information.      | Project<br>ProjNr.<br>Detailer<br>Observer<br>Reflector | Zottelstedt<br>98-0815-4711<br>Mr. Smith<br>Mrs. Black<br><u>KTR 1 N</u> |          |


Input of up to 10 Information lines in each Project Information. 16 alphanumeric characters per line.

**PgUP PgDn** to select the other page.

| 18 Edit Pro   | ject Info   | NONAME       |
|---|---|--------------|
| Instr.type<br>Instr.Nr.<br>Date<br>Remark<br>Remark | GDM 600<br>123456<br>21.12.2000<br>Jena<br>Carl-Zeiss-S | <b>171</b> 0 |

| Measu | re 3  | Z 🛉       | ×  |
|-------|---|-----------|----|
| Mode  | Press to toggle the<br>measure mode:<br>SD Hz V<br>HD Hz h<br>y x z<br>Hz V | z x<br>Hz | SD |
|       |   |           |    |

to copy the last measurement (measure buffer) and the PI with respect to the measure and registration mode to the current project.



Reflector

th

h

..... HD


#### 🕿 Tip

Use MODE and Rec to store different measure values without remeasuring the point.

## **Input of Parameters**

Inpt Input

- Instrument and Target Height (1)
- (2) Prism Constants
- (3) **Temperature and Pressure**
- Scale Factor of Local System / ppm (4)
- (5) Reflector Type ( **E** to select )



# Ν

Rec

## 🕿 Tip

For each reflector type a reflector height and a prism constant will be stored. If the type of reflector was changed, the last reflector height input for this reflector type is selected automatically. For controlling this leave the reflector type toggle field by pressing or .

| The local scale factor will be<br>used to correct the distance<br>measurements in a local<br>system. |  | The scale factor of the local system will not be<br>that calculated using the stationing routines. En-<br>tering a local scale factor will only effect meas-<br>urements in a local system.                   |                    |  |
|--|--|---|--------------------|--|
| Default  | : s = 1.000 000  | The values of addition and prism constant and the values of Scale Factor and PPM are connected.<br>Changing one value will effect the other partner value.  |                    |  |
| R-MC   | Recording Mode   | (1)<br>(2)<br>(3)   | R-M<br>R-C<br>R-MC | for original measured data<br>for computed data<br>for meas. and computed data |
| strume   | Recording <b>On</b><br><b>Configuration</b> In-<br>nt Switches | A selection of one of the recording modes is pos-<br>sible only if the right measuring mode is selected.<br>Selection of the Record mode is only possible<br>when the recording Configuration is switch to On |                    |  |

Ioff Incrementation of the point number On / Off

| 3 M∈            | Adr.                                 | _ 161 |
|-----------------|--------------------------------------|-------|
| 5               | Set Incrementation                   |       |
| ih<br>th<br>100 | Increment :                          | ] [   |
| Mode            | Rec Ion R-M Ecc. HidP Inpt Code Srck | 1 →2  |

Set the increment step.

to accept.

## 🕿 Tip

The furthest numerical part on the right of the point number will be incremented. For the incrementation it is necessary, that the point number can be moved to the left in the point number block of the marking.

Changing the Marking will cause the Incrementation to be switched off.



If the point number 99 was entered on the left side of the block, it cannot be incremented to 100. Then the following error message appears:

The incrementation will be automatically switched off.

| Error Incrementing<br>Point number to high ! |  |  |  |  |
|--|--|--|--|--|
| Incrementation will be swiched off !         |  |  |  |  |
| Press any key to continue                    |  |  |  |  |


For an incrementation from 99 up to 100 it is necessary, to enter the number more to the right in the block.


## **Input of the Point Identification PI**

Use the cursors to navigate the input field.

Switch between code fields using **[** 

Input the PI using the keyboard or a Codelist.





Configuration Marking Input field of the Point Identification PI (27 characters) with freely configurable fields.

## **Using Codelists**

| Code | Call Codelist | To activate this softkey, the PI field must have a codelist already attached to it (as defined during the Configuration of the Marking). |              |  |
|------|---------------|--|--------------|--|
|      |               | The cursor must be positioned within the required code field.  |              |  |
|      |               | ROAD_points_18   |              |  |
|      |               | Code     Description       SOP     Setting Out Point       DT     Detail Point       HP     Height Point       TP     Trig. Point        |              |  |
|      |               | Example: Codelist <b>ROAD_points_1</b>   | 8            |  |
|      | Configuration | Select the required Code with 🚺  | and 💭 .      |  |
|      | Codelists     | The correct Code is then implement field.  | ed in the Pl |  |

## Prism Search and Prism Tracking (RMT)

| Srch<br>Find        | Call<br>AutoLock™<br>Start searching<br>RMT  | AutoLock  |
|---------------------|--|---|
| Cent<br>Win<br>SwtP | Set centre for<br>window<br>Set dimension of<br>window<br>Select menu<br>TrackLight <sup>®</sup> | Use the Spacebar ■ to select AutoLock <sup>™</sup> OFF<br>ON or Tracking.<br>FineLock: On / Off / Tracking /<br>Trimble 5600– Operation AutoLock <sup>™</sup> |
| ¥ *                 | Status-Symbols:<br>AutoLock™ <b>On</b><br>Tracking <b>On</b><br>Tracking lost                    | <ul> <li>Tip</li> <li>Use the AutoLock<sup>™</sup> function of the<br/>Trimble 5600 for more practical one man<br/>operation of the instrument.</li> </ul>    |

| Cfg  | Configuration of<br>Prism Search                                  | 9141 Swi  |
|------|---|-----------|
| SwtP | Periphery Switches  |           |
|      | <b>Configuration</b><br>Instrument<br>Switches / Prism<br>Sensors | Configura |

| 9141 Switch AutoLock |       |
|----------------------|-------|
| AutoLock             | : Off |

Configuration Menu for the AutoLock<sup>™</sup> function.

| Eccentric Measuring / Intersection         |   |  |  |  |
|--|---|--|--|--|
| Ecc. Eccentricity<br>Intersection          | Eccentricity<br>Typ : Eccenter<br>Refl. Offset right<br>Length 0.000 m<br>Mode Once<br>Height Un                  |  |  |  |
|  | Indirect Survey         Type       : Intersections         Method       : Angle / Dist.         1. Hzv       Mode |  |  |  |
|  | <ul><li>toggling between options.</li><li>Type: Eccentricity</li><li>Type: Intersection</li></ul>                 |  |  |  |
| Eccentricity<br>∠ Length L < 100 m         | S Centre<br>Point   |  |  |  |
| Reflector Offset:                          | Eccentricity<br>Typ : Eccenter<br>Refl. Offset right<br>Length 0.000 m<br>Mode Once<br>Height Un                  |  |  |  |
| s     s       front of     behind          | toggling between options.ModeOncefor a one off Measurement,ModePermfor a permanent eccentricity,ModeOffto cancel. |  |  |  |
| slope (in sighting axis)<br>to the Centre. |   |  |  |  |

Height **On** To use the height of the eccentric point in position left, right, front of or behind to the centre. The centre height is calculated for a slope eccentre.

**Off** no height coordinate.

Ecc.



#### Method of measurement:






Angle/Dist.



general



toggling between options.

| Mode | Once | for a one off Measurement,    |
|------|------|-------------------------------|
| Mode | Perm | for a permanent eccentricity, |
| Mode | Off  | to cancel.                    |

#### Attention!

If the height difference between the eccentric point in position left, right, front of or behind to the centre is large, then set the height to **Off.** 

The function **Ecc.** is not available during the Hidden Point Measurement.

| n Point Measurem | ent   |  | a 🖪 🖄  |
|------------------|---|--|--|
| Hidden Point     |   |  | R1<br>R2<br>P  |
|                  |   |  | reflector R2 and   |
|                  |   |  | Reflectors R1 and  |
|                  | Hidden Po   | int  |  |
|                  |   | /R1 Mode :<br>R2 - P :<br>R2 R1 - R2 :<br>7777 Tolerance :   | 0.655 m<br>0.655 m<br>1.855 m<br>0.003 m   |
|                  | Modes:  | see Eccentric  | Measurement  |
|                  | accuracy of   | the measurement o  | ed to check the<br>f R1 - R2.  |
| Mode - Hidden    | 3 Hidden  | Point: Refl R1   | Adr: 166   |
| Node - Hidden    |   |  | sonll T b/   |
| D.M.             |   |  |  |
|                  | <pnr-< td=""><td>&gt;<info< td=""><td>&gt;   ∐<br/>net Code Srch →2</td></info<></td></pnr-<> | > <info< td=""><td>&gt;   ∐<br/>net Code Srch →2</td></info<>  | >   ∐<br>net Code Srch →2  |
| R-M, R-C, R-MC   | The program<br>urement of<br>height Z <sub>P</sub> w  | m guides the user th<br>R1 and R2.<br>/ill always be calcula   | nrough the meas-<br>The  |
|                  | Hidden Point<br>Mode - Hidden<br>R-M<br>R-M, R-C, R-MC  | R2-P       District         R1-R2       District         R1-R2       District         R2       Hidden Po         Modes:       Tolerance:         accuracy of       Default Value         Mode - Hidden       3 Hidden         R-M       R-M:         R-M, R-C, R-MC       Ioos12         R-M, R-C, R-MC       The program         urement of       height Z <sub>p</sub> w | Hidden Point         R2-P       Distance between the the Prism Point P         R1-R2       Distance between the R2 on the Prism Rod.         Hidden Point       R1-R2         Image: R1-R2       Distance between the R2 on the Prism Rod.         Hidden Point       R1-R2         Image: R1-R2       Pister Point         Image: R1-R2       Pister Point         Image: R1-R2       Pister Point         Image: R1-R2       Pister Point         Image: R-M       R-M, R-C, R-MC         Image: R2-P       R-M         R-M, R-C, R-MC       Image: R2-P |

## Attention!

Using a AutoLock<sup>™</sup> measurement can be problematic, as the AutoLock<sup>™</sup> will lock to the strongest Signal of two prisms inside the telescope suncircle. Please make a test measurement before using!

## **Object Height Measurement**

ObjH


After measuring to a reference point in Mode:



SD Hz V HD Hz h y x z

is this softkey ac-

cessible.




1

/ ▲ 12→ + ∠

The Reference Point defines the line of the Instrument - Reflector (I-R) and the vertical plane normal to I-R. It is then possible using only the angle measurement **HzV** to define heights and offsets in the plane:

- HD Horizontal Distance I-R
- **O** Perpendicular position L-R (90° to I-R)
- h Object Height from R



Measure Reference Point with 🞑 💷 🗠 . Eccentric measuring is also possible.

| 3 Measure           | Object       | Height                            | Adr:     | 169 |  |
|---------------------|--------------|-----------------------------------|----------|-----|--|
|                     | HD<br>O<br>h | 135.807 m<br>21.025 m<br>20.508 m | <b>1</b> | ļ   |  |
| 700500 Object Heigh |              |                                   |          |     |  |
| Mode Rec Io         | Code         | ÷2                                |          |     |  |

to measure Object Height + Offset in HzV measure mode.

Toggle the **Mode** softkey to see **HD Hz h** and record with **Rec**:

- HD Horizontal Distance I-L
- h Object Height from Station I

Au aut

AutoLock<sup>™</sup> is automatically cancelled

| Contro                  | ol Point Measuring                 |  |   |                    | ◢ ∿ ∡                    |
|-------------------------|------------------------------------|--|---|--------------------|--------------------------|
| CtrP<br>Define<br>Check | Control Point<br>2                 | To set a Control Point (CtrP). The measurement is<br>available in all measuring modes:<br><b>5131 Define Control Point</b> Adr: 173<br><b>5</b> 0.999700 JHZ 300.3446 gon<br>th 1.550 m V1 91.2246 gon<br>2136-10034 Control Point<br>Control Point<br>Control Point Of PUR.<br>Sight CtrP, Measure with Cor PUR.<br>Sighting and checking a CtrP is possible in every<br>measurement routine: |   |                    |                          |
|                         |                                    | 5133 Control Point   |   |                    |                          |
| Mode                    | switch to <b>dr</b>                |  | dl[m]<br>-0.001                                   | da[gon]<br>-0.0002 | dq[m]<br>0.000           |
| New                     | Repeat Measure                     | Mode Re  |   | Cfa                |                          |
| Cfg                     | Configuration<br>Error Limits CtrP | Results of CtrP Measuring with 🞑 :   |   |                    |                          |
|                         |                                    | dl   | Length misclo                                     |                    | [m]                      |
|                         | <b>Configuration</b><br>Program    | da<br>dq<br>dr   | Angle misclos<br>Cross misclosu<br>Radial misclos | ure                | [gon] (Hz)<br>[m]<br>[m] |

## **Motorised Directions and Hz-Circle Orientation**

- → Call-up
- 1↔2 Motorised turn Face 1 / 2
- HzOr Input of Hz circle orientation
- → Hz turn to a defined value:

| Sight Targ.  |            |                        |    |  |  |
|--|------------|------------------------|----|--|--|
|  |            | 37.2264 s<br>01.8942 s |    |  |  |
| 1012-9980 Direction 0∎<br><pnr><info></info></pnr> |            |                        |    |  |  |
| 1€→2 €   | <b>↓</b> → | Hz(                    | Dr |  |  |

Input the direction and press **Enter** to turn the instrument using the motors.

- $\rightarrow$
- Hz 90<sup>deg</sup> to the right
  - Hz 90<sup>deg</sup> to the left




Hz - 180<sup>deg</sup>

#### **Corrections of the Measured Values**

The measured values will be subjected to the following corrections:

- Influence of Temperature and Pressure (SD)
- Prism / Addition Constant (SD)
- Inclination of the Vertical Axis (HzV)
- Horizontal Collimation + Vertical Index (HzV)
- Trunnion axis (Hz)
- Circle Eccentricity (HzV)
- AutoLock<sup>™</sup> Corrections (HzV)

The calculated values (HD, h, x, y, z) will be computed from the corrected measured values and are corrected by the configured local scale factor.



After switching on the instrument and adjustment of the compensator all corrections are switched to **On**.

When the Compensator is switched on, the compensator symbol will be displayed.

#### Attention!

In order to improve the accuracy of the keyed in temperature, the instrument should not be subject to direct sunlight.

Technical Tips in <u>Further switches and</u>
 Technical Matters

SwtC With this switch, One can toggle the various corrections On and Off.



Compensator On

## Further Switches and Technical Matters

## e 🕅 🗶 🗖 🖾

| SwtP        | Periphery Switches<br><b>Trimble 5600</b><br>TrackLight <sup>®</sup> <b>On</b>               | 9132 Periphery Switches<br>Tracklight On<br>Sound On<br>Signal Volume O   |
|-------------|--|---|
| ₩<br>®<br>* | Trimble 5600<br>DR200+<br>TrackLight <sup>®</sup> On<br>EDM mode DR ON<br>Laserpointer ON    | 9132 Periphery Switches<br>Tracklight Off<br>Laserp.Off Off<br>Sound On<br>Signal Volume O  |
|             | Error Limits <b>On</b><br>Error Limits <b>Off</b><br>Configuration<br>Instrument<br>Switches | <ul> <li>Tip</li> <li>To activate the Error Limits in HidP, ObjH,</li> <li>CtrP and 2Fce, switch On in the Configuration of Instruments.</li> </ul> |

| DIN         | Ta sual a than alia   |   |  |  |
|-------------|---|---|--|--|
| D:N         | Toggle the dis-<br>tance meter<br>Mode:<br>Normal / <b>R</b> apid<br>Tracking | Technical Tips  |  |  |
|             |   | The Temperature and Pressure will have the following influence on the Distance accuracy:<br>$\Delta t \pm 1 ^{\circ}C \pm 1 \text{ppm}$ (parts per million) |  |  |
| Zon         | Height <b>On</b> / <b>Off</b>   | $\Delta p \pm 4$  | hPa ±1 ppm   |  |
| Info        | Input info line up<br>to 27 characters.                                       | Ctrl I<br>Ctlr L  | ant Hotkeys:<br>Illumination Display + Crosshair<br>Levelling Menu<br>Battery Management |  |
| 1Fce        | Measurement in 1  | Ctlr H  |  |  |
| 2Fce        | or 2 faces.   | Ctrl P<br>Ctrl R<br>Ctrl O  | <b>21</b> ( <sup>2</sup> <sup>2</sup>  |  |
| Mark        | Change the actual<br>Marking.   | *   | For instruments type<br>Trimble 5600 DR200+  |  |
| Del<br>cord | Delete the last re-   |   |  |  |
| Dset        | Setting for Distance<br>Meter Type <b>DR</b>                                  |   |  |  |

In order to operate the instrument in a coordinate system, it is necessary to position and orientate the instrument within the system.

Free Stationing


Stationing on a Known Point

Heightstationing

**Eccentric Stationing** 



If it is not possible to occupy a point with a known position, one can carry out a free Station



$$\varkappa$$
 2  $\leq$  BP  $\leq$  20

The program is separated into the plane adjustment and the height adjustment. Through measuring up to 20 known Backsight Points, the instrument will calculate the station position, the circle orientation **Om** and the scale factor s

In order to calculate the station height, the instrument height **ih** and the target height **th** must be measured.

| 411 Station  |                  | Adr:     | 256 |
|--|------------------|----------|-----|
| s 1.000000<br>ih 1.750 m   |                  |          |     |
| 111 1.250 III  |                  |          |     |
|  | Free Station     |          |     |
| <pnr< td=""><td>-&gt;<info></info></td><td></td><td></td></pnr<> | -> <info></info> |          |     |
|  | Edit Info Mark   | Code Sut |     |



to input the instrument height **ih**.



to confirm input of the station name.

- Change projects to Proj recall BP's from another.
- Ш see *Editor* for other functions.

After the coordinate filter, select the required BP

| 412 Backsight 1  | PROJNAME   |
|--|--|
| 1 9 2714 0077<br>2 9 2714 0061<br>3 7 0429 4022<br>4 8 0429 4032<br>25 8 0429 5077 | Backsight Pnt<br>Backsight Pnt<br>Backsight Pnt<br>Backsight Pnt<br>Center Pnt Z |
| Proj Inpt Edit Srch  | Adr. PNr Filt  |



Select first Backsight Point.

| Inpt | to input a new BP                | If BP is not in list, input BP:                   |           |
|------|----------------------------------|---|-----------|
|      |                                  | 72 Input  | Adr: 257  |
|      |                                  | Y 564738.255 m<br>X 403596.582 m<br>Z -9999.000 m |           |
|      |                                  | 37904 BP5∎<br><pnr></pnr>                         |           |
|      |                                  | Mode Ioff Info Mark                               | Code      |
|      |                                  | <b>Mode</b> for switching between YXZ, HDHzh.     | SDHzV and |
| Ľ    | Z = -9999.000 for points without | Select the input fields with 1.                   |           |
|      | known height                     | Record with 🤍 . End Input wi                      | th Esc.   |

#### **Free Stationing Measurement**

413 Measure Backsight Adr: 259 Mode **Toggle** measure Nr. SD 227.010 m 1 ナヤ mode SDHzV / HzV 38.1868 90n 97.1310 90n Hz th 1.650 m U1 ø 4 9 2714 0077 Backsight Pnt 1 BP with distance ٢. ----PNr--=><---Info R-M Ecc. HidP Inpt Code Srch →2 Mode measurement  $\wedge$ **BP** without dis-Start BP measurement with Cor PWR measurement tance 👁 Tip it is possible to edit the With Cursor target height **th**.

For a proper calculation it is possible to have a minimum of 2 BPs measured with a or 3 BPs measured with only . Therefore:

Select the second BP and measure.

You will then see the first adjustment screen:

4




to measure further BPs

| 414 Res   | iduals L2 |               | s = free     |
|-----------|-----------|---------------|--------------|
| Nr.       | vy[m]     | vx[m]         | vr[m]        |
| 1         | 0.000     | 0.000         | 0.000        |
| 2         | 0.000     | 0.000         | 0.000        |
|           |           |               |              |
|           |           |               |              |
| Mode More | BP Del N  | lew SP-A Scle | Rslt L1-A →2 |

The residuals here are zero, as this kind of selected adjustment method requires a third point for the residual computation.

The direction to the third BP will be driven automatically by the instrument.



± BP Off/On to skip the BP measurement It is possible to remove BPs from the adjustment to check their influence for the adjustment.

| 414 Res | iduals L2   |              | s = fixed    |
|---------|-------------|--------------|--------------|
| Nr.     | vl[m]       | va[gon]      | vq[m]        |
| 1       | -0.001      | -0.0009      | -0.003       |
| 2       | -0.001      | 0.0009       | 0.013        |
| 5       | 0.001       | 0.0005       | 0.010        |
| More    | 2 ±BP Del N | ew Helm Scle | Rslt L1-A →2 |

Use the cursors to select the point and then  $\pm BP$ . The adjustment will be recalculated. Pressing the function key again, this point comes back into the adjustment.


If more points will be removed than required for the calculation, the following notice will be displayed:

| Error                     | Free Stationing  |  |
|---------------------------|------------------|--|
| More Back                 | sights necessary |  |
| Press any key to continue |                  |  |

The program will automatically allow the measurement of further BPs as an adjustment.

#### 🕿 Tip

If further BPs are not required for the calculation, the program will go immediately to the adjustment.



#### **Adjustment Procedure**

The Least Squares Adjustment (L2 Norm) has 2 variations:

(1) Single Point Adjustment

#### (2) Helmert Transformation

Measured distances will always be adjusted with a scale factor s = 1.000000.

The adjustment menu will allow the selection of both adjustment methods. That means that the results can be seen from both adjustment types.

The switch is fixed when

- when the Configuration Change is set to Off ,
- Measurement without distances, or less than two distance measurements (switch from SP-A to Helmert-Transf.)

#### The Residual Menu

| 414 Res | iduals L2   |              | s = free     |
|---------|-------------|--------------|--------------|
| Nr.     | vl[m]       | va[gon]      | vq[m]        |
| 1       | 0.000       | -0.0006      | -0.002       |
| 2       | 0.000       | -0.0011      | -0.007       |
| e 3     | 0.000       | 0.0017       | 0.026        |
|         |             |              |              |
| More    | e ≛BP Del N | ew Helm Scle | Rslt L1-A →2 |

The adjustment L2-Norm with a default setting of single point adjustment.

#### 🕿 Tip

An e in the first column means that the residual is outside the error limits set in the Configuration.

**L1-A Norm** will allow the detection of a gross error in one of the BP measurements. This can then be deleted, and a new adjustment calculated.

#### L1-A

Switch to an adjustment with  $\Sigma$  absolute Residuals  $\rightarrow$ Min (L1-Norm)

Helm

Adjustment:

vv

vx

vr

#### Switch to Helmert Transformation

#### **Helmert Transformation**

Measurements to the BPs require a distance measurement in order that this adjustment type can be used.

The Helmert Transformation has the same weighting for direction and distance.

| 414 Res   | iduals L2 |               | s = free     |
|-----------|-----------|---------------|--------------|
| Nr.       | vy[m]     | VX[m]         | vr[m]        |
| 1         | -0.010    | -0.002        | 0.010        |
| 2         | 0.010     | -0.004        | 0.011        |
| 3         | 0.000     | 0.006         | 0.006        |
|           |           |               |              |
| Mode More | BP Del N  | lew SP-A Scle | Rslt L1-A →2 |

Adjustment L2-Norm of the Helmert Transformation. A BP without distance measurement will not be used.

Mode Is used within Helmert Transformation to switch between vl, va, vq

**v**-coordinate

x-coordinate

radial

### 🖝 Tip

**Mode**: Compare with the residuals of the single point adjustment.

SP-A Switch to Single Point Adjustment

### **Single Point Adjustment**

With SP-A it is possible to control error limits and direction and distance weighting in the Configuration menu. It is also possible to have BPs without a distance measurement.

| 414 Res | iduals L2 |              | s = free     |
|---------|-----------|--------------|--------------|
| Nr.     | vl[m]     | va[gon]      | vq[m]        |
| 1       | 0.000     | -0.0009      | -0.003       |
| 2       | 0.001     | -0.0016      | -0.010       |
| 3       | 0.000     | 0.0012       | 0.019        |
| e 4     |           | 0.0012       | 0.021        |
| More    | BP Det N  | ew Helm Scle | Rslt L1-A →2 |

Residuals of the SPA:

- vl Residuals in length
- va Residual in angle bearing
- vq Residual in normal to direction

**vl** is only displayed for points with a distance.

| Scle | Scale Factor <b>Free</b><br>or Fixed | 414 Residuals L2         Nr         Input Scalefactor         Scale        1<0000         e | s = free<br>vq[m]<br>-0.003<br>-0.010<br>0.019<br>0.021 |
|------|--------------------------------------|---|---|
|      |                                      | More ±BP Del New Helm Scl   | e Rslt L1-A →2  |
|      |                                      | after input.  |   |

Standard: **s** = **free** 

Default value **s** = **fixed**: 1.000000

Choosing a fixed scale factor will recall the scale range values set in the Configuration.

If s = Free, then a scale factor is computed for the adjustment.

If the scale factor input is outside the scale range values set in the Configuration, then the following screen is displayed:

| 414 | Reciduale 12          | c - free             |
|-----|-----------------------|----------------------|
| Nr  | Range exceeded        |                      |
|     | Min. :<br>Max. :      | 0.995000<br>1.005000 |
| е   | Press any key to con  | tinue                |
|     | More ±BP Del New Helm | Scle Rslt L1-A →2    |

I.e.:  $\pm$  5000 ppm scale range value.

#### 🕿 Tip

If the scale factor is **fixed** the number of unknowns of the adjustment decreases. I.e. even for the minimum geometry (2 BP's with Helmert Transformation) residuals can be computed.

You also can detect a faulty scale factor due to displaced BP's or measurement errors, as such errors normally have an impact on a free scale factor.

Scle

to switch back

Pressing **Scle** again sets the scale free and the adjustment will be computed again.

#### **Configuration of Free Stationing**

2

Cfg Configuration Free Stationing Setting of standard deviations for both observations and centring define the weighting within the SP-A.

| 9211 Free Stationing  |  |   |  |
|---|--|---|--|
| Adjustment Type<br>Stand. Deviation<br>Error Limits<br>Adjustment<br>Reductions |  | 6 |  |

Configuration menu Free Stationing.

Stand. Deviation

92112 Single Point Adjust.

| Orientation        | : | 0.0003 | gon |
|--------------------|---|--------|-----|
| Distances constant | : | 0.003  | _   |
| Distances linear   | : | 0      | ppm |
| Levelling          | : | 0.000  | m   |
|                    |   |        |     |

Default values are given as below:

Accuracy of directions:

| Directions: | 0.0003 gon |
|-------------|------------|
|             |            |

Accuracy of distances:

| Di | stance                | e, const | tant: | 0.001 m |  |
|----|-----------------------|----------|-------|---------|--|
| Di | stance                | e, linea | r:    | 0 ppm   |  |
| Ac | Accuracy of centring: |          |       |         |  |
| -  |                       |          |       |         |  |

Centring of target: 0.000 m

#### ൙ Tip

When you enter 0.0, the appropriate parameter has no impact on weighting.

The weights are used for the SP-A only, but not for the Helmert Transformation.

| Cfg<br>Adjustr | Configuration<br>Free Stationing<br>nent Type 1 | SP-A or the Heli  | as a standard, whether to use the<br><b>mert Transformation</b> and also<br>e a <b>fixed</b> or a <b>free</b> scale factor. |
|----------------|---|---|---|
|                |   |   | tation. Adjustment Type<br>: Single Point Adjustment  |
|                |   | Change  | : On  |
|                |   | Scale<br>Change   | : free<br>: On  |
|                |   | Select with   | , confirm with 🖵 .  |
|                |   |   | , you cannot change between differ-<br>ustments in your stationing.   |
| Error L        | imits 3   |   | ange error limits, without necessar-<br>your stationing process.  |
|                |   | 92113 Free S  | tat. Error Limits   |
|                |   | Linear Dev.<br>Angle Dev.<br>Orthog. Dev.<br>Lateral Dev. | s=fix s=free<br>vr 0.0210 0.030 m<br>va 0.0050 0.0050 gon<br>vq 0.030 0.020 m<br>v1 0.030 0.020 m                           |
|                |   | Select with 🚺   | , confirm with .  |
|                | <b>Configuration</b><br>Instrument<br>Switch    |   | will only be used, if the switch <b>Error</b><br><b>On</b> within the configuration menu.                                   |
| Scale R        | ange 6  | Defining the rar<br>only be accepte                       | nge within which a scale factor will<br>d.  |
|                |   | The scale factor ing process.                             | might change within the station-  |
|                |   | 92116 Statio  | ning Scale range  |
| £ -            | 9999≤ SR ≤ 9999                                 | Scale Range   | :±  1 <u>300</u> ррм  |
|                |   | 0.998500 < s <  | 0 ppm would accept scale factors of<br>< 1.001500 as a result of the station-<br>nces of 100 m you would accept<br>0.15 m.  |

#### **Neighbourhood principle and Distance Reductions**

Л

5

| Cfg        | Configuration<br>Free Stationing |  |  |
|------------|----------------------------------|--|--|
| Adjustment |                                  |  |  |

| 92114 \$ | Stationing A | )dj | ustment                |
|----------|--------------|-----|------------------------|
| Mode     |              | :   | Weight by distance     |
| Weight   | exponent n   | :   | 2.0 p=1/D <sup>n</sup> |
| Mode:    | Off          | /   | Distance weights       |
| n:       | 0.5          | /   | 1 / 1.5 / 2            |

The residuals for all BP's of stationing will proportionally be spread over the coordinate space for all detail points and set out points, in order to comply to the socalled neighbourhood principle.

#### Reductions

Measured distances can be corrected for projections into the Gauss-Krueger or the UTM system. They can also be corrected by a reduction from the site height to the mean sea level. The residuals are spread according to distance dependent weights, which are applied to a weighted average. So the coordinates of any new measured point are corrected by that individually averaged value.

#### 🕿 Tip

The higher the value of **n**, the smaller the impact of a far distanced BP.

| 92115 Reductions |   |              |  |  |
|------------------|---|--------------|--|--|
| Height           | : | On           |  |  |
| Projection       | : | Gauss-Kruger |  |  |

### Height : On / Off Projection: Gauss-Krueger / UTM / Off


If distance reductions are applied, they are used additionally to the existing scale factor **s**. In that case the scale factor **s** only represents tensions of the BP network and uncertainties in the measurements.

#### Attention!

Make sure that the Reductions are set ON or OFF during both Stationing and on-board coordinate computations!

#### **Error Handling**

If at the end of your stationing error limits are exceeded for any BP, you will find that BP marked by **e** in column 1 and see the message:



If the pre-set range for the scale factor is exceeded, the following display appears:

| Error Free Stationing<br>Scale range exceeded ! |                        |  |
|---|------------------------|--|
| Cancel  | Stationing ?<br>Yes No |  |
| Yes Stationing is cancelled.                    |                        |  |

No Return to displaying the residuals. Solve the problem or extend the acceptance range for the scale.

In case of a SP-A with directions measured only to 3 BP's, the software checks the standpoint and the 3 BP's not to be approximately located on a circle (no solution possible).

### Attention!


If stand point and 3 BP's are on a circle and only directions are measured, there is a warning.

You can solve the problem by at least 1 additional distance measurement.

#### Heightstationing

After 2D stationing, a height stationing can be carried out using the BP measurements. At least one BP must have a known height value that was measured.

If no BP has a height value, it is possible to carry out a separate heightstationing from the stationing menu.



The results of the Free Station will be 2D.

- Yes The height of the Free Station will be calculated from the BP measurements and the programs goes into the adjustment menu of the height stationing.
- Heightstationing

If it is not possible to compute the height from the measured points of the planimetric stationing, then a normal Heightstationing follows.

After Heightstationing the final stationing result will be displayed:

| 417 Stationi                                     |   |  |  |
|--|---|--|--|
| s 0.999963<br>ih 1.650 m                         | Y 3398809.264 m<br>X 5589314.299 m<br>Z 111.435 m |  |  |
| 1000 Free Station<br><pnr>(Info&gt; Yes No</pnr> |   |  |  |

#### Attention!




The complete stationing (plane stationing as well) will be ignored.


Yes

Free Stationing results will be stored.

#### **Results of the Free Stationing**

**Esc** to exit the Free Stationing program:





Yes If the results of the Free Station are okay, then it is possible to go exit to the results display.

Error Handling
The program will check the computed residuals against the error limits set in the Configuration.

#### **Results Display**

| 417 Stationi             |  |        |
|--------------------------|--|--------|
| s 0.999942<br>ih 1.750 m | Y 470631.745 m<br>X 1088033.971 m<br>Z 490.745 m |        |
| 113 12 1962              | Free Station                                     | Yes No |

Results Display of the Free Stationing in 3D.

- Yes to record the results and use the coordinate orientation.
- No Cancel the results of the Free Stationing without saving.


### **Stationing on a Known Point**

4

2



By measuring up to a maximum of 20 Backsight Points from a known coordinate, it is possible to achieve position and orientation of the instrument within a coordinate system.




The circle orientation shift **Om** and the scale factor **s** will be computed.

If no height coordinate is available for the known point, it is possible to compute a Heightstationing.

### **Selecting Known Station**

Coordinate points are filtered into the editor ready for selection:



If the required station is not in the file, it is possible to manually enter the data into the editor. Select the known point with 💶 .

| 422 Station  |  |   | Adr: | 259 |  |
|--|--|---|------|-----|--|
| s 1.000000<br>ih <b>1.250</b> m  | Y 470631.740<br>X 1088033.970<br>Z 349.740 | m |      |     |  |
| 8 0429 4032 Known Station<br><pnr><info><br/>Edit Info Mark Code 5wtP</info></pnr> |  |   |      |     |  |

to input the instrument height **ih**. **I I** 

m see *Editor* for other functions

to confirm the station.

1 < BP < 20ø

Proj to select a point from another

Inpt


project to input a new

station coordinate

## **Stationing on a Known Point**

Orientation of the known station is through:

- (1) Backsight Points
- (2) Input of a horizontal angle value



A 4

#### **Orientation through Backsight Measurement**

| Backsight(s) 1 |                               | Select and measure up to 20 BPs from the Project:   |  |  |  |
|----------------|-------------------------------|---|--|--|--|
| m              | Free Stationing               | 424 Backsight 1 PROJNAME  |  |  |  |
|                | Measurement<br>Adjustment     | 1 9 2714 0077 Backsight Pnt<br>2 9 2714 0061 Backsight Pnt<br>3 7 0429 4022 Backsight Pnt<br>4 8 0429 4032 Known Station<br>25 8 0429 5077 Center Pnt Z |  |  |  |
|                |                               | Proj Inpt Edit Srch Adr. PNr Filt   |  |  |  |
|                |                               | Select with 🚺 🚺 and press 🚚.  |  |  |  |
|                |                               | If $BP = Station$ , comes the message:  |  |  |  |
|                |                               | 424     Backsight 1       Stat. Knwn. Pnt.       Stat. and point identical  |  |  |  |
|                |                               | Select New<br>Press any key to continue   |  |  |  |
|                |                               | Proj Inpt Srch Adr. PNr Filt  |  |  |  |
|                |                               | After measurement to the first BP, the Residual Screen will be shown.   |  |  |  |
| More           | Measure further<br>Backsights | The instrument will automatically turn to further BPs.  |  |  |  |
|                |                               | 426 Residuals L2 s = free   |  |  |  |
|                |                               | Nr. v1[m] va[gon] vq[m]<br>1 0.002 0.0004 0.001   |  |  |  |
|                |                               | 2 -0.002 -0.0020 -0.013<br>e 3 -0.007 0.0016 0.025  |  |  |  |
|                |                               | More ≛BP Del New Scle Rslt L1-A →2  |  |  |  |

Residual Screen. Softkeys similar Free Stationing.

If there is a distance measurement to one BP, a scale can be computed.

| Rslt | Results display                                    | 427 Stat. Knw  | n. Pnt.                    |           | s = free                      |
|------|--|--|----------------------------|-----------|-------------------------------|
|      |  |  |                            | X         | 470631.740 m<br>1088033.970 m |
|      |  | so 0.<br>ss 0.00   | 0010 gon<br>0005           | Om<br>S   | 392.5644 gon<br>0.999944      |
|      |  | Press any ke   | ey to co                   | ntinue    |                               |
|      |  | The display scree<br>Stationing and t  |                            |           |                               |
|      |  | Circle shift   | Om                         | (so)      |                               |
|      |  | Scale factor   | s                          | (ss)      |                               |
| Cfg  | Configuration of<br>Stationing on a<br>known point | 9212 Stat. on<br>Stand. Devia<br>Error Limits<br>Adjustment<br>Reductions<br>Scale Range | tion 1<br>2<br>3<br>4<br>5 | Point     |                               |
|      | <b>Configuration</b><br>Programs                   | The Configuration tioning.   | on is the s                | ame as th | at for Free Sta-              |

### Orientation through input and measurement of a bearing

| Input a Hz - Value 2                    | 4241 Measure Backsight  | Adr:      | 259        |
|---|---|-----------|------------|
| Input a bearing angle A <sub>Pi</sub> . | Hz 47.5578 son<br>8 0429 4022 Backsight Pnt<br><pnr><br/>R=M Inpt</pnr> |           | Ļ          |
|   | to input ,  to measure<br>Hz-Circle.                                    | and orie  | entate the |
|   | After orientation, the results of the displayed.                        | stationin | ig are     |

#### **Results of Stationing on a Known Point**

| Heightstationing                  | <b>Esc</b> from the residual screen to exit. If no height is known for the station, then the height-stationing routine will be automatically called. |
|-----------------------------------|--|
| Free Stationing<br>Error Handling | The program will check the stationing results against the set error limits.  |

| 417 Stationi | ng OK?   |
|--------------|--|
| ih 1.750 m   | Y 470631.740 m<br>X 1088033.970 m<br>Z 490.729 m |
| 8 0429 4032  | Known Station <mark>Yes No</mark>                |

Results display of a 3D Stationing of a known station point.

Check the results,


- Yes
  - to save the results, implement the orientation and exit the program.
  - No Leave the Stationing without saving the results.

## Heightstationing



The heightstationing is used in conjunction with a 2D stationing or as a separate menu program.

 $\varkappa$  1  $\leq$  BP  $\leq$  20



The Station height  $\mathbf{Z}_{\mathbf{s}}$  will be calculated from up to a maximum of 20 Backsightpoints.

All measurements are performed in the **SDHzV** mode, with scale factor s=1. After height-stationing the previously used scale factor is reactivated.




Enter station point ID and instrument height **ih** after selection in menu *Stationing*.

Continue with **C**. To be proceeded with Heightstationing in the same way as after any stationing in the x-y plane:

2 alternatives for Heightstationing:

- (1) Measure to BP's
- (2) Enter a height value



#### **Measurement and Adjustment**

1

1

2

2

#### Backsight(s)

Select BP with known height and measure.

- More to me BP's
  - to measure more BP's
- **•BP** Off / on to skip or to activate BP's in the adjustment.
- Cfg Configuration Heightstationing

Standard deviation

Define distance range for weight p = 1.

**Error limits** 

Define maximum deviation in height.

Selection of BP's and measurements to be performed the same way as in <u>Measurement</u> <u>Free Stationing</u>. After one BP being measured the display for residuals appears.

 $\sim$ 

| 445 Residuals L2     |           |
|----------------------|-----------|
| Nr.                  | vz[m]     |
| 1                    | 0.016     |
| e 2                  | -0.054    |
|                      |           |
|                      |           |
| More ±BP Del New Cfg | RSLT L1-A |

Display of residuals in Heightstationing. For analysis of the results use the same function keys as in Free Stationing.

Heightstationing uses the principle of a weighted average according to the predefined weights (set in Configuration).

| 92141                      | Heightstationing St                                   | and. Deviation |
|----------------------------|---|----------------|
| e : 🔳                      | 3] m Distance f                                       | or Weight 1    |
| Weight<br>Weight<br>If c = | for D > c : p = c<br>for D <= c : p = 1<br>0 : p = 1  | 2/D 2<br>/D 2  |
| Exam.:                     | up to 30 m distance<br>from 30 m distance or<br>c = 0 |                |

#### Entering a height value

Input of Height

You can manually enter the height of the station point. Then there is no measurement.

| Input | : Sta | ation | Height |
|-------|-------|-------|--------|
| Z 80. | 088   | m     |        |

After the height entry, Heightstationing is done.

#### **Results of the Heightstationing**

Rslt Show result of Heightstationing The height of your station and is standard deviation are displayed:

| 446 Hei | ghtstationing | 3      |           |
|---------|---------------|--------|-----------|
| sz      | 0.029 m       | z      | 490.745 m |
| Press   | any key to co | ontinu | e         |

**Esc** When pressed in the display of the residuals: Heightstationing is finished and the result is checked in accordance with the pre-set error limit for the actual deviation in height. That error limit to be previously defined in Configuration.

| 417 Stationi |               |        |
|--------------|---------------|--------|
| ih 1.750 m   | Z 490.745 m   |        |
| 8 0429 4032  | HeightStation | Yes No |

Check the results,

- Yes to save the results, implement the Heightstationing and exit the program.
- No Leave the Heightstationing without saving the results.


If Heightstationiong was previously called from a stationing in the x-y plane, the program automatically returns to that stationing menu, to show the overall stationing results.

### **Eccentric Stationing**



3

If the detail points and the set out points cannot be measured from a station on a known point, it is feasible to set up the station on an unknown point close to the known point (the so-called centre point).



 $\square \qquad 2 \le BP + CP \le 20$ 

all function keys

Free Stationing

please see

Measure directions  $\bigtriangleup$  to the BP's and combined distances and directions  $\checkmark$  to the centre point: With these data the coordinates of your station and the orientation **Om** of the horizontal circle are determined. Up to 20 BP's (including the centre point) can be measured.

Stationing in the x-y plane and Heightstationing are done separately. In case of Heightstationing, you have to input instrument height and prism height.



to confirm the entry of ecc. station

Then you can display the coordinates of the centre point in the editor:

 432 Center
 PROJNAME

 1 9 2714 0077
 Backsight Pnt

 2 9 2714 0061
 Backsight Pnt

 3 7 0429 4022
 Backsight Pnt

 4 8 0429 4032
 Backsight Pnt

 25 8 0429 5077
 Center Pnt Z

Select the centre point and press Enter.

#### **Measurement Eccentric Station**

A + A

| 4332                       | Meas.        | to Cen         | ter                         |                 | Adr: | 26 |
|----------------------------|--------------|----------------|-----------------------------|-----------------|------|----|
| Nr. 1<br>th                | ∣<br>1.650 m | SD<br>Hz<br>V1 | 7.010<br>38.1868<br>97.1310 | m<br>90n<br>90n | Ĵ ŀ^ | ſ  |
| 8 0429 5077 Center Pnt Z   |              |                |                             |                 |      |    |
| R-M Ecc. Inpt Code Srch →2 |              |                |                             |                 |      |    |

Measure SDHzV (Centre) by Contrel or PWR.

Then select and measure first BP in the measurement mode  $\bigtriangleup$  HzV:



Free Stationing Measurement Free Stationing

m

The display of the residuals is similar to the other types of stationing:

| 436 Res | iduals L2   |              | s = fixed    |
|---------|-------------|--------------|--------------|
| Nr.     | v1[m]       | va[gon]      | vq[m]        |
| 1       | 0.001       | 0.0000       | 0.000        |
| 23      |             | 0.0002       | 0.000        |
| 3       |             | 0.0003       | 0.002        |
|         |             |              |              |
| More    | : *BP Del N | lew Cfg Scle | Rslt L1-A →2 |

The adjustment is according to a weighted average.



More BP Measurements

| 436 Residuals L2   |  |  |  |  |
|--------------------|--|--|--|--|
| Backsigh<br>Center | t <b>and a state of the state of </b> |  |  |  |
| More ±BP D         | el New Cfg Scle Rslt L1-A →2   |  |  |  |
| Backsight pt.:     | Measure another BP   |  |  |  |
| Centre:            | Re-measure centre point<br>(optional).   |  |  |  |

## **Eccentric Stationing**

| Scle                 | Scale factor  | In Eccentric Stationing the scale factor <b>cannot be</b><br><b>free</b> . However, you can enter any fixed scale fac-<br>tor, as long as it is in accordance with the pre-<br>configured scale range.<br>Default: <b>s</b> = <b>1.000000</b>  |
|----------------------|---|--|
| Ω                    | all other function<br>keys please see<br><i>Free Stationing</i> | <ul> <li>Tip</li> <li>Do not locate the eccentric station point too far away from the centre point.</li> <li>A feasible distance is 10 m.</li> <li>For greater distances it is better to choose the regular Free Stationing, the centre point then being used as one of several BP's.</li> </ul> |
| □<br><u>sults of</u> | Free Stationing <u>Re-</u><br>Free <u>Stationing</u>            | The Eccentric Stationing concludes in the same way as Free Stationing. You can then proceed with Heightstationing, if required.  |

 417 Stationing OK?

 \$ 1.000000
 Y 470732.639 m

 ih
 1.750 m

 Z 426.880 m

 213 12 1962
 Ecc. Station

Display of the results of Eccentric Stationing and Heightstationing.

- Yes for storing the results and then finishing the Eccentric Stationing.
- No Leave Eccentric Stationing without recording the results.

After a stationing in a higher-order coordinate system the program *Coordinates* follows with the measurement of detail points or the setting-out of points in this coordinate system.

### **Detail Points**

### Setting Out


## **Detail Points**



Determination of the coordinates and heights of new points by distance and angle measurement in a higher-order coordinate system.

The actual stationing will be used by the Detail Point program (including the scale factor).

The program Detail Points is similar to the program Measure in a Local System.



| Mode | Selection of the |
|------|------------------|
|      | measuring mo     |

| 12→ |  |
|-----|--|
| 1   |  |
|     |  |

R-MC

Ш

е de YXZ

**Recording Mode:** 

R-M, R-C, R-MC

R-M, R-C, R-MC

Configuration

Instrument Switches

SD Hz V HD Hz h

R-M

| 51            | Detail A                                      | Points       |                                |                 | Adr: | 124 |  |  |
|---------------|---|--------------|--------------------------------|-----------------|------|-----|--|--|
| s<br>ih<br>th | 1.000000<br>1.750<br>1.650                    | m Hz<br>m V1 | 227.010<br>13.1262<br>101.1589 | m<br>90n<br>90n | j b  | ļ   |  |  |
| 76<br><       | 200034<br>PNr                                 | De           | tail Poin<br>Info              | t<br>->         | 8 -  |     |  |  |
| Mod           | Mode Rec IOff R-M Ecc. HidP Inpt Code Srch +2 |              |                                |                 |      |     |  |  |

or **PWR** to measure the point.

- R-M for original measured data
- R-C for computed data
- R-MC includes R-M and R-C

It is possible to record oriented (by stationing, see figure) or not-oriented Hz-directions. For coordinate computation oriented Hz-directions will be used.

5-2

## **Detail Points**


StCk Stationing Check, displays the actual Stationing.

| Stationing                               |   |  |
|--|---|--|
| s 1.000000<br>ih 1.750 m                 | Y 564423.233 m<br>X 403583.541 m<br>Z 130.576 m |  |
| 100558<br><pnr<br>Press any key</pnr<br> |   |  |

#### **Eccentric Measuring / Intersection**



Ecc. Eccentricity Intersection



| Indirect Survey |                |   |                               |  |  |  |
|-----------------|----------------|---|-------------------------------|--|--|--|
| 2. Dist         | Type<br>Method | : | Intersections<br>Angle ∕Dist. |  |  |  |
| 1. HzV          | Mode           |   | Once                          |  |  |  |

toggling between options.

- Type: Eccentricity
- Type: Intersection

Eccentricity

د Length L < 100 m

slope (in sighting axis)

to the Centre.

Reflector Offset:

right of


front of

S

Âs



behind



toggling between options.

| Mode <b>Once</b> for | one eccentric measurement, |
|----------------------|----------------------------|
|----------------------|----------------------------|

- Mode **Perm** for a permanent eccentricity,
- Mode **Off** to cancel.

Height **On** To use the height of the eccentric point in position left, right, front of or behind to the centre. The centre height is calculated for a slope eccenter.

**Off** no height coordinate.

Ecc. Int

Intersection


#### Method of measurement:



3

perpend.

general



## **Detail Points**

toggling between options.

| Mode | Once | for one eccentric measurement, |
|------|------|--------------------------------|
| Mode | Perm | for a permanent eccentricity,  |
| Mode | Off  | to cancel.                     |

### Attention!

If the height difference between the eccentric point in position left, right, front of or behind to the centre is large, then set the height to **Off.** 

The function **Ecc.** is not available during the Hidden Point Measurement.

# Detail Point

| Hidden Point Measureme | nt   | a i 🖄  |
|------------------------|--|--|
| HidP Call Hidden Point |  | R1<br>R2   |
|                        | rod poi  | e of the reflectors R1 and R2 on   |
|                        | Hidden Point   |  |
|                        | R1<br>R2<br>R2   | Mode : <mark>Permanent</mark><br>R2 - P : 1.115 m<br>R1 - R2 : 3.500 m<br>Tolerance : 0.003 m  |
|                        | Mode:  | similar to eccentric measure   |
|                        | Tolerance:   | permitted maximum value for accuracy of the R1-R2 distance.  |
|                        | Default value:   | 0.003 m  |
|                        | The program giv<br>bigger than peri                      | ves a hint, if the tolerance value is mitted.  |
| Recording Modes HidP:  | 51 Hidden Poi  | int: Refl R1 Adr: 166  |
| R-M<br>R-M, R-C, R-MC  | R1 2.510 m<br>ih 1.750 m<br>R2 0.655 m<br>100512<br>KPNr | SD 100.126 m<br>Hz 112.3468 son<br>∪1 101.4688 son<br>Channel No 5∎<br>-> <info></info>  |
| 🔛 R-M, R-C, R-MC       | Mode Rec Ion R   | R-MHidP Inpt Code Srch →2  |
|                        | and R2 by the h The height $Z_P$ wi                      | fines the order of measuring R1<br>elp of the display information.<br>Il be computed from the station<br>he instrument height <b>ih</b> and the<br>ce. |
|                        | Attention!   |  |

Be careful using AutoLock for hidden point measurement. Test first.

### **Detail Points**

#### **Object Height Measurement**




After measurement to a reference point with modes



SD Hz V HD Hz h YXZ

this function key is available.



 $\sim$ 

12→

+ 🗠

**.** 


The reference point defines the line Instrument-Reflector (I-R) and the vertical plane normal to I-R. Now it is possible, to measure object heights to points in that plane only by **HzV** angle measurement:

HD Horizontal distance I-R

Ο

Orthogonal dev. L-R (90° to I-R)

Object height to R (reference point) h



point measurement also possible.

| 51  | Measure     | Object         | Height                             | Adr: | 199 |
|-----|-------------|----------------|------------------------------------|------|-----|
|     |             | HD<br>O<br>h   | 113.692 m<br>18.173 m<br>9.961 m   | 2    | Ļ   |
|     | 0120<br>PNr | <br>0bj/<br>>< | ect heigh <mark>i</mark><br>−Info> | 184  |     |
| Mod | le Rec Iof  | Code           | +2                                 |      |     |

to measure object height + orthogonal deviation with 🛆

Mode is a switch between the display of HD O h and HD Hz h. Recording with Rec.

| HD | Horizontal distance Instrument - L |
|----|------------------------------------|
| h  | Object height to I (instrument )   |

Object height to I (instrument)

AutoLock will be automatically switched off

Mode

Switches the display of HD O h, Hz V, SD Hz V HD Hzh, YXZ

## **Detail Points**

#### **Connecting Distances**

- P→P The connecting distance to the last measured point will be computed.
- Rec To record the connecting distance

| 511 Connec             | Adr:                | 202                              |  |  |  |  |
|------------------------|---------------------|----------------------------------|--|--|--|--|
|                        | SD<br>HD<br>h       | 40.011 m<br>39.842 m<br>-3.681 m |  |  |  |  |
| <b>2</b> 29000<br>≺PNr | 29000 Conn.Distance |                                  |  |  |  |  |
| Rec                    |                     |                                  |  |  |  |  |

Press **Rec** to record the connecting distance.

or **Esc** back to the measuring menu without recording.

#### 2 Face Measurement

| í | La  |
|---|-----|
|   | - 2 |

2Lg

toggles between face 1 and face 2.

| 51                                      | Detail                       | Poi | ints           | Face | 1                    | Adr: | 460 |
|---|------------------------------|-----|----------------|------|----------------------|------|-----|
| s<br>ih<br>th                           | 1.000000<br>1.5800<br>1.5800 | m   | SD<br>Hz<br>V1 | 13.  | 0000<br>1134<br>0561 | 2    | ļ   |
| 123456 Face 1+2<br><pnr></pnr>          |                              |     |                |      |                      |      |     |
| StCk Del Edit →1 2Fce Mark SwtC SwtP →1 |                              |     |                |      |                      |      |     |

After measurement in face 1 the instrument turns automatically in face 2. After measuring in face 2 the instrument turns back to face 1.

#### Attention!

Using AutoLock is not possible.

Q

**Configuration** Programs General Functions 2-Face-Measurem. The measurement values and mean values of measurement in face 1 and face 2 will be computed and stored as defined in the program configuration. Srch

D:T

Rec

| Erro             | r           | Measure in 2 Faces<br>Limits Exceeded |                         |  |  |
|------------------|-------------|---------------------------------------|-------------------------|--|--|
| d 1<br>dHz<br>dV | =<br>=<br>= | 0.0000 m<br>0.0000 gon<br>-0.2400 gon |                         |  |  |
| Yes              | То          | accept and sa                         | ve the mean value.      |  |  |
| No               | No          | saving. New I                         | measurement is possible |  |  |

If the error limits are exceeded, comes

### **Distance and AutoLock with Tracking**

When in Measure or Detail Points use the following technique for faster topographic surveying:

- 1. Turn on AutoLock to Tracking
- 2. Turn on Distance Tracking to D:T
- 3. Use the **Rec** softkey to record the current displayed position



.++

If the prism is lost, the symbol for "Prism lost" appears in the display and the TrackLight turns on automatically helping to rebuilt the connection. The **Rec** softkey is locked for this time.

Setting the Search Window to Automatic Center ON the instrument aims close to the target direction after loosing contact.

### Attention!

If distance tracking is switched off by pressing **Esc** or **D:N**, the measure buffer will not be filled with new values and the **Rec** softkey stores the same (the last tracked) value again and again.

| _ |     |
|---|-----|
| 5 | _a  |
|   | - 3 |

in this mode does a precise measurement using the FineLock function. After then it comes back to the distance and FineLock tracking mode.

#### **Value Corrections**

| Configuration<br>Instrument      | The measured values will be subjected to the following corrections:   |
|----------------------------------|---|
|                                  | Influence of Temperature and Pressure (SD)  |
|                                  | manual setting  |
|                                  | Prism / Addition Constant (SD)  |
|                                  | Inclination of the Vertical Axis (HzV)  |
|                                  | • Horizontal Collimation + Vertical Index (HzV)   |
|                                  | • Trunnion axis (Hz)  |
|                                  | Circle Eccentricity (HzV)   |
|                                  | AutoLock / Tracker Corrections (HzV)  |
| <b>Configuration</b><br>Programs | The calculated values (HD, h, X, Y, Z) will be com-<br>puted from the corrected measured values and<br>are corrected by the following (selectable) influ-<br>ences: |
|                                  | Scale factor from stationing  |
|                                  | Projection reduction (Gauss-Krueger or UTM)   |
|                                  | Height reduction  |
|                                  | Refraction and earth curvature  |
|                                  | Best-fit Adjustment   |
| <b>Annex</b><br>Formulae         | The exact formulas are given in the annex.  |

# **Detail Points**

| SwtC | With this switch,<br>One can toggle the<br>various corrections<br><b>On</b> and <b>Off</b> . | 9133 Correction Switches<br>Tilt Compensation In<br>Atmospheric Corrections On                                 |
|------|--|--|
|      |  | Toggle with 📰 , Confirm with 🗔 .   |
| ļ    | Compensator <b>On</b>  | After switching on the instrument and adjustment of the compensator all corrections are switched to <b>On.</b> |
|      |  |  |

When the Compensator is switched on, the compensator symbol will be displayed.

## **Setting Out**


#### Coordinates


#### Setting Out

Setting-out of coordinate points.

The actual stationing will be used by the *Setting Out* program (including the scale factor).

The *TrackLight* of the Trimble 5600 is very useful for setting out points and will drastically reduce the time needed to set out a point.





Setting out menu.

Configuration Instrument Switches Reference System It is possible to record oriented (by stationing) or notoriented Hz-directions. For setting out parameter computation, oriented Hz-directions will be used.

#### **Rectangular Coordinates**

1

- Rectangular Coord.
  - ⇒ : S , P
     ⊕ : (SD, Hz, V)<sub>s-A</sub>
  - $\blacksquare$  : (dl, dq, dr)<sub>P-A</sub>
  - $\blacksquare$  : (ai, aq, ar)<sub>P-A</sub>

Setting out using coordinates Y, X, Z with orthogonal corrections dl, dq, dr or coordinate corrections dy, dx, dz. After the call-up there is a selection of the set out points supported by a coordinate filter from the project file.

# **Setting Out**

| Inpt<br>ordinat<br>Proj | to enter a co-<br>te<br>select another<br>project  | 520 Ca<br>18<br>20<br>21<br>22<br>Prot In   |
|-------------------------|--|---|
|                         | <b>Data Management</b><br>Editor   | Recall th<br>possible<br>input di   |
| Skip                    | Call up a new point<br>from project file<br>without saving the<br>last point meas-<br>urement.           | 521 Se<br>s 0.9<br>in<br>th<br>426000<br><f<br>NO<br/>After se<br/>set out</f<br> |
| *                       | with prism<br>tracking activated,<br>the instrument will<br>not turn<br>automatically to<br>the bearing. | At the store of the prise direction   |
| Nomi                    | to realign the direc-<br>tion of the Trimble<br>5600 to the re-<br>quired nominal di-<br>rection.        | The Se  |

| 520 Call Set Out       | Point              | PROJECT |
|------------------------|--------------------|---------|
| 18 142278              | Set Out            |         |
| 19 142279<br>20 142280 | Set Out<br>Set Out |         |
| 21 142281<br>22 142282 | Set Out<br>Set Out |         |
|                        |                    |         |
| Proj Inpt Edit:        | Srch Adr. PNr      | Filt    |

Recall the set out point from the project data. It is possible to recall points from another project, or input directly.

| 521 Setting   | Adr:                             | 1277  |        |  |  |
|---|----------------------------------|-------|--------|--|--|
| s 0.999963<br>ih 1.650 m<br>th 1.730 m  | HD 65.378 m<br>da 0.0000 gon     | J 17  | Ļ      |  |  |
| 426000<br><pnr< th=""><th>Set Out Poin<br/>-&gt;<info></info></th><th>¦₿ ≌→</th><th>★<br/>☆</th></pnr<> | Set Out Poin<br>-> <info></info> | ¦₿ ≌→ | ★<br>☆ |  |  |
| Nomi Plot R-C Skip D:N Inpt Code Srch →2  |                                  |       |        |  |  |

After selection the direction and distance to the set out point is displayed.

At the same time, the motors turn the instrument to the correct bearing and vertical angle.

The prism should be aligned to the telescope direction.

measure the position of the prism and displays the setting out screen.

#### The Setting Out screen



Esc to save the set out coordinates and to select another point e.g. from another project file.

Pressing Mode will display other values:

# Setting Out

| Mode            | Selection of<br>misclosures:<br>dl, dq, dr or                 | dl, dq, dr   | length, cross, and radial<br>misclosures                            |  |
|-----------------|---|--|---|--|
|                 | dy, dx, dz  | dy, dx, dz   | coordinate differences  |  |
|                 |   | HD   | Horizontal Distance   |  |
|                 |   | da   | Angle misclosure  |  |
|                 |   |  | for a set out point are exceeded,<br>will show a star as a warning. |  |
|                 |   | Setting out wi   | th AutoLock in Tracking   |  |
| ·* <sup>#</sup> | AutoLock-Tracking   | Using AutoLock and Distance Tracking together provides the fastest solution.   |   |  |
| D:T<br>D:N      | distance :tracking<br>distance:normal                         | The distance softkey is used to turn the distance tracking on and off.   |   |  |
|                 |   | 5  | e set out point is only possible<br>istance measurement             |  |
| Srch            | AutoLock modes  | A single measure   | ement is activated with   |  |
|                 |   | ← OrPWR.   |   |  |
| R-MC            | Record mode   | Recording  |   |  |
|                 | <b>Configuration</b><br>Program<br>Coordinates<br>Setting Out | The recording mode is set within the Configura-<br>tion <i>Coordinates Setting Out</i> , but can be toggled<br>using the softkey <b>R-M</b> , <b>R-C</b> , <b>R-MC</b> . |   |  |

Before recording, the error in the setting out is compared with the error limits set in the configuration.

If the error limits are exceeded:

| Error                | Setting Out<br>Error limits exceeded! |  |  |  |
|----------------------|---------------------------------------|--|--|--|
| Repeat Measurement ? |                                       |  |  |  |
|                      | Yes No                                |  |  |  |
| Yes                  | to repeat the measurement.            |  |  |  |
| No                   | Record and call the next point.       |  |  |  |

Zooming the dl, dq

display.

| 522 Settin   | ig Out   |       | Adr:      | 124          |
|--|--|-------|-----------|--------------|
| dl   | -0.387   | м     |           | 1            |
| dq   | -1.930   | м     |           | Ŷ            |
| 37701  | Set out  | Point | İ∣⊟ ≌→    |              |
| <pnr< td=""><td>&gt;<infa< td=""><td>&gt;</td><td></td><td></td></infa<></td></pnr<> | > <infa< td=""><td>&gt;</td><td></td><td></td></infa<> | >     |           |              |
| Mode PL  | ot R-MR  | Inpt  | Code Srck | 1 <b>→</b> 2 |

Press **Plot** again for normal viewing.

### **Station Check**

Plot

Stat. Check3This is used to check that the correct station coordinates are occupied, and that the orientation of the circle is correct for the coordinate system.

| Stationing  |   |  |  |  |  |
|---|---|--|--|--|--|
| s 1.000000<br>ih 1.750 m  | Y 564423.233 m<br>X 403583.541 m<br>Z 130.576 m |  |  |  |  |
| 100558 Free Station<br><pnr><info><br/>Press any key to continue</info></pnr> |   |  |  |  |  |

# 5-16

This chapter describes advanced applications in the daily surveyor's practical work. This applications are implemented in the menu *Coordinates* and *Special* of the Geodimeter® software.

Point-to-Line Distance


# **Point-to-Line Distance**


6

2



Determination of Point-to-Line distances. The line is defined by angle and distance measurement of two points or the recall of these points from the project file.






Survey by quasi-perpendiculars, staking out of points or profiles orthogonal to a line can be done by the help of this measuring method.

The line defining points  $P_1$  and  $P_2$  can be measured from a free selectable Station S.

For the point measuring  $P_i$  orthogonal to the line in a local system the x-axis will be defined by  $P_1 P_2$ with  $P_1$  as the coordinate origin.

The heights refer to line point  $P_1$  with height z=0 or a heightstationing.

Selection of measuring in a local system or a coordinate system.



| Measu   | Measuring in a local system 🕢 🖾  |   |  |  |  |  |
|---------|--|---|--|--|--|--|
| Local S | Local System       1         6111 Measure Point P1       Adr: 2         Point to Line       Inc         ih       Loading the last line?         in       Inc         Ves       No         Kocel Rec Ford Raw Eccel Line?       Secel State         The last measured line and their coordinates we be loaded by the program. |   |  |  |  |  |
|         |  | No Program goes further with.   |  |  |  |  |
|         |  | Line measuring:   |  |  |  |  |
|         |  | 6111 Measure Point P1     Adr: 225       \$ 0.999944     SD 257.235 m       ih 1.750 m     Hz 24.1245 son       th 1.650 m     U1 100.0368 son       1001     Line Point 1 <pnr>&lt;<info></info></pnr>   |  |  |  |  |
| Zon     | Switch on and se-<br>lect the height ref-<br>erence  | The height reference for defining the line can be selected by the Softkey <b>Zon</b> :  |  |  |  |  |
|         |  | <ol> <li>Height from P<sub>1</sub></li> <li>Height from heightstationing</li> </ol>   |  |  |  |  |
|         |  | <ol> <li>No height (<b>Zoff</b>)</li> </ol>   |  |  |  |  |
| Zoff    | No height  | If no other height reference is defined, the height from $\mathbf{P_1}$ is default  |  |  |  |  |
|         |  | or <b>PWR</b> to measure line point <b>P</b> <sub>1</sub>   |  |  |  |  |
|         |  | 6112 Measure Point P2Adr: 227 $s$ 0.999944 $BZ$ 2277.255 m $in$ 1.750 m $HZ$ 124.455 son $th$ 1.650 m $U1$ 100.0038 son $1002$ Line Point 2 $C = -PNr Nr = - Nr = CoccFIREL CodeModeRecForthCodeFreite2ModeRecforthR = MEccFIREL CodeR = MEccFIREL CodeR = MecceccR = MeccR = MeccR = MeccR = N = CocceccR = N = CoccceccR = N = CoccceccR = N = CocccceccR = N = Coccccccccccccccccccccccccccccccccccc$ |  |  |  |  |

If  $\mathbf{P_1}$  and  $\mathbf{P_2}$  are identical, a message appears in the program.

# **Point-to-Line Distance**

New

New line

measuring

| 611 | 3 Result |          |                        |   | s | = | fixed |
|-----|----------|----------|------------------------|---|---|---|-------|
| s   | 1.000000 | X1<br>X2 | 0.000 m<br>219.764 m   |   |   |   |       |
| ds  | 0.002 m  | s s      | 219.764 m<br>219.764 m |   |   |   |       |
| <   | PNr      |          | ne P1 P2<br>InfoX      | > |   |   |       |
|     |          |          | New                    | T |   | S | tCK   |

Result of the measured line  $P_1 P_2$ . The x-axis is defined by both points with point  $P_1$  as the coordinate origin.



Accept the line measurement.

StCk


Station check

To check the station coordinates referring to the coordinate system defined by the line.

| Stationing               |   |  |
|--------------------------|---|--|
| s 0.999944<br>ih 1.750 m | Y 51.194 m<br>X 21.614 m<br>Z 1.087 m       |  |
|                          | Station<br>-> <info><br/>to continue</info> |  |

#### Point-to-Line distance measurement

After defining the line, point  $P_i$  measuring can be done. The orthogonal position and the line distance of the points (y<sub>i</sub>, x<sub>i</sub>) to the line  $P_1 P_2$  will be computed:



#### Measuring in a coordinate system

2

#### **Coordinate System**


A stationing must be done before measuring poin-toline distances in a coordinate system. The program starts similar to the local system. You will be asked whether or not you wish to use the last line.

#### Line definition

can be done by

- Measuring both line points (similar to the local system),
- Call-up of both points from project file,
- Combination between measuring and call-up for both points.

In case of a new line definition the program leads automatically to the call-up (**Edit**) for the first point  $P_1$ :




call-up the point **P**<sub>1</sub> from project file

or

Edit Back to ca

Back to the Editor to call-up the line point from project file

**Esc** goes to the measurement menu:



Or PWR to measure line point P<sub>1</sub>

Measuring or calling-up of the second line points leads to the result display:

# **Point-to-Line Distance**

Station check

s Length of line

StCk

| 612 | 3 Result |                   |           | s | = | fixed |
|-----|----------|-------------------|-----------|---|---|-------|
| s   | 1.000000 | X1                | 0.000 m   |   |   |       |
|     |          | X2                | 219.764 m |   |   |       |
| dS  | 0.002 m  | s                 | 219.764 m |   |   |       |
| <   | PNr      | ne P1 P2<br>Info> |           |   |   |       |
|     | New      |                   |           |   |   | tCK   |

The local Station coordinates referring to coordinate system defined by the line will be displayed (not the higher-order coordinates):

| Stationing               |  |  |  |  |  |
|--------------------------|--|--|--|--|--|
| s 0.999944<br>ih 1.750 m | Y 151.194 m<br>X 121.614 m                           |  |  |  |  |
|                          | Station<br><pnr><br/>Press any key to continue</pnr> |  |  |  |  |

Display of the station coordinates.

|   | <b>Configuration</b><br>Programs<br>Special<br>Point to Line | Tip<br>To activate recording Grid Coordinates,<br>switch On in the Configuration of Instru-<br>ments.      |
|---|--|--|
| Q | Point-to-Line<br>Distance<br>Local System                    | <b>Point-to-Line distance measurement</b><br>The measurement is similar to measuring in a local<br>system. |

This chapter describes the entry, transfer and storage of data.

Editor

Data Transfer

Data Format

PCMCIA Card Data Memory

#### Editor

For the entry of point information and coordinates.

7

Display and editing of the project file using selectable output filters.

| 7 Editor               | PROJECT |
|------------------------|---------|
| 1 37701                | BP1     |
| 2 37700                | BP2     |
| 3 37089                | BP3     |
| 4 37103                | BP4     |
| 5 FREE STATIO          | NING    |
| Proj Inot Del Edit Sro |         |

The editor menu displays the addresses of the current project file and their contents in an abbreviated form (27 PI characters).

If an output filter has been set, this is indicated in the menu title bar.

#### Keys frequently used in the editor

|                  | $\rightarrow$    | Up and down cursor keys                     |
|------------------|------------------|---|
| PgU <sup>p</sup> | PgD <sub>n</sub> | Scrolling the display by four address items |
| Home             | End              | Jump to the first and last<br>addresses     |
|                  |                  | Navigating between input fields             |
|                  |                  | Recording entries                           |
| Esc              |                  | Quitting the editor                         |

## Quitting an input menu (Inpt, Edit)

**Esc** Quitting the current input menu. If any entries made have not been saved with

the following enquiry appears:

|      | nput 0dr · 87                |
|------|------------------------------|
| A    | )pply Changes ?              |
| 123  | Yes No                       |
| Mode | Ioff Info Mark Code          |
| Yes  | The change (entry) is saved. |
| No   | The change is not saved.     |

# Entering a data record

| Inpt        | Editor input menu   | 72 Inp  | Y         224560.124 m           X         523587.359 m           Z         -9999.000 m           Nr>         Info           Info         Merza Gode |  |  |
|-------------|---|---|--|--|--|
|             |   |   | Coordinates<br>Directions and distances  |  |  |
| Mode<br>t2→ | Switching between<br>the entry of<br>Y X Z / y x z<br>SD Hz V | differen  | <b>bde</b> button permits you to switch between<br>it input modes (corresponding to the<br>ing modes).   |  |  |
|             | HD Hz h   | Attention!  |  |  |  |
| Ioff        | Incrementation<br>for the entry <b>off</b>                    | In the YXZ mode, you have to enter the value <b>Z=-9999.000</b> m for points of unknown height. The height <b>Z=0.000 m</b> is considered to be a known height and is used as such by the programs. |  |  |  |
| Ion         | Incrementation<br>for the entry <b>on</b>                     |   |  |  |  |
| Mark        | Changing the<br>marking                                       |   |  |  |  |
| Code        | Calling the code-   | Record  | ling the entry   |  |  |
|             | list<br>Measurement in a<br>local System                      | The data line entered is saved at the end of the<br>current project file at the address displayed in the<br>address window.   |  |  |  |
|             | Use of codelists  |   | For recording.   |  |  |
|             |   |   | The line entered remains available in the display and can be edited for the next input line.   |  |  |
|             |   |   | The memory address for the next input line is incremented by 1.  |  |  |
|             |   | Esc   | Quitting the input menu.   |  |  |

## Editing a data record

| 74 Edit     Adr:       X     #4545265672921 m       X     5460475.3866 m       Z     270.5473 m       201709     KT71 <pnr></pnr>  |                                 |
|--|---------------------------------|
| Mark       Changing the marking         Code       Calling the code list         Only coordinates or values defined by input or be edited here in the displayed input mode. In all measured data cannot be edited.         PgUP       PgDD         Selecting further records for dising and (if possible) editing.         If you select a record to which attributes such headers, scale, ih, project info line etc. have be assigned by the program, the record is display and the PI can be edited using Edit: <b>74</b> Edit       Edit         It is is a Project Info Line         Display of an attribute line (e.g Info Line).         Save and Quitting the display | Origi-<br>play-<br>n as<br>peen |
| Recording<br>a recordThe edited record is saved without the need<br>quit the editing function. The same address i<br>project data file is used for saving.   |                                 |
| SrchSearch for recordSearching for a record or addressAdr.or addressImage: Contract or address   |                                 |

#### **Filtering of records**

Filt

Setting an output filter

For data transfer or deletion, it is often advisable to define a filter by combining several optional criteria. Only the relevant records are then displayed for further use in the editor.

| 79 Filter                                  |       | PROJECT |
|--|-------|---------|
| Mode:<br>All                               | from: |         |
| 2???????????<br><pnr<br>Mode R5et</pnr<br> | Code  |         |

Menu for the generation of filters. The filter currently selected is displayed. If no filter has been set, the input fields are blank.

#### **Filter options**

- Point identification (text or code blocks)
- Addresses from to
- Point numbers from to
- Attributes of values (Y-X-Z, SD Hz V, etc.)
- Combinations of these options

## **Filter effect**

- If the PI is used for filtering, only the records with the selected marking are filtered.
- If other criteria are used for filtering, the filter applies to all markings
- With a combination of PI + other criteria, the selected marking applies.

## Setting a filter

Press is to activate the selected filter. After that, the filtered brief display appears again. The active filter is shown in the menu bar:

| 7 Editor Filter Pl    | 1 / Y-X-Z   | PROJECT      |
|-----------------------|-------------|--------------|
| 7 37701               | BP1         |              |
| 8 37700<br>12 37701   | BP2<br>BP1  |              |
| 13 37700              | BP2         |              |
| 16 37103              | BP4         |              |
| Proj Inpt Del Edit Sr | ch Adr. PNr | Repl Filt →2 |


| RSet                    | Resetting an out-<br>put filter                 | Resetting a filter         IPR0.1FCT         Mode         Mode         Yes         Mode         Yes         All the data of a project is displayed.  |
|-------------------------|---|--|
| Mark                    | Activating or<br>changing the<br>marking        | <b>Point identification filter</b><br>Select <b>Mark</b> to activate the current marking or to<br>change to a different marking.   |
| Code                    | Filtering acc. to<br>coding with code-<br>lists | If the marking defines code blocks, you can select<br>these as filter attributes using <b>Code</b> .<br><b>PROJECT</b> Mode:       PROJECT         Mode:       Project <tr< th=""></tr<> |
| A→A                     | Address filter                                  | Filtering according to address ranges<br>Set an output filter from address i to address j.   |
| Default<br>from:<br>to: | address range:<br>first address<br>last address | 79 Filter       PROJECT         Mode:       Adress         A11       from:       11         88       88         ????????????????????????????????????   |



Point number filter

#### Filtering according to point number ranges

Set an output filter from point number i to point number j.



Example: Filtering of the point numbers **8000** to **8015** for data records which include the data attributes Y X Z for the **selected marking**.

Filtering according to point numbers is independent of the marking, unless PI is used as a filter criterion at the same time.

Other in-between records containing information (headers, text lines, etc.) are omitted.

| Filtering | according | to data | attributes | s |
|-----------|-----------|---------|------------|---|

By default, all data attributes are accepted for filtering. The **Mode** input field shows **All** in this case.

| 79 Filter   |   | PROJECT |
|-------------|---|---------|
| Mode :      | _                                       |         |
| Y-X-Z       | from                                    |         |
| 10105222222 | 777777777777777777777777777777777777777 |         |
|             | -> <info></info>                        |         |
| Mode RSet   | P+P A+A Mark                            | Code    |

The **Mode** softkey permits you to filter out the following 11 data combinations:

All / SD-Hz-V / Hz-V / HD-Hz-h / y-x-z / y-x-? / ?-?-z / Y-X-Z / Y-X-? / ?-?-Z / HD-O-h

👁 Tip

In this way, you can simulate coordinate files or measured data files, for example.

Mode

Filtering acc. to data attributes

is like a wildcard

?

## Searching for data records

| Srch | Calling up search         | 75 Searches  | PROJECT                                  |  |
|------|---------------------------|--|--|--|
| _    | 5 1                       | ????850 Buil Cor 2?? ??????<br>pppppp Obje Frm Def <info<br>?*</info<br>   |  |  |
|      |                           | Mask-oriented search for data lines according to different criteria. The output filter currently se-lected is effective.                         |  |  |
|      |                           | Search options: Point number<br>Code or text<br>Time (if incl. in<br>Combination of  |  |  |
|      |                           | To enter the search criterion, proc<br>way as for the setting of a PI filter   |  |  |
|      |                           | If you have searched for a mask before, this mask is offered for editing or for continued search.  |  |  |
|      |                           | 🖝 Tip  |  |  |
|      |                           | The search is only made in records with the selected marking.  |  |  |
|      |                           | The placeholders "?" in the mask<br>use of any character for the sear<br>search is necessary in the Pl posi<br>be retained. Entered blanks are s | ch, i.e. if no<br>tion, " <b>?</b> " can |  |
| Mark | Changing the Mark-<br>ing | When you select a different marki<br>mask is deleted. The layout of the<br>is automatically adapted to the ne                                    | placeholders "?"                         |  |
| Code | Calling the Code-<br>list | If code fields have been defined in<br>marking, you can search the code<br>ciated codelist.  |  |  |

?**↓** 

Search to file end

Search to file beginning Starts the search.

The search starts at the current address and continues downwards to the file end. You can use the up and down keys ? $\checkmark$  and ? $\uparrow$  to change the search direction. If the search is not successful, the following message is displayed:

| Error Editor Search<br>Not Found ! |                                 |  |
|------------------------------------|---------------------------------|--|
|                                    | Cor ??? ?????<br>Frm Def 〈Info〉 |  |
| Press any key to                   | continue                        |  |

If the search is successful, the cursor moves to the relevant record in the editor brief display.

#### 🕿 Tip

Searching for PI in a large project file, it helps to save time if you start the search from an address near the PI required.

Adr

Search for/calling up addresses

| Call                                 | PROJECT               |
|--------------------------------------|-----------------------|
| Address <b>78</b>                    | 20<br>20              |
| 34 Std Dev. befo<br>35 Std Dev. befo | ore Adjust.           |
| Proj Inpt Del Edit Srch              | Adr. PNr Repl Filt →2 |

Enter:  $1 \le \text{address} \le n$ (n=last address used)

The last address **n** of the project file is always displayed by default.

The start and result of the search correspond to those of the **Srch** function. The output filter currently selected is effective.

| PNr           | Search for/calling | 1   | Call   |   | PROJECT      |  |  |
|---------------|--------------------|-----|--|---|--------------|--|--|
|               | up point number    |     | Point  | t number <b>2056</b>  | ree          |  |  |
|               |                    |     |  | 35 Std Dev. before Adjust.  |              |  |  |
|               |                    |     | Proj In  | pt Del Edit Srch Adr. PNr   | Repl Filt →2 |  |  |
|               |                    |     | Enter:   | Point number  |              |  |  |
|               |                    |     | those o  | rt and result of the search of<br>f the <b>Srch</b> function. The ou<br>elected is effective. | •            |  |  |
|               |                    |     | 🖛 Tip  | )   |              |  |  |
|               |                    |     | The search for an address and point number<br>is made irrespective of the marking. The<br>markings PI1, PI2 etc. used in the project file<br>must be configured in the instrument. |   |              |  |  |
| Repl<br>place | Search and re-     | re- |  | nches<br>????????Point D??????<br>PNr>  |              |  |  |
|               |                    |     |  | ??????????Point F2?????<br>?Nr> <info></info>   | Code         |  |  |
|               |                    |     |  | riented search for and repla<br>the same way as in the <b>Src</b> l                           |              |  |  |
|               |                    |     | Enter:   | Search mask (-string)<br>Replacement mask (-string  | g)           |  |  |
|               |                    |     |  | To entry of the replaceme   | nt string    |  |  |
|               |                    |     |  | Start search / replace  |              |  |  |
|               |                    |     | ?↓   | Search direction  |              |  |  |
|               |                    |     | Confirm  | nation of replacement:  |              |  |  |
|               |                    |     | 78 Sa=<br>400 Re   | erches<br>2place  | ]            |  |  |
|               |                    |     |  | ith Confirmation?   | es No        |  |  |
|               |                    |     | ·  |   | Code         |  |  |

- No The new string without prior enquiry replaces all strings conforming to the search criterion.
- Yes Each replacement is preceded by an enquiry, with a display of the data line found:

| 751 Replace?   | Adr:   | 288 |
|--|--------|-----|
|  | Yes No |     |
| 9600 Free StInt<br><pnr><info< td=""><td>-&gt;</td><td></td></info<></pnr> | ->     |     |
| КРМXIIII0  | -/     |     |

Yes The displayed data line is replaced by the new line.


No No replacement, search is continued.

After completion of the search / replacement, the result is displayed:

| Search and Replace |                    |  |  |
|--------------------|--------------------|--|--|
| 11                 | Lines Found!       |  |  |
| Press any          | ny key to continue |  |  |

#### **Deleting data records**

Del Deletes data records This function deletes the data line marked by cursor in the project file:





If an output filter is set, this function deletes all records set in the current output filter:

7 Editor PRD.TECT Delete
Delete all data in filter?
Ves No
Proj Inpl Del Edit Bren Adr. PNr Rept Filt +2




All records in the current output filter are deleted.

The current output filter is then reset, and all undeleted data of the project file is displayed again.



No deletion, return to the editor menu

After deletion, the data memory can be reorganised in the same way as by the **OrgP** function:



Caution! This deletes the data for good!

No No data memory reorganisation. Attention! Gaps in the addresses! But the data remains available in the project file!

Attention!

Only the reorganisation of the data memory will physically delete the selected records in the project file. If this process has not yet been started, you can reactivate the address ranges selected for deletion by using an external editor and replacing the delete identifier "~" in column 119 of the record by a blank. Please note, however, that the record length of 121 bytes (characters) must not be exceeded!


Data recovery after deletion?

Yes, but be careful when using external editors !

After the deletion of records, you return to the editor menu (brief display).

## **Further function keys**

| Proj | Project change                  | You can change the current project without hav-<br>ing to quit the editor. When you quit the editor,<br>the project originally selected is reloaded. |   |   |
|------|---------------------------------|--|---|---|
| OrgP | Data memory reor-<br>ganisation | Reorganise<br>ject.  | es the data memory in th  | e current pro-                          |
|      |                                 | without su   | n is available if data has k<br>bsequent memory reorg<br>gaps therefore exist in th | anisation, and                          |
|      |                                 |  | Reorganization<br>t Reorganization ?  |   |
|      |                                 |  |   | Or9P →1                                 |
|      |                                 | Ca   | ata memory reorganisati<br>aution! This deletes tl<br>ood!                          |   |
|      |                                 | tion! Gaps   | o data memory reorgani<br>in the addresses! But<br>lable in the project             | sation. Atten-<br>the data re-<br>file! |



**Data Transfer** 

Cable for data transfer using the Xon/Xoff protocol:

8

Elta CU  $\leftrightarrow$  PC Cable: plus PC adapter Cat. No. PC Cable 571 202 188 PC adapter 571 202 204

| 8 Data Transfer               | PROJECT          |
|-------------------------------|------------------|
| Send Data 1<br>Receive Data 2 | Remote Control 6 |

Data transfer between Elta CU and PC.

## Elta CU $\Theta$ PC

Connect theElta CU with an external battery or power supply and start the Elta CU in Offline-Mode. Then connect both devices by a serial interface cable plus pc adapter and start the necessary programs for data transfer.

# Default Interface parameters for transmitting and receiving project files:

| Baud rate: | 19200    |
|------------|----------|
| Protocol:  | Xon/Xoff |
| Parity:    | none     |
| Stop bits: | 1        |
| Data bits: | 8        |

#### 👁 Tip


For data transfer to the PC, you can use the MS-Windows<sup>™</sup> Terminal program, or the Zeiss Control Centre software.

## Attention!


The data transfer via the foot connector of the Trimble 5600 is not active.

#### **PC Terminal settings**

Set the communication port as shown in the picture (e.g. for Windows<sup>™</sup> 3.xx Terminal program with 9600 Baud Rate):



For sending or receiving a project file, set the terminal preferences as shown in the following picture:



To send or receive a project file, select for transfers "Send text file" or "Receive text file".

Example Windows<sup>™</sup> 95/98 or Windows<sup>™</sup> NT Hyper-Terminal Program with 9600 Bits per second: The COM port settings can be switched in the Hyper-Terminal Program of Windows<sup>TM</sup> 98 or Windows<sup>TM</sup> NT under *FIle* > *Properties* > *Configuration* as follows:

| со | M1 Properties ?>                           | < |
|----|--|---|
| Po | t Settings                                 |   |
|    |  | 1 |
|    | <u>B</u> its per second: <mark>9600</mark> |   |
|    | Data bits: 8                               |   |
|    | Parity: None                               |   |
|    | Stop bits: 1                               |   |
|    | Elow control: Xon / Xoff                   | l |
|    | <u>A</u> dvanced <u>R</u> estore Defaults  |   |
|    | OK Cancel Apply                            |   |

Tip: for a much faster data transmission switch off the "local echo" in the Hyperterminal ASCII-Configuration. To send or receive a project file, select for transfers "Send text file" or "Receive text file":

| Send Te:   | xt File           |   |          | ? ×                  |
|--|-------------------|---|----------|----------------------|
| Look jn:   | 🔄 HyperTerminal   | - |          | 0-0-<br>5-5-<br>0-0- |
| <ul> <li>Proj1123.</li> <li>Proj2434.</li> </ul> |                   |   |          |                      |
| E Proj2435.                                      |                   |   |          |                      |
|  |                   |   |          |                      |
|  |                   |   |          |                      |
| L  | _                 |   |          | _                    |
| File <u>n</u> ame:                               | Proj2434.dat      |   |          | <u>O</u> pen         |
| Files of type:                                   | Text file (*.TXT) |   | <u> </u> | Cancel               |

### Elta CU Data transmission

| Send Data 1<br>For the transmission of data<br>files. |   | STUEHMER 3<br>PROJ_F 9   | 15730         GESTERN         11011           3993         10_02_97         28677           9801         11_02_97         12826           18029         12_02_97         9922           43681         NONAME         42229 |
|---|---|--|--|
| Send  | Transmits data files                          | Use the cursor keys to select the project file required and transmit it with <b>Send</b> . |  |
| Cfg   | Configuration of<br>interface parame-<br>ters | Parity N   | arameters<br>19200 Data bits 8<br>None Stop bits 1<br>otocol Xon-Xoff  |
|   |   | 5  | of Elta CU interface parameters. Th<br>ers has to be set on the external<br>.).  |
|   |   | Baudrate:  | 1200 / 2400 / 9600 / 19200<br>38400 / 57600 / 115200   |
|   |   | Parity:  | no / odd / even  |
|   |   | Protocoll:   | Xon-Xoff / Ln-Ctl / Rec500   |
|   |   | Data bits:   | 8/7  |

Stop bits: 1 / 2



to select parameters,

to accept.



Change drive

Use the softkey Dir to change the drive:

Data drive Elta CU®

A:\ D:\DATEN PC card drive internal drive

This change will be displayed in the menu bar with

Send A:\ Send D:\DATEN

#### 🕿 Tip

The instrument or program at the receiving end must be set to the receive mode before you can transmit the project file.

| Data                      | reception                                     |                                  |   |  |  |
|---------------------------|---|----------------------------------|---|--|--|
| Receive Data 2            |   | Target Fil                       | Target File   |  |  |
| For receiving data files. |   | Name 🔐                           | JNAME   |  |  |
|                           |   | Rece<br>Enter the new            | file name.  |  |  |
| Rece                      | to enter the target<br>file name              |                                  | accept sets the instrument in the ceiving mode.               |  |  |
|                           |   | Target drive is                  | Target drive is the actual data carrier:                      |  |  |
|                           |   | A:∖<br>D:∖DATEN                  | (for Elta CU® PC card drive)<br>(for Elta CU® internal drive) |  |  |
| Cfg                       | Configuration of<br>interface parame-<br>ters | Configuration<br>Send Data.      | of interface parameters is similar to                         |  |  |
|                           |   | The Elta CU is<br>transmitting e | now waiting for the file from the nd:                         |  |  |
|                           |   | Target Fil<br>Receivi            |   |  |  |
|                           |   | Na Please                        | Wait  |  |  |
|                           |   | Cance 1                          | with ESC  |  |  |
|                           |   | Rece                             | Cfs   |  |  |

**Esc** to continue after receiving the data.

#### 🕿 Tip

**Time-out** occurs after 45 seconds without data communication.

The message "Data format error" indicates a data error. The program returns to the data transfer menu.

## Data Format

#### M5 data format

| Project file <name>.DAT<br/><name> Project name</name></name>     | When you set up a new project, an ASCII project file is created whose records conform to a predefined format.   |  |
|---|---|--|
| M5 record format  | The Geodimeter® uses the Zeiss <b>M5 data format,</b><br>which is the common standard for all Zeiss<br>surveying systems.   |  |
| 1 Address block<br>1 information block<br>3 numerical data blocks | All 5 data blocks are preceded by a type identifie<br>The 3 numerical data blocks have a standard<br>layout comprising 14 digits. In addition to the<br>decimal point and sign, they accept numeric<br>values with the specified number of decimal<br>places.<br>The information block is defined by 27 character.<br>It is used for point identification (PI) and text<br>information (TI e.g.).<br>The address block is comprised of 5 digits (from<br>address 1 to 99999). |  |

#### M5 data line

The data line of the M5 format has a length of 121 characters (bytes). The multiplication of this figure by the number of addresses (lines) stored gives you the volume of the project file in bytes.

Blanks are significant characters in the M5 file and must not be deleted.

The example describes an M5 data line at address 176 with coordinates (YXZ) recorded in unit **m**. The point identification of marking 1 is **DDKS S402 4201**. Column 119 includes a blank (no error code).

The end of the line has CR, LF (columns 120 and 121, shown here as  $\leq$  ).

| 121   | 345678901               | dim5 ?<=   |                   | 334.784 m   <=                        |      |
|-------|-------------------------|--|-------------------|---------------------------------------|------|
| 110   | 234567890123            | 45678901234  | <>Value5          | 334.784                               |      |
| 100   | 578901                  | 5-123  | >                 | N1                                    |      |
| 06    | 67890123456789          | dim4]  |                   | <u> </u>                              |      |
| 08    | 678901234567890         | 12345678901234   | <>                | 74968.796 m Z                         |      |
| 70    | 89012345                | dim3  T4 -   |                   | <u>ж</u>                              |      |
| 60    | 345678901234567         | 12345678901234   | <value3></value3> | 56590.405 m X                         |      |
|       | 012                     | тз-  |                   | ×                                     |      |
| 30 40 | 123456789012345678      | 7 <mark>89012345678901234567</mark>   T3•12345678901234•dim3   T4•12345678901234•dim4   T5•12345678901234•dim5   ?<= | <value2></value2> |                                       |      |
| m     | 67890                   | 56789  |                   | s402                                  |      |
| 20    | 78901 <mark>2345</mark> | Eor=M5 Adr= <mark>12345</mark>  T2a= <mark>1234567</mark> 5  |                   | For M5   Adr 176   PI1 DDKS 8402 4201 |      |
|       | 3456                    | 2345   | Valuel            | 176                                   |      |
| 10    | 789012                  | Adr -1   | Va                | $\mathbf{Adr}$                        |      |
| ط ا   | trov<br>123456          | SM-TOT 4Sside  | nment             | Exar<br>Exar                          | nple |

| Col. 120-121:<br>Column 119:<br>Col. 114-117: | Carriage Return <, Line Feed<br>Blank field, in case of error "e"<br>Unit for block5       |
|---|--|
| Column 99-112:                                | Block5 value block   |
| Column 96-97:<br>Column 91-94:                | Type identifier5 for block5<br>Unit for block4   |
| Column 76-89:                                 | Block4 value block   |
| Column 73-74:<br>Column 68-71:                | Type identifier4 for Block4<br>Unit for block3   |
| Column 53-66:                                 | Block3 value block   |
| Column 50-51:                                 | Type identifier3 for block3  |
| Column 22-48:                                 | Information block PI or TI<br>(point identification PI or<br>text information TI, TO etc.) |
| Column 18-20:                                 | Type identification2 Pla (a=1-0,<br>for 10 Markings) or Tl                                 |
| Column 12-16:                                 | Memory address of data line  |
| Column 8-10:                                  | Type identifier 1 Adr for address  |
| Column 1-6:                                   | Defines M5 format  |
| ■ blank                                       | separator  |


# Data Format

## Explanations to the data line

| Abbr.              | Description                         | Digits  | Characters       | Meaning                             |
|--------------------|-------------------------------------|---------|------------------|-------------------------------------|
| For                | Format identifier M5<br>Format type | 3<br>2  | alpha<br>alpha   | Elta® Format<br>5 meas. data blocks |
| Adr                | Address identifier<br>Value1        | 3<br>5  | alpha<br>numeric | Value1<br>Memory address            |
| T2                 | Type identifier                     | 2<br>1  | alpha<br>numeric | Value2 (Pla ,Tl, TO)                |
| a                  | Marking Value2                      | 27      | alpha            | a=1, 2, 3 ,, 9, 0<br>Pl or Tl       |
| Т3                 | Type identifier<br>Value3           | 2<br>14 | alpha<br>numeric | Value3<br>14-digit value            |
| dim3               | Unit                                | 4       | alpha            | 4-digit unit                        |
| Τ4                 | Type identifier<br>Value4           | 2<br>14 | alpha<br>numeric | Value4<br>14-digit value            |
| dim4               | Unit                                | 4       | alpha            | 4-digit unit                        |
| Τ5                 | Type identifier<br>Value5           | 2<br>14 | alpha<br>numeric | Value5<br>14-digit value            |
| dim5               | Unit                                | 4       | alpha            | 4-digit unit                        |
| ?                  | Identifier                          | 1       | alpha            | Error message, or <b>•</b>          |
| Special characters |                                     |         | ASCII code       | Hex code                            |
|                    | Separator                           | 1       | ASCII 124        | Hex 7C                              |
| •                  | Blank                               | 1       | ASCII 32         | Hex 20                              |
| <                  | CR (Carriage Return)                | 1       | ASCII 13         | Hex 0D                              |
| =                  | LF (Line Feed)                      | 1       | ASCII 10         | Hex 0A                              |

# **PCMCIA Card Data Memory**

#### **PCMCIA cards**



The memory concept of the card is fully MS-DOS<sup>®</sup>-compatible. The project memory is only limited by the storage capacity of the card.

#### 🕿 Tip

When the card is full, you can continue storage on the D:\ drive of the Elta CU<sup>®</sup>. There is an internal memory with minimum of 3000 data lines available.

SRAM and ATA FLASH PCMCIA cards can both be used.

Elta CU - SRAM-Cards - ATA-Flash Cards When using SRAM cards, make sure to check the charge condition of the integrated battery at regular intervals. If this is not possible, change the battery about every 2 years to be on the safe side.

The SRAM card, i.e. the card is automatically loaded during its use in the drive If you are planning not to use the SRAM card for a prolonged period of time (> 1 year), you should save the data, as there is the risk of battery drain and the resultant loss of the data.

According to the manufacturer, rechargeable SRAM cards have a battery life of approx. 10 years.

#### Attention!

Please use only the PCMCIA cards recommended by Trimble.

## **PCMCIA drives**

The PCMCIA drive is installed as drive A:\ in the Elta CU $\circledast$ .

The Elta CU® reads and writes SRAM and ATA Flash cards as well.

Make sure that other computers and PCMCIA drives also use drivers compatible with the Elta CU® drivers for reading and writing the card.

### Attention!

Please use only the PCMCIA drives and drivers recommended by Trimble AB.

When in doubt, please contact your authorised Trimble dealer.

## Formatting a PCMCIA card

With the Elta CU® it is possible to format a PC card.

|         |  | Main Menu  |  |                         |  |
|---------|--|--|--|-------------------------|--|
|         |  |  | mm Exit ?  | 6 7                     |  |
|         |  | Mea<br>Sta<br>Coo                                | Yes  | 6<br>7<br>8<br>Dos No 9 |  |
|         |  |  |  |                         |  |
|         |  | <b>Esc</b> in the main menu to leave the program |  |                         |  |
|         |  | <b>DOS</b> go to the MS-DOS® mode.               |  |                         |  |
|         |  | Elta CU con                                      | nmand:   |                         |  |
|         |  | C:\> <b>SRAMFC</b>                               | DRM A:\  | (example)               |  |
|         |  | Attention  | 1!   |                         |  |
|         |  | the internal<br>This leads to                    | ole to format<br>ne Elta CU®.<br>nd the<br>ke sure, that |                         |  |
|         |  |  | fferent type of PC<br>llowing command                    |                         |  |
| Hint to | navigate in the full<br>Elta CU®<br>Operation<br>Graphical Display | SRAM Card:                                       | SRAMFORM   |                         |  |
| display |  | ATA Card:  | ATAFORM  |                         |  |
|         |  | Linear Flash:                                    | FLASHFMT   |                         |  |
|         |  | The formatting can take 1-2 min.                 |  |                         |  |

The instrument adjustment defines all corrections and correction values for the Trimble 5600®, which are required to ensure optimum measuring accuracy.

### Adjusting V-Index / Hz-Collimation

Adjusting Tracker

Adjusting Compensator

### Adjustment

#### **Adjustment methods**

Adjustment 2

The menu item *Adjustment* offers the following adjustment programs:

Increased strain placed on the instrument by extreme measuring conditions, transportation, prolonged storage and major changes in temperature may lead to misalignment of the instrument and faulty measuring results. Such errors can be eliminated by instrument adjustment or by specific measuring methods.

| 2 Adjust    |   | NONAME |
|-------------|---|--------|
| Standard    | 1 |        |
| Tracker     | з |        |
| Compensator | 5 |        |
|             |   |        |

Adjustment menu.

Instrument CorrectionsDetermination of the vertical index correctionStandard(V index) and sighting axis correction (Hz collimation).

Determination of the collimation corrections.

Determination of the compensator run centre.

#### Attention!


Before starting any adjustment, allow the instrument to adapt to the ambient temperature and make sure it is protected against heating up on one side (sun radiation).

Tracker

Compensator

### Adjustment

#### Instrument errors and their correction



#### **Adjusting V-Index / Hz-Collimation**

The vertical index and sighting axis corrections should be recomputed after prolonged storage or transportation of the instrument, after major temperature changes and prior to precise height measurements.

#### 🕿 Tip

Before starting this procedure, precisely level the instrument using the electronic level.

To determine the corrections, sight a clearly visible target in **Hz** and **V** from a distance of approx. 100 m. The sighting point should be close to the horizontal plane (in the range V =  $100^{\text{grads}} \pm 10^{\text{grads}}$ ).

#### Standard

Determination of the sighting axis and vertical index corrections, or setting the values c = i = 0.

| 211 Instr. Corr.                | Standard                 |  |
|---------------------------------|--------------------------|--|
| c                               | 0.0008 son<br>0.0008 son |  |
| New Calculation<br>Set: c=0,i=0 | 1<br>2                   |  |

The current **c** and **i** values are displayed in the readings window.

- c sighting axis correction
- i vertical index correction

#### **New Calculation**

Determination of the **c** and **i** values by measurement in two faces.

| 212 Instr.   | Adj. Fa  | ace 1                |           | Adr: | 478 |
|--|----------|----------------------|-----------|------|-----|
| Sight with:<br>Cross Hairs   | Hz<br>V1 | 134.3246<br>100.0450 |           |      |     |
| 1000<br><pnr< th=""><th></th><th>i Measu<br/>-Info</th><th>ir⊒<br/>·&gt;</th><th>84</th><th></th></pnr<> |          | i Measu<br>-Info     | ir⊒<br>·> | 84   |     |
|  | R-MC     | M.                   | ark       | Code |     |

for measurement in face 1. The instrument then turns automatically to face 2. Sight the same point again.

for measurement in face 2.

### Adjustment

The new vertical index and sighting axis corrections are computed automatically.

| 214                           | Instr. Co                       | orr.: Select |
|-------------------------------|---------------------------------|--------------|
| old                           |                                 | New          |
| c<br>i                        | 0.0000 son<br>0.0000 son        |              |
| Apply<br>Yes No               |                                 |              |
| Yes The new values are saved. |                                 |              |
| No                            | No The old values are retained. |              |

#### Technical

During the computation of the vertical index and sighting axis correction, the program also determines the compensator run centre.

#### **Tolerance exceeded**

If either the **c** or **i** value exceeds the admissible range of  $\pm$  50 mgrads, the following error message appears:

| Error    | Instr. Corr. Standard<br>Limits Exceeded |
|----------|--|
| Index Co | rrection lil > 50 mgon                   |
| Press an | y key to continue                        |

The values are not saved, and the menu for new calculation is displayed again.

#### Attention!

2

If the values remain outside the tolerance range, despite accurate sighting and repeated measurement, you should have the instrument checked by the service team.

Set: c=0, i=0

Setting the **c** and **i** values to zero.

### Adjustment

#### **Adjusting Tracker Unit**

3

#### Tracker Unit

Determination of the collimation corrections similar to the optics of the telescope. The V-Index and Hz-Collimation are taken into account.

Adjust/activate the compensator before. The initialisation of the compensator has to be done before.

| 2 Adjust    |   | NONAME |
|-------------|---|--------|
| Standard    | 1 |        |
| Tracker     | з |        |
| Compensator | 5 |        |

Select Tracker adjustment

Adjust Tracker

1. Aim at active target 2. Start with <RETURN>

Aim to the RMT.

Start Tracker adjustment

🕿 Tip

Precisely sight a clearly visible **RMT** from a minimum distance of approx. 100 m. Better aim to the RMT in working range!

for adjustment measurement

| Adjust Tracker |  |
|----------------|--|
|                |  |
| Please Wait    |  |

Tracker adjustment is running.

The new values of the corrections are recorded automatically.

The adjustment is automatic and can take approx. 30 seconds. Please take care not to move the instrument or RMT during this time. The program returns then back to the menu.

#### Attention!

Please pay attention that the RMT is not obstructed during the adjustment e.g. since of traffic and there is no influence of vibrations onto the instrument or the RMT.


#### Adjustment failed

| Error                    | Adjust Tracker    |
|--------------------------|-------------------|
| Target lost or not found |                   |
| Press any                | y key to continue |

RMT was obstructed. Start adjustment again.

If the values remain outside the tolerance range, despite accurate sighting and repeated measurement, you should have the instrument checked by the service team.

### **Adjusting Compensator**



Compensator


Determination of the compensator run centre and checking of the instrument levelling.

**Compensator Initialisation** 

Determination of the new run centre components of the compensator.

The Trimble 5600® features a dual-axis compensator, which compensates any vertical shaft inclinations remaining after instrument levelling both in the sighting and trunnion axis directions.

To check the compensator, its run centre should be determined at regular intervals and in particular prior to precise height measurements.



The current cpompensator status is displayed in the readings window




5

Start compensator initialisation.

Adjust Compensator

Please Wait...

Compensator adjustment is running.



Status: ok. Compensator is adjusted.

#### Attention!

For the accurate determination of the run centre, it is essential that the liquid in the compensator is allowed to settle, i.e. any vibration of the compensator must be avoided.

### Adjustment

Check Levelling

Calling up the "Electronic level" display for levelling the instrument. 2

#### Levelling -0.0009 (||||•••••|||) Trunnion



The signs of the inclination values in position 1 have to be interpreted as follows:

| Inclination     | Trunnion axis | Sighting axis |
|-----------------|---------------|---------------|
| positive value: | to the right  | to the front  |
| negative value: | to the left   | to the back   |

Gefore Measurement Use the tribrach footscrews to set the inclination values roughly to zero. More precise levelling is not required if compensation has been activated. At any rate, the residual inclinations should be within the compensator working range.

#### 🕿 Tip

Precise levelling is advisable if the compensator needs to be deactivated due to vibrations.

The electronic level can be called up at any point of the program using the **Ctrl L** hotkey.

#### Attention!

If the instrument was levelled and centred above a ground point, you have to check the centring with the optical plummet after any relevelling.

### 8-10

With the configuration, you can adjust the Trimble 5600® to all measurement conditions and requests taking into account an optimum of operator convenience.

**Configuration Instrument** 


**Configuration Programs** 

**Configuration Markings** 

**Configuration Codelists** 

**Configuration Update** 

### Configuration



| Instrument            |   |  |
|-----------------------|---|--|
| Programs              | 2 |  |
| Markings<br>Codelists | 3 |  |
| Update                | 5 |  |
|                       |   |  |

and or with keys **1** to **5** for a directly menu selection.

Generally, the settings of the configuration are stored permanently. Exceptional cases (temporary storage) are indicated in the description.

#### **Operation in the submenus**

For the setting of switches or input of information and data, resp., the handling of the menus of the configuration is based on a common concept. The following keys are frequently used:

| <b>1</b> | Cursor positioning  |
|----------|---|
| 0 -      | 9 Keys for direct selecting of submenus   |
|          | Toggling in selection fields  |
|          | Confirming entrance and quitting  |
| Esc      | Quitting of submenu;<br>when settings have been changed,<br>the following question is asked prior to<br>quitting: |
|          | netrument Tune  |
|          | onfiguration  |
| ser -    | Yes No  |

Trimble 5600® The System Total Station Operation

Yes

Change accepted


No No change of settings

This user information is a pre-request for the following descriptions.



Setting and checking of all switches, parameters and options necessary for best operation of the instrument.

#### 91 Instrument




Menu of the instrument configuration. "5 EDM-Setting" active with 5600 DR 200+!

**91 Configuration Instrument** 

and log or with keys 0 to 9 for a directly menu selection.

#### **Overview Instrument Configuration**



### — 911 Instrument Type 912 External Distance Calibration 913 Switches 9131 Illumination 9132 Peripheries 9133 Adjustments 9134 Units / Decimal Points 9135 Reference System – 9136 Recording 9137 Error Limits 914 Prism Sensors \_ 9141 AutoLock 915 EDM-Settings 916 Clock - 917On/Off-Configuration - 918 Language - 919 Batteries - 910 Default

1

2

#### Instrum.-Type

Definition, whether measuring with instrument or by manual input.

| 911 Instrumen<br>Type<br>CU Serial No<br>CU SW-Version<br>PC Version | : Trimble System 5600<br>. : 69010006           |
|--|---|
| Туре:  | Trimble 5600 - Total Station or<br>Manual Input |
| CU Serial No.:   | Display of ELTA CU serial<br>number             |
| SW Version:  | Installed Software Release.                     |
| PC Version:  | Display of PC Type                              |

2=486 Processor

#### Calibration

Display and input of calibration scale and addition correction for supplementary correction of distance measurement.

#### 912 EDM Calibration

Calibration Scale : 1.000000 Calib. Offset Co. : 0.0000 m

 Calibration scale:
 Default = 1.000000

 ∞
 0.998500 < Km < 1.001500</td>

 Calib. Offset Co.:
 Default = 0.0 mm

 ∞
 -12.7 mm < Ac < 12.7 mm</td>

#### Attention!

Both values influence the measured distance directly! Therefore, they must have been determined by means of an accurate calibration.

3

3

1

#### Switches

Switches

**举** 

☆ |

Illumination

Switching instrument functions and their parameters on and off.

Switching on and off and adjusting the illumination

available in the instrument.

Cross Hair on

Display on

#### 913 Switches

| Illumination<br>Peripheries<br>Corrections<br>Units<br>Reference System | 12345 | Recording<br>Error Limits | 6<br>7 |
|---|-------|---------------------------|--------|
| nererence ogsten  |       |                           |        |

Menu Switches for instrument configuration.

| 9131 Illumination Switches |           |              |                |  |
|----------------------------|-----------|--------------|----------------|--|
| On                         | Brightnes | s:           | Normal         |  |
| On                         | Contrast  | :            | 8              |  |
|                            | On        | On Brightnes | On Brightness: |  |

Cross Hair: on / off

and the switches for the display illumination:

| Display:    | on/off               |
|-------------|----------------------|
| Brightness: | low / normal / high  |
| Contrast:   | 0 (low) to 10 (high) |

#### 👁 Tip

The illumination can also be switched on and off using the hotkey **Ctrl + I**.

| Switches              | 3 |
|-----------------------|---|
| Peripheries           | 2 |
| Switching sensors and |   |
| actuators on and off. |   |




TrackLight on

| 9132 Periphery Switches |           |  |
|-------------------------|-----------|--|
| Tracklight              | Off       |  |
| Laserp.Off<br>Sound     | Off<br>On |  |
| Signal Volume           |           |  |

Toggling all switches  $On \leftrightarrow Off$ .

| Track Light On:   | Permanent and Blinking  |
|-------------------|-------------------------|
| Laserpointer OFF: | Switch OFF mode Pointer |
| Sound:            | Keyboard sound          |
| Signal Volume:    |                         |



| Switches | 3 |
|----------|---|
| Units    | 4 |

Modification of display of measuring units and number of decimal places.

### 9133 Correction Switches Tilt Compensation On Atmospheric Corrections On

Toggling all switches  $On \leftrightarrow Off$ .

After instrument startup and adjustment of the compensator all switches are again in position **On**.

| 9134 Units +                                  | Decima              | l Point⊴           | 5                 |            |
|---|---------------------|--------------------|-------------------|------------|
| Distance<br>Angles<br>Temperature<br>Pressure | : 9                 | on<br>C<br>Pa      | 3<br>4<br>0<br>0  |            |
| <b>Distances:</b><br>Decimal places:          | <b>m</b><br>1-4     | <b>ft</b><br>1-4   |                   |            |
| <b>Angles:</b><br>Decimal places:             | <b>grads</b><br>1-5 | <b>DMS</b><br>0-1  | <b>deg</b><br>1-5 | mil<br>1-4 |
| <b>Temperature:</b><br>Decimal places:        | ° <b>C</b><br>0-1   | ° <b>F</b><br>0-1  |                   |            |
| <b>Pressure:</b><br>Decimal places:           | <b>hPa</b><br>0-1   | <b>Torr</b><br>0-1 | inHg<br>1         |            |

#### 🖝 Tip

The number of decimal places is not related to the internal data storage, but only to the appearance of the data on the display.

Switchover angle and distance units also via hotkeys Ctrl+A and Ctrl+D.

3

5


#### Switches

Reference System

Modification of display of coordinate systems and definition of angles and bearings.

| 9135 Switch Reference System |               |  |
|------------------------------|---------------|--|
| Axis Definit.                | : [53]N       |  |
| Display                      | : <u>E-N</u>  |  |
| Height                       | : Z           |  |
| Hz-Direction                 | : oriented    |  |
| Vert.Orient                  | :Zenith Angle |  |

Assignment of coordinates:



| H7-1 | )iro | ctior | •• |
|------|------|-------|----|
| 112  |      | CUOI  |    |

| <b>absolute:</b> | recording of the absolute                               |
|------------------|---|
| (default)        | (original) Hz circle reading.                           |
| oriented:        | recording of the oriented (by stationing) Hz direction. |

| vitch | es 3                    | 9136 Recordi                       | ng Switch   |  |
|-------|-------------------------|------------------------------------|---|--|
| cord  | ling 6                  | Recording<br>Destination<br>Format | On<br>Internal<br>Rec E                               |  |
| _     |                         |                                    |   |  |
| 1     | Recording <b>On</b>     | Switches the da                    | ita storage <b>On</b> or <b>Off</b> .                 |  |
| -     | Recording On            | Default value:                     | Recording <b>On</b>                                   |  |
|       |                         | Target Drive:                      | Internal (A:\ or D:\DATEN)                            |  |
|       |                         | Format:                            | Rec E (M5, internal)                                  |  |
|       |                         |                                    |   |  |
| vitch | es 3                    | 9137 Switch                        | Error Limits  |  |
| ror L | imits 7                 | Error Limits                       | 5 On  |  |
| _ E   | Error limits <b>Off</b> | Default value:                     | Error limits <b>On</b>                                |  |
| _ E   | Error limits <b>On</b>  |                                    | Switches the error limits set in the configuration of |  |

the programs **On** or **Off**.

4

....5

#### **Prism Sensors**

Configuration of the prism sensors.



#### AutoLock

Activation and configuration of the AutoLock mode.

#### 9141 Switch AutoLock

AutoLock

: Off

Menu configuration of prism sensors.

#### 9141 Switch AutoLock

AutoLock

: On

#### AutoLock:

### On / Tracking / Off When AutoLock is activated, this setting is offered

first in the measurement programs.

#### EDM-Setting

Configuration of EDMsettings for Direct Reflex mode.

| EDM Settings                   |                           |
|--------------------------------|---------------------------|
| Standard deviation<br>EDM Mode | : 0 <b>.003</b> m<br>: DR |
| Dist interval max.             | : 500 m                   |
| Dist interval min.             | : 2m                      |
| Pointer                        | : Off                     |
| Weak signal                    | : On                      |

| Standard deviation: | requested accuracy       |
|---------------------|--------------------------|
|                     | (1mm to 0.9m)            |
| EDM Mode:           | PR-reflector             |
|                     | DR-no reflector          |
| Dist interval max:  | distance interval        |
|                     | Standard: 200m           |
| Dist interval min:  | distance interval        |
|                     | Standard: 2m             |
| Pointer:            | Laser pointer ON / OFF   |
| Weak signal:        | reflected signal is weak |

| Clock | 6                   | 916 Clock Configration                             |                                   |                                  |  |
|-------|---------------------|--|-----------------------------------|----------------------------------|--|
|       | cation of date and  | Time Format<br>Date Format                         | :                                 | 24 HH HMM<br>DD.MM.YY            |  |
|       |                     | Time format:                                       |                                   |                                  |  |
|       |                     | 24 HH.MM<br>24 HH:MM:SS<br>12 HH:MM<br>12 HH:MM:SS | 12 Hours:                         | Vinutes:Seconds                  |  |
|       |                     | Date format:                                       |                                   |                                  |  |
|       |                     | тт.мм.))<br>мм.тт.))<br>)).мм.тт                   | Day.Mont<br>Month.Da<br>Year.Mont | y.Year                           |  |
|       |                     | Ctrl T Hotl<br>each program le                     | •                                 | t of time and date in            |  |
| Time  | for time input      | 9161 Time and                                      | d Date                            |                                  |  |
| Dat   | for date input      | Time   | :                                 | 08:31                            |  |
| Cfg   | Configuration       | Date   | :                                 | 29.01.98                         |  |
|       | display time / date | After baying pre                                   | ssed the swi                      | tches <b>Time</b> or <b>Date</b> |  |

After having pressed the switches **Time** or **Date** the input of time or date can be done in the configured format.

#### **On/Off Config**

Configuration of functions to be executed after booting or before loading the application.

7

| 917 On/Off Configuration |      |  |
|--------------------------|------|--|
|                          |      |  |
| Levelling :              | On   |  |
| Station Input            | : On |  |
| -                        |      |  |
|                          |      |  |

Toggling of switches  $On \leftrightarrow Off$ .

Levelling: Display levelling menu

**Station Input:** Input of station information before start measuring in a local system.

8

9

#### Station Input

Before measuring in a local system a point information and further station parameters (th, ih, Reflector Type etc.) can be entered. This will be stored in the project file as like a header for the following measurement values.

#### Language

Configuration of the language, in which the software appears on the display.

Batteries

Management and checking of the batteries connected and their capacities.

| 918 Language Configuration |   |         |
|----------------------------|---|---------|
| Language Version           | : | english |

Here, existing and integrated language versions are offered for activation.

#### 919 Battery Management

Battery Instrument Battery RCU Backup Battery

Low ----o.k.

Display of the remaining battery capacity of instrument or RCU or backup battery.

**Ctrl B** Hotkey for activating the battery manager (in every menu available).

#### 🕿 Tip

If the instrument or RCU battery is empty the Elta CU displays a warning and automatically switches over to the Backup Battery. Now disconnect the empty battery and connect the full battery. Meanwhile the Backup Battery will power the system.

#### **Default Setting**

Resets the complete configuration of the instrument to the default values defined in the program.

| 91 Instrument<br>Standard Settings |    |
|------------------------------------|----|
| Ins<br>Dis Set Standard Values ?   | 6  |
| Swi<br>Pri Yes No                  | 89 |
| Internees o percent of the         | Ō  |



Yes

0

back without modification.

reset of all parameters of the instrument configuration to their default values.




Setting and checking of all switches, parameters and options required for the application programs

| 92 Program Configuration   |           |               |   |
|--|-----------|---------------|---|
| Stationing<br>Coordinates<br>Special<br>Gen. Functions<br>Project Info | 1<br>2345 | Standard Set. | o |

Menu of the program configuration.

and or with keys **0** to **5** for a directly menu selection.



### **Overview Configuration Stationing**

#### Stationing

Setting and checking of error limits, standard deviations, scale ranges and reduction parameters.

#### 921 Stationings

Free Stationing 1 Stat. Knwn. Pnt 2 Ecc. Station 3 Heightstation. 4

Menu for the configuration of the stationing.

| Free Stationing    | 1 |
|--------------------|---|
| in analogy to that |   |
| Stat. Knwn. Pnt    | 2 |
| Eccentric Station  | 3 |
|                    |   |

| 9211 Free Stationing  |                             |         |   |
|---|-----------------------------|---------|---|
| Adjustment Type<br>Stand. Deviation<br>Error Limits<br>Adjustment<br>Reductions | 1 Scale<br>2<br>3<br>4<br>5 | Range é | • |

Configuration menu free stationing.

The configuration of free stationing includes all possible settings of the configuration of stationing on a known point and eccentric station.

### Free Stationing

Adjustment Type

Definition, if and how the type of computation and the scale are set as standard in the free stationing.

1

| 92111 Free St | tation. Adjustment Type   |
|---------------|---------------------------|
| Calculations  | : Single Point Adjustment |
| Change        | : On                      |
| Scale         | : free                    |
| Change        | : On                      |

The setting entered corresponds to the type of computation displayed first in the program.

| Computation: | Single point adjustment /<br>Helmert transformation   |
|--------------|---|
| Scale:       | free / fixed  |
| Change:      | <b>On</b><br>Type of computation and scale<br>can be changed during the free<br>stationing. |
|              | <b>Off</b><br>Given type of computation and   |

scale setting cannot be changed.

1

2

1

3

#### Free Stationing

#### Stand. Deviation

Definition of standard deviations of observations and centring for the weighting in the single point adjustment.

 $\swarrow$  0.0001  $\leq$  sr < 1 grad

 $0.001 \leq sdc < 1 m$ 

 $0 \leq sdl < 1000 \text{ ppm}$ 

 $0.000 \le sz < 1 m$ 

#### 92112 Single Point Adjust.

| Orientation<br>Distances constant | : | 0 <mark>.0003</mark> gon<br>0.003 m |
|-----------------------------------|---|-------------------------------------|
| Distances linear                  |   | mqq O                               |
| Levelling                         | : | 0.000 m                             |

Input of values in given measuring units.

| Default values:  |  |
|------------------|--|
| sr = 0.0003 grad |  |

| Distances constant: | sdc = 0.001 m |
|---------------------|---------------|
| (constant part)     |               |

Distances linear: sdl = (linear part)

sdl = 0 ppm

Target centring: sz = 0.000 m(centring accuracy reflector above target)

### 🕿 Tip

Bearings:

A specification of 0.0 results in remaining this parameter without influence on the weighting.

### Free Stationing Error Limits

Definition of error limits for the results of the free stationing.

| Ľ | $0.000 \le va < 1$ | grad |
|---|--------------------|------|
|---|--------------------|------|

 $0.000 \le vr/vq/vl < 1 m$ 

| 92113 Free Stat. Error Limits |    |        |        |     |
|-------------------------------|----|--------|--------|-----|
|                               |    | s=fix  | s=free |     |
| Linear Dev.                   | vr | 0.040  | 0.030  | м   |
| Angle Dev.                    | va | 0.0050 | 0.0050 | gon |
| Orthog. Dev.                  | vq | 0.030  | 0.020  | m   |
| Lateral Dev.                  | v1 | 0.030  | 0.020  | м   |

Input of values in given measuring units.

| Default values:          | s= <b>fix</b> | s= <b>free</b> |
|--------------------------|---------------|----------------|
| Linear dev. <b>vr</b> :  | 0.040         | 0.030 m        |
| Bearing dev. <b>va</b> : | 0.0050        | 0.0050 grad    |
| Transv. dev. <b>vq</b> : | 0.030         | 0.020 m        |
| Long. dev. <b>vl</b> :   | 0.030         | 0.020 m        |

| Free | Stationing |
|------|------------|
|      |            |

#### Adjustment

Activation and deactivation or weight definition, resp., of best-fit adjustment.

| 92114 Stationing Adjustment |   |        |             |  |
|-----------------------------|---|--------|-------------|--|
| Mode                        | : | Weight | by distance |  |
| Weight exponent n           | : | 2.0    | p=1/D "     |  |
|                             |   | D' /   | 1011        |  |

#### Mode:

Distances / Off

**Weight exponent:** 0.5 / 1 / 1.5 / 2 For distributing the residuals according to distances by means of the arithmetic mean.

Default Mode:

Off

| Free Stationing |  |
|-----------------|--|
|                 |  |

Reductions

Activation and deactivation of projection reductions.

| 92115 Reduc  | tions |              |
|--------------|-------|--------------|
| Height       | :     | On           |
| Projection   | :     | Gauss-Kruger |
| Height reduc |       | On / Off     |

Projection: Gauss-Krueger / UTM / Off

Default reduction: Off

The reductions act (when activated) parallel to the existing scale factor **s** on the distances measured.

# Free Stationing1Scale Range6

Definition of the admissible scale range.

 $\cancel{\ } \text{-9999} \leq \text{ SR } \leq 9999$ 

| 92116 | Stationing | Scale | range |  |
|-------|------------|-------|-------|--|
|       |            |       |       |  |

Scale Range : ±

|1<u>300</u> ppm

#### Scale range:

Default value:

Input in [ppm]

± 1500 ppm

#### 🕿 Tip

With a value of 0 ppm, the scale range will not be checked.

#### Heightstationing

4

Definition of standard deviations and error limits of the height stationing.

9214 Heightstationing

Stand. Deviation 1 Error Limits 2

Menu of the configuration height stationing.

| Heightstationing | 4 |
|------------------|---|
| Stand. Deviation | 1 |
|                  |   |

Definition of the distance section, for which p = 1 is applied.

 $\varkappa$   $0 \le c \le 9999 m$ 

| 92141 Height                                  | stationing Stand.  | Deviation                |
|---|--|--------------------------|
| с: 🔳 3] м                                     | Distance for We  | ight 1                   |
| Weight for D<br>Weight for D<br>If c = O      | $\begin{array}{c} c : p = c^{2}/D^{2} \\ c : p = 1 \\ c : p = 1/D^{2} \end{array}$ |                          |
| Input distance                                | <b>c</b> in [m].   |                          |
| Default:                                      | c = 30 m   |                          |
| Example:<br>up to 30 m dist<br>from 30 m dist | tance $\rightarrow$ ance onwards $\rightarrow$                                     | p = 1<br>$p = c^2 / D^2$ |

 $\rightarrow p = 1/D^2$ 

| Heightstationing | 3 |
|------------------|---|
|                  |   |
| Error Limits     |   |

Definition of the max. admissible height deviation.

*⊯* 0 ≤ vz ≤ 1 m


| 92142    | Height    | Static           | n Error          | Limits          |
|----------|-----------|------------------|------------------|-----------------|
| Height   | Dev.      | vz :             |                  | 0 <b>.030</b> m |
| Input he | eight dev | /iation <b>v</b> | <b>z</b> in [m]. |                 |

Default: vz = 0.030 m

c = 0

4

#### **Overview Configuration Coordinates**



| Coordinates |       |     |     |
|-------------|-------|-----|-----|
|             | Coore | ino | 100 |
|             |       |     |     |

Setting and checking of error limits, admissible differences and ranges in the coordinate programs.

Trimble 5600 Manual Part II

| 92          | 22                | Coo                 | rdi                | nate                         | Prog              | gr. | ams     |       |     |   |
|-------------|-------------------|---------------------|--------------------|------------------------------|-------------------|-----|---------|-------|-----|---|
| I<br>T<br>Z | ett<br>rav<br>nte | ing<br>vers<br>erse | j Ou<br>se<br>seti | ints<br>Jt<br>ions<br>at ior | 1<br>23<br>4<br>5 |     | Helmert | Tran⊴ | sf. | 6 |

Menu configuration coordinate programs.

The Verification Point Configuration for Detail Point Measurement will be described in Trimble 5600 Manual Part II for the program packages *Special* and *Professional (Professional Plus!)*.


| Coordinates 2               | 9222 Setting Out                                    |
|-----------------------------|---|
| Setting Out 2               | Error Limits 1<br>Recording 2                       |
| Setting out configuration   |   |
|                             |   |
|                             | Menu of the setting out configuration.              |
|                             |   |
| Setting Out 2               | 92221 Setting Out Error Limits                      |
| Error Limits 1              | Linear Dev. dr : 🗾 0.030 m                          |
| dmissible deviations for    | Height Dev. dh : 0.030 m                            |
| e definitive coordinates of | Defection   |
| setting-out point.          | Default value:                                      |
|                             | Linear deviation dr: 0.020 m                        |
|                             | Height deviation dh: 0.020 m                        |
| 0 ≤ dr/dh < 1 m             |   |
|                             | ☞ Tip   |
|                             | If one value is set to 0, this error limit will not |
|                             | be checked.   |
|                             |   |
|                             |   |
|                             |   |
| g Out 2                     | 92222 Setting Out Recording                         |
| age 2                       | Lateral, Orthog. Dev <b>On</b><br>CoordDiff. Off    |
| vation or deactivation of   | Actual Coordinates Off                              |
| storage of setting out      | <u>L</u>  |
| ults.                       | Togaling of switches $On \leftrightarrow Off$ .     |

🕿 Tip

The description of further coordinate program configuration (Traverse etc.) will be done in the second part of the Trimble 5600 Manual (Special and Professional Software).

Toggling of switches  $On \leftrightarrow Off$ .

#### **Overview Configuration Special**



| 923 Special Prog | rams |
|------------------|------|
| Point to Line    | 1    |
| Multiple Rounds  | 3    |
|                  |      |

Menu Configuration of Special Programs.

This manual describes the Point-to-Line Distances configuration. All the other special programs and their configuration will be explained in the second part of the Trimble 5600 manual.

| Special       |  |
|---------------|--|
|               |  |
| Point to Line |  |

Configuration of the Pointto-Line Distances program.

#### **Distance Deviation**

Input of parameters for computation of the maximum distance deviation. Scale Range

3

1

2

3

Definition of the admissible scale range.

 $\cancel{s} -9999 \le SR \le 9999$ 

#### Recording

Activation and deactivation of the storage of grid coordinate s.

|       |                 |       | _ |  |  |
|-------|-----------------|-------|---|--|--|
| Dist. | Deviat<br>Range | ion 1 |   |  |  |
| scare | nange           |       |   |  |  |

| 92311  | Point to Li | ne - Deviation in dist |
|--------|-------------|------------------------|
| Max. d | istance ds  | = a + b*s² + c*s       |
| а      | 0.040       | s[m]                   |
| ь      | : 0.0080    | ds[m]                  |
| C      | : 0.00030   |                        |

| 92312 | Point | to Line | Scale | Range          |     |
|-------|-------|---------|-------|----------------|-----|
| Scale | Range | : ±     |       | 1 <u>300</u> F | nqq |
|       |       |         |       |                |     |

Scale Range:


Input in [ppm]

Default Value:

± 1500 ppm

| 923 | 13 | Poi  | nt  | to I | ine | Recording |  |
|-----|----|------|-----|------|-----|-----------|--|
|     |    |      |     |      |     |           |  |
| Gri | dC | Coor | din | ate  | 5:  | On        |  |
|     |    |      |     |      |     |           |  |
|     |    |      |     |      |     |           |  |

#### **Overview Configuration General Functions**



### 924 Configuration General Functions 9241 Constants 9242 2-Face Measuring 92422 Error Limits 9243 Control Point 9244 Distance Measuring 9245 Point Identification 9246 Station Definition

General Functions

Configuration of general functions and constants.

| 924 General Funct | ions |
|-------------------|------|
| Constants         | 1    |
| 2-Face Measuring  | 2    |
| Control Point     | 3    |
| Distance Meas.    | 4    |
| Identical Point   | 5    |

Menu of the configuration of general functions.

## General Functions4Constants1

Modification of the constant parameters earth radius and refraction coefficient relevant to reductions and corrections.

| 9241 Constants           |                         |
|--------------------------|-------------------------|
| Earth Curvature :        | 6 <mark>370000</mark> m |
| Refractions Coefficient: | 0.13                    |

Input in the predefined measuring units of

Earth radius R: Default value 6370000 m

Refraction coefficient k: Default value 0.13

*⊭* -1.00 ≤ k ≤ 1.00

4

2

**General Functions** 

2-Face Measuring

Configuration of the recording and error limits for points measured in two faces.

| 2-Face Measuring | 2 |
|------------------|---|
| Recording        | 1 |
|                  |   |

9242 2-Face Measurement

Recording i Error Limits 2

Menu of the configuration measurement in 2 faces.

| 92421 | 2-Face | Measurement | Recording |
|-------|--------|-------------|-----------|
|       |        |             |           |

Single Values <mark>Off</mark> Middle On Differences Off

| Toggling of switches | $On \leftrightarrow Off$ . |
|----------------------|----------------------------|
|----------------------|----------------------------|

Default switch: as shown in the screen shot.

**Single values:** Recording the single values from both faces.

Mean: Recording the mean from both faces.

Differences: Recording the differences between both faces measurements

#### 🕿 Tip

For various recording modes the following is applied:

- **R-M** Recording of the original measurements or the mean, resp., and/or the differences between them.
- **R-C** Recording of the respective computation values in the same way.
- **R-MC** Recording of measurement and computation values in the same way.

| 2-Face Measuring | 2 |
|------------------|---|
| Error Limits     | 2 |

Input of the error limits for the measurement in 2 faces.

| $\mathscr{K}  0.0000 \leq da \leq$ | 1 | grad |
|------------------------------------|---|------|
|------------------------------------|---|------|

| 0.000 | $\leq dc$ | ı∕dl/dh | ≤ 1 | m |
|-------|-----------|---------|-----|---|
|-------|-----------|---------|-----|---|

| 92422 2-Face                         | Measure. Err                 | or Limits   |
|--------------------------------------|------------------------------|---|
|                                      | da :<br>dq :<br>dl :<br>dh : | 0 <mark>.0050</mark> gon<br>0.020 m<br>0.020 m<br>0.020 m |
| Input in the prec<br>measuring units |                              | Default value:  |
| Bearing deviat                       | ion da:                      | 0.0050 grad   |
| Transverse dev                       | viation dq:                  | 0.020 m   |
| Longitudinal d                       | ev. dl:                      | 0.020 m   |
| Height deviation                     | on dh:                       | 0.020 m   |
|                                      |                              |   |

#### 🖝 Tip

4

3

If one value is set to  ${\bf 0},$  this error limit will not be checked.

### General Functions

**Control Point** 

Input of the error limits for the control point measurement.

| 9243 Control Point Error Limits   |   |  |
|---|---|--|
| Linear Dev. dr :<br>Angle Dev. da :<br>Orthog. Dev. dq :<br>Lateral Dev. dl : | 0 <mark>.030</mark> m<br>0.0050 gon<br>0.020 m<br>0.020 m |  |
| Input in the predefined measuring units of                                    | Default value:  |  |
| Linear deviation dr:  | 0.030 m   |  |
| Bearing deviation da:   | 0.0050 grad   |  |
| Transverse deviation dq:  | 0.020 m   |  |
| Longitudinal dev. dl:   | 0.020 m   |  |
|   |   |  |

#### 👁 Tip


If one value is set to  ${\bf 0},$  this error limit will not be checked.

| General Functions 4 9245 Configure Identical Points |   | l Points   |                  |
|---|---|--|------------------|
| Identi  | cal Points 5  | Radial Dev. dr :   | 0 <b>.0200</b> m |
| •   | of a linear deviation<br>ecision of identical<br>s. | Input in the predefined measuring unit of  | Default value:   |
| Ľ   | $0 \leq dr \leq 1 m$                                | Linear deviation dr:   | 0.020 m          |
|   |   | <ul> <li>Tip</li> <li>When setting the value for a default value is used international setting the value setting the value is used international setting the value setting the v</li></ul> |                  |

### **Configuration Standard Settings**

| Programs 2  | 92 Program Configuration  |
|---|---|
| Default Settings 0  | Stationing 1<br>Coordinates 2<br>Special 3<br>Gen. Functions 4<br>Project Info 5 Default Set. 0 |
| Setting of standard values for all program configurations | Project Info 5 <u>Default Set</u> . 0   |
|   | Select with an or 0.  |
|   | 92 Program Configuration<br>Standard Settings   |
|   | Sta<br>Coo<br>Spe<br>Gen <u>Yes No</u><br>Project into <u>percent</u> O                         |
|   | Yes For setting default (standard) values.  |
|   | No default settings, back to menu<br>Configuration Programs.                                    |
|   |   |

### **Configuration Markings**



## Generating and processing markings for the point identification.

The 27-digit point identification (PI) can be occupied with different blocks:

| • | Point number block | <ppp><br/><nnn></nnn></ppp> |
|---|--------------------|-----------------------------|
| • | Text block         | <eee><br/>&lt;###&gt;</eee> |
| • | Code block         | <ccc></ccc>                 |
|   |                    |                             |

- Time block <ttt...>
- Spaces block >---..<

A multiple definition of text and code blocks is possible.

Only one point number block and one time block can be defined at a time.

 $\varkappa$  1  $\leq$  number  $\leq$  10 A maximum of 10 markings can be entered.

#### 🕿 Tip

The instrument is delivered with a standard setting of marking No. 1 which can be overwritten by another marking.

As pre-request for the storage of a marking, at least one point number block must be set.

- **Esc** for escaping the Configuration Markings.
- Store marking

Marking No. 1 is the

Marking No. 1 is the standard marking.

#### **Processing of set markings**

Legend of the lines:

- 1 Action
- 2 Operation
- 3 Ruler
- 4 Field label
- 5 Control character
- 6 Block marking

After calling up the *Configuration markings*, the first marking which has been set is shown in the display:

| 1 — <mark>93 Marking list</mark>   | Nr. | 1/3 |
|--|-----|-----|
| 3 - 123456789-123456789-1234567<br>4 - <pnr> <info><br/>5 - C I</info></pnr> |     |     |
| 6  |     |     |
| New Del  | Edi | t   |

Nr. 1/3 indicates the consecutive number (1) of the displayed marking out of all defined markings (3).

- **EXAMPLE** Scrolling in the marking list (endless)
- Home Display of the first marking
- End Display of the last marking set
- Activation of input (like Edit)
- Esc Back to menu Configuration
- New generate new marking
- Del delete displayed marking
- Edit edit displayed marking

#### **Delete marking**




Yes Marking is deleted, renumbering of the remaining markings.

No Back, without deletion of marking.

Esc similar to **No**.

Edit marking in analogy to Marking New

### **Generating new Markings**



The field label is an information which can be entered in addition to the blocks set.

## Input of the field label

For the input, all alphanumeric characters, including special characters, are available.

| 931 Marking definition   | Nr.<br>End: | <b>4/4</b><br>Esc |
|--|-------------|-------------------|
| 123456789-123456789-1234567<br><b>{Point NoXCodeXDescriptn</b> } |             |                   |
| Tabs Curs List PNr Code  | Time Del    |                   |

Ins Del usable for editing.


The code field is stored with the marking.

### 🕿 Tip

In a measuring program, the field label is used as orientation for the blocks set. Consequently, it should be entered in that way.

### PNr

Set point number block



Go with the cursor control keys to the initial posi-

Selection type of point number (numeric or alphanumeric point number).

For entering a point number in the measurement menu then will be defined:

Numeric only numbers in the block ,

Alpha-Numeric all signs allowed.

Setting the point number block

tion of the point number block.



alpha-numeric

Via **alpha-numeric** selection the block is marked with  $<\mathbf{p}>$  in line 6 (block marking), beginning at the current cursor position.

| Point number field<br>End position: ← →                              | Nr.<br>End: | 2⁄2<br>↓ |
|--|-------------|----------|
| 123456789-123456789-1234567<br><pnr< td=""><td></td><td></td></pnr<> |             |          |
| C<br>< qqqqqqqqq   |             |          |
| Tabs Curs List PNr Code  | TimelC      | )el      |

Via **numeric** selection the block is marked with **<n>** in line 6 (block marking), beginning at the current cursor position.

| Point number field<br>End position: ← → | Nr.<br>End: | 2∕2<br>↓ |
|---|-------------|----------|
| 123456789-123456789-1234567<br>KPNr     |             |          |
| <pre><nnnnnnnn></nnnnnnnn></pre>        |             |          |
| Tabs Curs List PNr Code                 | Time        | Del      |

<n> numeric

Ľ

### 🕿 Tip

The characters < > belong to the block, therefore, the minimum size or <n> comprehends 3 characters.

As proposal, the default cursor position (**C** in line 5) is set on the first place within the PNr block, but that can be changed any time with **Curs**.



go to final position of the PNr block.

 $3 \le PNr block \le 14$  A maximum of 14 characters can be set for the PNr block.



Accept point number block.

### 🕿 Tip

When pressing **PNr** then at another place of the PI, the old entry in the block marking is deleted and set again at the new position.

| Setting | а | text | or | code | block |
|---------|---|------|----|------|-------|
|---------|---|------|----|------|-------|

A maximum of 5 blocks can be defined as text or code blocks. There is as well a numerical or an alphanumerical selection possible.

# Configuration When entering the PI, a *codelist* can be accessed within the code blocks.

Go with the cursor control keys to the initial position of the text or code block.

| Code | Set text or code |
|------|------------------|
|      | block            |

| Text and Code field<br>End position: ← →   | Nr. 4<br>End: ∢ | 4 |
|--|-----------------|---|
| 123456789-123456789-1234567<br><point no=""><code<b>D<descriptn><br/>C T <pppppppp><eee></eee></pppppppp></descriptn></code<b></point> |                 |   |
| Tabs Curs List PNr Code  | Time Del        |   |

Via **Code**, the block is marked with **<>** in line 6 (block marking), beginning at the current cursor position. This is the minimum size of a text or code block. Each alphanumerical code block is being marked as block <eeeee...>, each numerical as block <#####...>.

### 🕿 Tip

As proposal, the default tabulator position (**T** in line 5) is set on the first place within the text or code block, but that can be changed any time with **Tabs**.

 $\leftarrow \rightarrow$ 

go to final position of the text or code block.

 $\swarrow$  2  $\leq$  text block  $\leq$  24


A maximum of 24 characters can be set for a text or code block.

Accept text or code block.

### Allocating a codelist

It is possible to allocate a codelist to a text block set, converting thus the text block into a code block.

Set the cursor on the text block destined to become the code block.



With **List**, all selectable codelists are offered. If no codelist has been defined yet, the softkey **List** has no effect.



for selection (also various codelists).

Allocation of all marked codelists and back to the menu.

| 931 Marking definition  | Nr.<br>End: | <b>4/4</b><br>Esc |
|---|-------------|-------------------|
| 123456789-123456789-1234567<br>{Point NoXCode>{Descriptn>                           |             |                   |
|   |             |                   |
| <pre><pre><pre><cccc xeeeeeeee=""></cccc></pre> Tabs Curs List PNr Code</pre></pre> | Time Del    |                   |

The block marking <eee...> has now been replaced by the block marking <ccc...>.

### 🕿 Tip

It is also possible to allocate a codelist subsequently in a marking that has already been generated.

List

Allocating a codelist

### Configuration Instrument / Clock

Set time block

Time

## Setting a time block

urationIn this field, the system time is automaticallyent / Clockstored in the time format specified.A time block cannot be set within another block.

Select with the cursor control keys the initial position of the time block.

| 931 Marking definition   | Nr.<br>End: | <b>4/4</b><br>Esc |
|--|-------------|-------------------|
| 123456789-123456789-1234567<br><point no=""><code><t<b>Dme&gt;<txt><br/>C T<br/><pppppppp><cccc><tttt></tttt></cccc></pppppppp></txt></t<b></code></point> |             |                   |
| Tabs Curs List PNr Code  | Time Del    |                   |

Via **Time**, the block is marked with **<ttt>** in line 6 (block marking), beginning at the current cursor position.

## 🕿 Tip

If the space available between the initial position and the marking end or the next block is not sufficient for the configured time format, the softkey **Time** has no effect.

<pppp>----<cccccc>

## Setting a space block

At the beginning of a marking definition all places of the marking are occupied by forced blanks (------ in the block marking, line 6). By specifying blocks, these blanks are occupied accordingly.

With the initial positioning of blocks, blanks can be set between the blocks which are then locked when entering the Pl and for tab stops.

|      |                                      | Further function keys   |
|------|--------------------------------------|---|
| Del  | Deleting blocks                      | Set the cursor into the block range and delete the block with <b>Del</b> (attention, without enquiry!).   |
|      |                                      | Tip<br>For changing initial positions, the blocks are<br>first to be deleted.   |
| Tabs | Setting tab stops                    | Tab stops can be set at any position (exception:<br>forced blanks). A tab stop can be set in each<br>defined input block. When entering the PI, the<br>cursor jumps to this position by means of the  |
|      |                                      | 🔄 key.  |
|      |                                      | Go to the target position using the cursor control<br>keys and set a tab stop with <b>Tabs</b> . A <b>T</b> will appear<br>in line 5 (control characters). The tab stop can be<br>deleted again with the <b>Del</b> softkey.  |
| Curs | Setting a default<br>cursor position | The default cursor position can be set at any<br>position (exception: forced blanks). For each<br>marking, only one default cursor position can be<br>set. The cursor jumps automatically to this<br>position after a measurement for entering or<br>editing the PI.  |
|      |                                      | Go to the target position using the cursor control<br>keys and set the position with <b>Curs.</b> A <b>C</b> will<br>appear in line 5 (control characters). If a tab stop <b>T</b><br>has been set at the same place, this will be<br>overwritten by <b>C</b> . The cursor position is of equal<br>importance to the tabulator. |

### 🕿 Tip

When setting **Curs** at another place, the old **C** is being deleted.

### **Store marking**


**Esc** for quit in the menu of the *Configuration markings* leads to the enquiry:

|  | -   |                   |
|--|---|-------------------|
| Mark   | ing definition  | 10r 4/4<br>Esc    |
| 123<br>(Po                                     | Save Changes ?  |                   |
| 0<br><pp< th=""><th></th><th>Yes No</th></pp<> |   | Yes No            |
| Tabs   | Curs List PNr Code  | 2 Time Del        |
| Yes  | Acceptance of the m<br>consecutive number<br>display of the renum       | r, continues with |
| No   | Marking is not accept<br>of the marking list is<br>established. Back to | s being re-       |

Esc Back to the definition of the new marking.

markings.

## **Configuration Codelists**



Creating a new

New

For objects of everyday surveying, coded point information can be managed in the form of codelists.

Thus, they can be allocated quickly and simply to a code block of the marking and, consequently, to the PI during the measurement.

After being called up from the configuration menu, the codelists already generated are displayed:

| 94 Codelists  |                              |
|---|------------------------------|
| Lines<br>Roadlines<br>Backsights<br>Points<br>Buildings | Linear Objects<br>Topography |
| New Del Conn Copy Name                                  | Edit                         |

A maximum of 16 lists can be stored. Having reached this number, the functions **New** and **Copy** are no longer available.


The number of codes per list depends on the available memory.

### **Processing codelists**

codelist

| Del  | Delete a codelist           | 94 Codelists<br>Li<br>RO<br>Ba<br>Po<br>Roadlines<br>Bu<br>Ves No<br>New Det Conn Copy Name<br>Edit   |
|------|-----------------------------|---|
|      |                             | Yes Deletion of selected codelist.  |
|      |                             | No (or <b>Esc</b> ) Back, without deletion.   |
| Conn | Connecting two<br>codelists | Select the first codelist with the cursor control keys, then, select <b>Conn</b> in order to connect the first with a second list out of the remaining codelists. |
|      |                             | Confirm the selection of the second codelist with   |
|      |                             | <b>↓</b> .  |

## **Configuration Codelists**



Copy Copying the selected codelist

Name Renaming the selected codelist Select codelist with the cursor control keys, select then **Copy** or **Name** in order to copy or rename the list.



**Name:** Data string with a maximum of 18 alphanumeric characters.

List is copied with new name or renamed.


Esc Back to menu Codelists.

### 🕿 Tip

Codelists cannot be copied or renamed using the same name with the same ASCII characters.

But a difference is made between upper-case and lower-case letters, i.e. names like *LIST* and *List* are different.

### Generating new codelist



## **Editing codelist**

Edit Editing an existing codelist

Set the cursor at the codelist to be edited and select **Edit**:



Example: Editing the codelist *point type*.

| Code: | A maximum of 10          |
|-------|--------------------------|
|       | alphanumeric characters. |

Meaning: Description of the code with a maximum of 20 alphanumeric characters.

### 🕿 Tip

In the application program, the **Code** is transferred into the code block allocated to the list.

## Admissible keys for editing codelist

|     |                          |                                  | PgU <sup>p</sup> PgD <sub>n</sub>                                   | Scrolling in              | n the codelist | t. |
|-----|--------------------------|----------------------------------|---|---------------------------|----------------|----|
|     |                          | Home End                         | Junp  | to the first on of the in |                |    |
|     |                          |                                  | Changing the<br>and meaning.  | input field b             | etween cod     | e  |
|     |                          | F A                              | Accepting cod   | e input in lis            | st.            |    |
|     |                          | Esc                              | scape editing   | of codelist.              |                |    |
| New | Entering a new<br>code   | New Del                          | le HP<br>icr. <u>Hei</u>  | -<br>h ?↓                 |                |    |
| Del | Delete code              | <b>Del</b> (atter<br>By this fur | onto the cod<br>ntion, no enqu<br>nction, the sel<br>ely and copied | uiry!).<br>ected code l   | line is delete |    |
| Ins | Inserting a code<br>line |                                  | e code line sav<br>f the marked o                                   |                           | uffer memor    | у, |
|     |                          |                                  | uently, with th<br>code lines ca<br>d.                              |                           |                |    |

## **Configuration Codelists**



Searching a code line

|     | Descr.         | 18                | ] |
|-----|----------------|-------------------|---|
|     | Code<br>Descr. | TP<br>Trig. Point |   |
| New | Del Ins        | Srch ?+           |   |


Search for code **or** meaning, also of partial strings. No attention is paid to upper-case or lower-case letters.

Search is carried out from the cursor position downwards. If the search is successful, the cursor jumps to the respective code position.

Esc Without search back to the editing menu.

**Continuing search** for a code line for a code line immediately by means of this function.

## **Configuration Update**



For activation of the software-packages it is necessary, to enter a code generated by Spectraprecision for the Elta CU.

There is one authorisation code for each software package. After input you get access to the software.

| 95 Update                |   |
|--------------------------|---|
| Input Authorisation Code | 1 |
|                          |   |
|                          |   |
|                          |   |

Menu Update Configuration.

951 Configuration Auth.-Code

Input Authorisation Code

1

Code Input for each software package.

| Package                | AuthCode         |
|------------------------|------------------|
| Basic                  | 291192           |
| Expert<br>Professional | 996972<br>125372 |
| Special                | 182315           |
|                        |                  |

Select the software-package by cursor-keys.


Edit

For code input / change

| 95.1<br>BE  | <u>Configuratio</u><br>DIT | n Auth -Pode                          | ]— |
|-------------|----------------------------|---------------------------------------|----|
| B<br>B<br>S | Package<br>AuthCode        | Professional<br> 1 <mark>25372</mark> |    |
|             |                            | Edit                                  |    |

Input of the authorisation code.

to confirm the code input.



The annex contains a compilation of symbols, keys, formulae and constants as well as explanations of concepts used for the Trimble 5600 series total station.

Furthermore, it gives an overview of the technical data and instructions for maintenance and care of the instrument. Important certificates are also attached.

## Symbols and Keys

**Geodetic Glossary** 

**Technical Data** 

Formula and Constants

Certificates

Index

## Symbols and keys

| Status Symbols: | The instrument displays status symbols to show internal instrument settings. |
|-----------------|--|
| a 🖪 🖏 a         | Symbols for Measure Mode   |
| <u> </u>        | SD Hz V HD Hz h Y X Z Hz V   |
| of              | Switch on Target Sensoring <sup>*</sup>                                      |
|                 | AutoLock   |
| ** ×            | Tracking*  |
|                 | Tracking switched on Tracking prism lost                                     |
| 2 7 8           |  |
|                 | Vertical Reference System  |
|                 | Zenith Vertical Height Slope [%]   |
|                 | Error Limits   |
|                 | switched off switched on   |
|                 | TrackLight   |
|                 | PositionLight on   |
| × *             | Illumination   |
|                 | Display on Cross hairs on  |
| P               |  |
|                 | Recording switched on  |
| L J             | Compensator switched on  |
|                 | <sup>*</sup> not for all instruments   |

## **Keys and Function**

| Escape        | Esc                       | Quitting program levels                  |
|---------------|---------------------------|--|
| Shift         | ①                         | Dual assignment switchover               |
| Tabulator     |                           | Selector and tab key                     |
| Caps          | $\left[ \uparrow \right]$ | Upper-case and lower-case letters        |
| Control       | Ctrl                      | Control and hotkeys                      |
| Function keys | F1 F                      | 10 Softkeys activation                   |
| Space key     |                           | Space and selector key                   |
| Cursor keys   |                           | Positioning the Cursor up/down           |
| Cursor keys   |                           | Positioning the Cursor to the left/right |
| Numeric block | 0                         | 9 Numeric input function                 |
| Enter key     |                           | Confirmation + measurement triggering    |
| Power key     | PWR                       | Switching the instrument on              |
| Page Up       | PgU <sup>p</sup>          | Scrolling up                             |
| Page Down     | PgD <sub>n</sub>          | Scrolling down                           |
| Home          | Home                      | Cursor at the start of line or list      |
| End           | End                       | Cursor at the end of line or list        |
| Alt key       | Alt                       | In connection with Ctrl and MS-DOS®      |

## Symbols and Keys



### **Hotkeys and Function**

The most hotkeys are available in every program level. The unit switches only in the measurement menus.

| Ctrl B | <b>B</b> attery control  |
|--------|--|
| Ctrl H | <b>H</b> elp   |
| Ctrl   | Illumination Display + Crosshair   |
| Ctrl L | Levelling Compensator  |
| Ctrl M | Indication of $\mathbf{M}\textsc{emory}$ capacity (RAM)                                |
| Ctrl T | Indication of Date and $\mathbf{T}$ ime  |
| Ctrl D | Switch <b>D</b> istance measurement units on <b>m / ft</b>                             |
| Ctrl A | Switch Angle measurement units on<br>gon / dms / deg / mil in the<br>measuring program |
| Ctrl Z | Switch the vertical reference system   |
| Ctrl S | Instrument <b>S</b> tatus  |
| Ctrl P | Switch the PositionLight <b>on / off</b>   |



Ctrl R Direct Reflex Mode\*

This key code is only useful in the MS-DOS® mode.

| Ctrl Alt → | Scroll display to the right |
|------------|-----------------------------|
| Ctrl[Alt]→ | Scroll display to the right |

Ctrl Alt Scroll display down

Ctrl Alt 1 Scroll display up

Reboot of the ZEISS Elta CU® PC

Ctri Alt Del Reboot of the ZEISS Elta CU® PC

## Attention !

In case of reboot the ZEISS Elta CU® in an application programm measurement data or other important settings ca be lost.

|                                 | A   |
|---------------------------------|---|
| Addition correction             | Correction of the addition value ("additive constant") of the distance measuring instrument   |
| Auto Lock=<br>Precise detection | Target focussing by means of sensors, realised<br>automatically and independent of the observer, as<br>well as automatic, motorised readjustment of the<br>instrument   |
|                                 | В   |
| Backsight point                 | A point with known coordinates used for the station point determination and/or for <i>orientation</i> .   |
| Bearing angle                   | Hz bearing orientated to a reference bearing (generally to grid north)  |
| Bearing (Hz)                    | Value read in the horizontal circle of the instrument, whose accidental orientation is determined by the zero position of the graduated circle.   |
|                                 | C   |
| Calibration scale               | Influences systematically the distance<br>measurement. Best possible adjustment to 1.0 by<br>the manufacturer. Without influence on all other<br>scale specifications   |
| Code, code lists                | Reference number for the point description, characterises certain point types, compilation and explanation in <i>code lists</i>   |
| Compensation                    | Mathematical consideration of the <i>vertical axis</i><br><i>inclinations</i> measured with the <i>compensator</i> , in<br>Hz and V angle measurements  |
| Compensator run centre          | electronic centre of the instrument in sighting and trunnion axis directions  |
| Configuration                   | Basic settings of the instrument (e.g. measuring<br>units, coordinate system etc.). Proceeding from<br>the respective measuring program, it is possible to<br>access locally the relevant configuration. The<br>configuration can be transmitted to other<br>instruments/computers. |

| Connecting distance   | Spatial distance, plane distance and height difference between 2 target points  |
|---|---|
| Control point   | Point for checking the <i>orientation</i> of the instrument. It is defined at the beginning of a measurement and can be measured any time for checking.   |
| Conventional  | Conventional control of the measuring process by the operator at the instrument.  |
| Coordinates, global   | higher-order coordinate system (e.g. Gauss-<br>Krüger)  |
| Coordinates, local  | Zero of this coordinate system is the station point<br>of the instrument with the coordinates (0,0,0).<br>The <i>orientation</i> is determined by the zero direction<br>of the Hz circle  |
|   | D   |
|   |   |
| Distance measuring method   | Variable measuring time (and with it measuring<br>accuracy) in accordance with the purpose of<br>application:<br>Normal <b>D:N</b> , Tracking <b>D:T</b>  |
| Distance measuring method   | accuracy) in accordance with the purpose of application:  |
| Distance measuring method<br>Eccentricity = eccentric<br>target measurement | accuracy) in accordance with the purpose of application:<br>Normal <b>D:N</b> , Tracking <b>D:T</b>   |
| Eccentricity = eccentric  | accuracy) in accordance with the purpose of<br>application:<br>Normal <b>D:N</b> , Tracking <b>D:T</b><br><b>E</b><br>The reflector is not set up right in the target point,  |
| Eccentricity = eccentric<br>target measurement                              | accuracy) in accordance with the purpose of<br>application:<br>Normal <b>D:N</b> , Tracking <b>D:T</b><br><b>E</b><br>The reflector is not set up right in the target point,<br>but in a defined position to it.<br>Switch for toggling <i>eccentric target point</i> |

## F

| Free Stationing            | Free choice of the station. The measurements to<br>known <i>backsight points</i> are taken as starting<br>point for computing the station coordinates, the<br><i>scale</i> and the orientation of the graduated circle<br>by <i>single point adjustment</i> or <i>Helmert</i><br><i>transformation</i> |
|----------------------------|--|
|                            | н  |
| Height stationing          | The height of the station point is derived from measurements to known height points  |
| Helmert transformation     | <i>Transformation</i> (similarity transformation) named after Helmert, between two rectangular coordinate systems, <i>free stationing</i>  |
| Hidden point reflector rod | Reflector rod with 2 reflectors arranged in a fixed<br>distance to each other; for the position and height<br>determination of inaccessible points such as<br>channels, shafts, room corners; can be held also in<br>oblique position to the point to be measured                                      |
| Hz collimation correction  | (also correction of collimation or sighting axis )<br>Correction of the deviation of the sighting axis<br>from its required position at right angles to the<br>trunnion axis. Determination by measurement in<br>two positions, automatic correction in<br>measurements in one position                |
|                            | 1  |
| Incrementing               | Input of an interval (increment), by which the point number is automatically counted   |
| Instrument height          | Height of the telescope trunnion axis above the station height (ground point)  |

| Interface            | Contact point between 2 systems or system areas,<br>in which information is interchanged according to<br>defined rules   |
|----------------------|--|
|                      | L  |
| Loss of contact      | During a <i>target tracking</i> one does not succeed in keeping the prism within the visual field of the <i>precise target detection</i>   |
| L1 Norm              | Adjustment in which the sum of the absolute<br>corrections is turned into the minimum, for<br>recognising outliers with special accuracy. In all<br>adjustments, an L1 adjustment can be additionally<br>calculated. |
| L2 Norm              | Adjustment in which the sum of the correction squares is turned into the minimum (adjustment according to the method of least squares)   |
|                      | 0  |
| Object height        | Determination of the height of points to which a<br>direct distance measurement is impossible, by<br>means of a pure angle measurement   |
| Orientation          | When orientating the instrument, the <i>bearing</i> angle of the zero of the graduated circle Omega  |
|                      | (Om) is calculated. For this, measurements to one<br>or various <i>backsight points</i> can be made or the<br><i>bearing angle</i> of a known point can be entered.  |
|                      | or various backsight points can be made or the   |
| Point Identification | or various <i>backsight points</i> can be made or the <i>bearing angle</i> of a known point can be entered.  |

| Prism Search                               | Methods for quick finding of a prism.   |
|--|---|
| Project                                    | Quantity of data sets, which are combined under<br>one name into an independent unit within the<br>database   |
| Projection reduction                       | Reduction into the projection plane   |
|  | R   |
| Radio data transmission<br>module Georadio | Radio communication between station and target<br>for transmitting data and information, 70 cm<br>band. Observe announcement.   |
| Recording mode                             | Switch in all measuring programs for controlling,<br>which data are to be recorded: measuring values,<br>computing values or both types   |
| Reference Point                            | used here as reflector station for the indirect height determination  |
| Refraction coefficient                     | Measure for the light-beam refraction in the atmosphere; can be set by the user   |
| Remote Control Unit RCU                    | Alphanumeric computer with radio data<br>transmission module Georadio for controlling the<br>measuring process from the target point  |
| Residual                                   | Difference between nominal and transformed coordinates  |
| Run center                                 | see Compensator run centres   |
|  | S   |
| Scale                                      | With a <i>scale</i> , the measured distance is varied proportionally to the length and can thus be adapted to certain marginal conditions. There exist a series of direct and indirect scale effects: <i>calibration scale</i> , <i>weather correction</i> , <i>projection reduction</i> , height reduction, reticule scale |

| Single point adjustment        | Method for computing a <i>free stationing</i> by adjustment of all distance and bearing observations according to the method of least squares.   |
|--------------------------------|--|
| Softkey                        | Function key which has different functions in dependence on the program  |
| Standard deviation             | Statistical value for the accuracy of a computed value   |
| Standard project               | Project implemented by the manufacturer (project name: NONAME), which can be used without project definition   |
| Standard settings              | Values set by the manufacturer, for all configuration parameters   |
| Stationing                     | Station point determination and/or calculation of<br>the orientation of the graduated circle:<br>stationing on a known point, free stationing and<br>off-centre station, height stationing (height only) |
| Stationing on a known<br>point | Given: Station point coordinates / backsight<br>bearing.<br>The <i>scale</i> and the <i>orientation</i> of the graduated<br>circle are derived from the measurements to<br>known <i>backsight points</i> |
|                                | т  |
| Target search                  | Quick search roundabout target sensor of the total station, for search and setting of prisms in the target area  |
| Target tracking                | Continuous tracking of the telescope in Hz and V<br>angles after the moving prism with the help of the<br>precise target sensor FineLock   |
| Time                           | The time can be displayed and recorded together with the measuring values in the <i>point identification</i>   |
|                                |  |

| Tracking                  | Continuous measurement of the angles and<br>distances. Generally, Hz and V values are always<br>measured and displayed; set permanent<br>measurement for distance measurements  |
|---------------------------|---|
| Track Light               | Quick optical sighting aid for setting out;<br>visualisation of the sighting line for the reflector<br>porter so that he can orientate himself<br>independently and quickly with reference to the<br>sighting line                |
| Transformation            | Computing program for converting point<br>coordinates between different coordinate systems.<br>At least 2 identical points have to be known in<br>both systems.   |
|                           | V   |
| Vertical axis inclination | The inclinations of the vertical axis of the instrument in sighting axis direction and trunnion axis direction are measured with the <i>compensator</i> . Digital and analogue representation of the inclinations on the display. |
|                           | W   |
| Weather correction        | Correction of the distance measurement by values<br>for temperature and air pressure which deviate<br>from the standard values  |
| Weighting specifications  | For the adjustment, a certain influence (direct or indirectly by specifying <i>standard deviations</i> ) on the total result can be assigned to the measuring values (stationing programs)  |

### **Electromagnetic Compatibility (EMV)**

The EU Conformity Declaration confirms the perfect function of the instrument in an electromagnetic environment.

### Attention!

Computers and radio devices connected to the Geodimeter® which are not part of the Trimble System delivery, have to meet the same EMV requirements in order to ensure that the overall configuration complies with the applicable interference suppression standards.

Interference suppression as per: EN 55022 class B

Noise immunity: EN 50082-2

### 🕿 Tip

Strong magnetic fields generated by mid and low voltage transformer stations possibly exceed the check criterions. Make a plausibility check of the results when measuring on such conditions.

## Zeiss Elta® Control Unit

| Display screen, | 8 lines by 40 columns, CGA graphic display  |
|-----------------|---|
|                 | (320x80 pixels), illuminated,<br>optional 2nd display face available  |
| Keyboard        | Full QWERTY alphanumeric keyboard   |
| Data recording  | Data stored on PC-Card ; storage capacity approx.<br>8000 data lines per 1 Mb.<br>Internal Flash disk approx. 3000 data lines .<br>Interface RS 232 C |
| Battery         | NiMH 700mAH   |
| Charging time   | 25min. with 350mA (Single Charger)  |
| Function time   | 20min. to 2h  |
|                 | If battery-low occurs, an error dialog is shown in the Zeiss Elta® Control Unit Display. There are two different warnings:                            |
|                 | Battery - Low - Voltage<br>- RCU -<br>Please change !<br>Press any key to continue  |
|                 | Opportunity to work after pressing any key - but only for a short time !  |
|                 | Battery - Low - Voltage<br>- RCU -<br>Please change immediately !   |
|                 | The battery change must be made within max.2 hours (full charged); otherwise the user has to restart the Zeiss Elta® Control Unit.                    |
|                 |   |

## **Technical Data**

### Modes of Operation

### **Remote Control**





**Robotic Control** 



### 👁 Tips

Select an exposed place, if possible, for setting up the instrument. Avoid valleys and depressions, the proximity of big buildings, metal (cars, bridges) and waters.

Turn the cable connections carefully tight

Do not kink or bend the cable connection extremely.

### Attention!

The Georadio is provided with a General Admission most countries of the world. If there should arise questions with reference to the application of the radio data transmission module in other countries than the above mentioned, please contact the trader in your country.

Active neighbouring radio equipments on the same transmitter frequency may possibly lead to adverse effects. In this case, please select other frequency.

The admission becomes ineffective in case of using another antenna ( $\lambda/2$  antenna or antenna with higher gain).

Please contact us for further instructions.

## Computations formula for angle measurement

| V angle measurement    | $V_k = V_0 + V_1 + V_2 + i + nz$  |
|------------------------|---|
|                        | $\begin{array}{l} V_{O} &= \text{uncorrected V circle reading} \\ V_1 &= \text{correction due to V circle eccentricity} \\ V_1 &= A_{V} \cdot \sin\left(V_{O} \cdot \phi_{V}\right) \\ A_{V} &= \text{amplitude} \\ \phi_{V} &= \text{phase} \\ V_2 &= V \text{ circle orientation} \\ i &= \text{index correction} \\ i &= \frac{1}{2}(400 - V_1 - V_1) \\ nz &= \text{current vertical axis inclination in the} \\ \text{sighting direction} \end{array}$ |
| Hz bearing measurement | $Hz = Hz_0 + Hz_1 + Hz_2 + Hz_3 + Hz_4 + A$   |
|                        | Hz <sub>o</sub> = uncorr. Hz circle reading-(absolut)   |
|                        | $\begin{array}{ll} \text{Hz}_1 = \text{ corr. due to Hz circle eccentricity} \\ \text{Hz}_1 &= A_{\text{Hz}} \cdot \sin\left(\text{Hz}_{\text{O}}\text{-}\phi_{\text{Hz}}\right) \\ A_{\text{hz}} &= \text{ amplitude} \\ \phi_{\text{Hz}} &= \text{ phase} \end{array}$  |
|                        | $Hz_2 = due to collimation correction$<br>$Hz_2 = c/sin V_k$  |
|                        | $c = -\sin(V_{\parallel}) \cdot \frac{dHz}{2}$  |
|                        | $\begin{array}{ll} dHz &= (Hz_{II} - Hz_{I} + 200) \\ Hz_{II_{i}} Hz_{I} &= Hz \text{ in Lage 1,2} \end{array}$   |
|                        | c = collimation error   |
|                        | $\begin{array}{ll} Hz_3 = \mbox{ due to current } nk \mbox{ vertical axis inclination in the tilting axis direction} \\ Hz_3 & = \mbox{ nk/tan } V_k \end{array}$   |
|                        | $Hz_4 = corr. due to tilting axis error k$<br>$Hz_4 = k/tan V_k$  |
|                        | A = circle orientation, e. g. Hz setting<br>(necessary for computations of coordinates)   |

### **Computations formula for distance measurement**

| Internal correction formula<br>(with correction from<br>external calibration) | $f D_{c1}$<br>$f D_u$<br>$f m_{cal}$<br>$f Ak_{cal}$                                     | <ul> <li>= D<sub>u</sub> · m<sub>cal</sub> + Ak<sub>cal</sub></li> <li>= uncorrected measured distance</li> <li>= scale from external calibration</li> <li>= addition constant from external calibration</li> </ul>              |
|---|--|--|
| Weather correction<br>formulae with additional<br>constants.                  | D <sub>c2</sub><br>D <sub>c1</sub><br>A <sub>c</sub><br>K <sub>W</sub><br>T <sub>r</sub> | $= D_{c1} (1+K_w 10^{-6})+A_c + T_r$<br>carrier wavelength 0.85 µm<br>precision scale 3 m<br>= corrected distance<br>= addition constant<br>= weather correction<br>= threedimensional eccentricity<br>(value input in menu 912) |

The weather correction  $K_w$  is computed as follows:

| K <sub>w</sub> | $= 281.8 - \left[ \frac{0.29065}{1 + \alpha t} P - \frac{4.126 \cdot 10^{-4} h}{1 + \alpha t} E \right]$ |  |  |
|----------------|--|--|--|
| р              | = air pressure in hPa  |  |  |
| t              | = temperature in degrees Celsius   |  |  |
| h              | = relative humidity in %   |  |  |
| α              | = coefficient of vapour pressure cor-  |  |  |
|                | rection 1/273,16   |  |  |
| Е              | = saturation aire presure to   |  |  |
|                | Magnus Tetens  |  |  |
|                | $\frac{7,5 \cdot t}{1,5 \cdot t} + 0.7857$   |  |  |
| Е              | $= 10^{\frac{7,5\cdot t}{t+237,3}+0.7857}$   |  |  |
|                |  |  |  |

In case of standard atmospheric conditions with p = 1013,25 hPa, t = 12 °C und h = 60% the correction K<sub>w</sub> disappears. The basic value of h = 60% for the relative humidity is fixed. When the conditons are very extremly (humid and hot) the deviation of weather correction is maximal 2 ppm.

## **Reduction formula**

| V angle measurement      | Refrakti   | Refraktion correction of the V angle measurement   |  |
|--------------------------|--|--|--|
|                          | V′   | $= V_{k} + \frac{\delta}{2} = \frac{D_{k2}}{2R} \cdot k_{L} \cdot \rho$  |  |
| Distance measurement     | Horizontal distance in the instrument horiz  |  |  |
|                          | E  | $= \frac{R}{\rho} \cdot \arctan \frac{D_{k2} \cdot \sin V'}{R + D_{k2} \cdot \cos V'}  \rho = \frac{200}{\pi}$   |  |
| Height difference        |  | d are corretions of refraction, earth<br>re, instrument- and reflector height  |  |
|                          | dh   | $= D_{k2} \cdot \cos V_k + \frac{1 - k_L}{2R} \cdot E^2 + ih - th$   |  |
|                          | V <sub>k</sub><br>k <sub>L</sub><br>R  | <ul> <li>corrected V circle reading</li> <li>influence of refraction,</li> <li>Default: 0.13</li> <li>mean earth radius in the field,</li> <li>Default: 6 370 000 m</li> </ul>           |  |
|                          | ih<br>th   | <ul> <li>instrument height</li> <li>reflector height</li> </ul>  |  |
| Horizontal distance with | E <sub>m</sub>   | = E • m  |  |
| scale correction         | Е  | = horizontal distance in the instrument  |  |
|                          | E <sub>m</sub>   | horizon<br>= horizontal distance with scale corr. m<br>= scale (e.g. from Free Stationing)   |  |
| Height reduction         | Reduction of horizontal distances from instrument horizon into the used projection horizon (e.g. NN) |  |  |
|                          | $E_m = di$<br>$E_o = di$<br>= mear   | $E_m \cdot \frac{R}{R+H}$<br>istance in the instrument horizo [m]<br>istance in the used projection horizon[m] R<br>in earth radius in the project [m]<br>mean height in the project [m] |  |

Reduction into the projection plane

The distance is reduced into the projection plan with the mean distance from the main meridian.

### 1. Gauß - Krüger - Projection

$$E_{GK} = E + k_{GK} \qquad k_{GK} = E \cdot \frac{Y_m^2}{2R^2}$$
$$E_{GK} = E \left(1 + \frac{Y_m^2}{2R^2}\right) = E + E \cdot \frac{Y_m^2}{2R^2}$$

with:

| E               | = Distance between two points       |
|-----------------|-------------------------------------|
| E <sub>GK</sub> | = distance in the Gauß-Krüger-Plane |
| Y <sub>m</sub>  | = mean distance from the main meri- |
|                 | dian                                |
| R               | = earth radius                      |

#### 2. UTM - Projection

$$\mathbf{E}_{\text{UTM}} = \mathbf{E} \cdot \mathbf{0}, 9996 \left( 1 + \frac{\mathbf{Y}_{\text{m}}^2}{2R^2} \right)$$

Note:

Distances used in stationing and e.g. in a subsequent polar survey must be treated identically. If, for example, no height and projection reductions have been applied in stationing, this must also not be done in the polar survey. In this case, the corresponding reduction is incorporated in the randomly selected scale or in the stationing corrections, if a given scale is used. In the latter case, it is always advisable to perform a best-fit adjustment if major corrections are involved.

### **Verifying on Calibration Distances**

Basically, all measured distances are corrected with reference to: the entered scale the entered additive constant the influence of pressure and temperature internal influencing variables.

### Attention!

Prior to the practical realization of the calibration measurement, the current values of the parameters additive constant, pressure and temperature are to be entered. Projection reduction and height reduction are to be deactivated and the scale is to be set to default: 1.000000, as the test distances normally are not referred to sea level. This is to secure that all corrections are made completely and perfectly. Furthermore, this allows a direct comparison of nominal and actual values.

If a weather correction is to be carried out externally, the temperature must be set to 12°C and the air pressure to 1013.25 hPa. Then, the internal correction goes to zero. Formulae formula

### **Prism and Additive Constants**

All total stations manufactured by Trimble AB, in combination with their reflectors are adjusted with the **additive constant 0.000**.

In case of measurements to reflectors of other manufacturers, a possibly existing additive constant can be determined by measurement and entered.

Another possibility consists in calculating an additive constant by means of the known prism constant of the reflector used and entering it. This prism constant is calculated as function of the geometric value of the prism, the type of glass and the place of the mechanical reference point. The prism constant for reflectors of Zeiss determined that way is -**35 mm or –3mm**.

It is necessary to enter the prim constant, and the addition constant isn't readable.

The calculation and the save function were not modified, only the method used to display.

Prism constants K:

#### Carl Zeiss :

| KTO            | -35 mm |
|----------------|--------|
| KTR            | -35 mm |
| KTM            | -35 mm |
| Mini prism Kit | -18 mm |
| 360°Prism      | - 3 mm |
| Trimble        |        |
| Super prism    | 0 mm   |
| Prism ring     | 2 mm   |
|                |        |

Please enter the correct value.

In case of measurements to reflectors of other manufacturers the user has to enter the prism constant and check the correctness by measurements to known distances.

Storage:

The connection between addition constant A and prism constant is shown in the following calculation formula:

$$A = P_{F} + 35 \text{ mm}$$

Example:

 $\begin{array}{ll} \mbox{Foreign reflector} & \mbox{prism constant P}_{\rm F}= & -30 \mbox{ mm} \\ \mbox{Addition constant in connection with this foreign} \\ \mbox{reflector} & \mbox{A}= & + \ 5 \mbox{ mm} \\ \end{array}$ 

In this case, in the Geodimeter  $\ensuremath{\mathbb{R}}$  additive constant + 0.005 m can be set optionally.

### Certificate of Type Approval

Telecommunications Act 1986 (0.12): Section \$6

Radiocommunications Agency

Page 1 of 2

| APPROVAL No.                 | : 10770   |  |
|------------------------------|---|--|
| ISSUE No.                    | r 1   | ORIGINAL CERTIFICATE DATE : 23 August 94 |
|                              |   |  |
| SUBMITTED BY<br>GEOTRONICS A |   | MANUFACTURED BY :                        |
| 80X 54                       |   | GEOTRONICS AB                            |
| 5162 11 DAND                 | FPYD  | BOX 64<br>S182 11 DANDERYD               |
| SWELEN                       |   | SWEDEN                                   |
| 3                            |   | 0.2220                                   |
|                              |   |  |
|                              |   |  |
| -                            |   |  |
|                              | PE ( AFPROVED EQUIPMENT<br>TEGORY : LOW POWER TELEMETRY |  |
| TRADE NAME                   | GEODIMETER  |  |
| TYPE NO.                     | : 571202234   |  |
|                              | • \$\12\$\$\$\$#  |  |
| TEMPERATURE                  | RANGE : -10°C to +55°C                                  |  |
|                              |   |  |
| SFECIFICATIO                 |   | (S) CHANNEL SEPARATION(S)                |
| MP71329 NOV                  | Sé 16KOFID  | 25.0×Hz                                  |
| TODAL UNIT                   | S ! 1   |  |
| UNIT NO 1                    | TYPE : TRANSCEIVER                                      |  |
| 0011 001 1                   | IIPE : IRANSCEIVER                                      | MOBILE                                   |
|                              | FOWER CHARACTERISTICS -                                 |  |
|                              | R.F. POWER : 100mW                                      |  |
|                              | TERMINATED  | FIXED                                    |
|                              |   |  |
|                              | FREQUENCY CHARACTERISTICS -                             | TRANSMITTER : 458.5MHz to 458.8MHz       |
|                              |   | RECEIVER : 458.5MHz to 458.8MHz          |
|                              |   |  |
| COMMENTS :                   | THE USE OF THIS EQUIPMENT MAN                           | BE SUBJECTED TO THE ISSUE OF >           |
|                              | LICENCE.  |  |
|                              | TOTAL NUMPED OF   | VARIANTS : 0                             |
|                              | LOTAL NURBER OF   | TARIANTA I V                             |
|                              |   |  |
|                              |   |  |
|                              |   |  |
|                              |   |  |
|                              |   |  |
|                              |   |  |
|                              |   |  |
| MPT 132                      |   |  |
| W.T. LICEN                   |   | ·  |
| EXEMPT                       | ال  |  |
|                              |   |  |
|                              |   |  |

CTA1

#### Certificate of Type Approval

Colonempiristations Let 1784 (4,13) Dertins 24

#### Contraction of the Lines of the y

1000 12 51 2

APPROVAL NO. : 10770 ISSUE No. : 1

ORIGINAL CERTIFICATE DATE : 23 August 94

THE SECRETARY OF STATE FOR TRADE AND INDUSTRY APPROVES FOR THE TIME BEING UNDER SECTION 84 OF THE TELECOMMUNICATIONS ACT 1984 THE EQUIPMENT DESCRIBED ABOVE PROVIDED IT COMPLIES WITH THE ABOVE SPECIFICATIONS AT ALL TIMES FOR THE PURPOSES OF : LICENCES GRANTED UNDER SECTION 1 OF THE WIRELESS TELEGRAPHY ACT 1949 AND/OR ANY EXEMPTION REGULATIONS MADE UNDER THAT SECTION.

SIGNED ON BEHALF OF THE SECRETARY OF STATE :

JOHN POOLE 23 August 94


ADDRESS FOR QUERY : Radiocommunications Agency, Room 514, Waterloo Bridge House Waterloo Road, London, SE1 8UA

END OF CERTIFICATE

#### FEDERAL COMMUNICATIONS COMMISSION

WASHINGTON, D.C. 20564

#### GRANT OF EQUIPMENT AUTHORIZATION



| Α | Addition correction                | 9-4; 10-6 |
|---|------------------------------------|-----------|
|   | Formula                            |           |
|   | Additive constant                  |           |
|   | Formula                            |           |
|   | Input                              | 3-8       |
|   | Adjustment                         |           |
|   | Eccentric station                  |           |
|   | Free stationing                    |           |
|   | Heightstationing                   |           |
|   | Adjustment procedure               |           |
|   | Configuration                      |           |
|   | Authorisation Code                 |           |
|   | Autolock™ (only for servo          |           |
|   | instruments)                       | 2-15      |
|   | ,                                  |           |
| В | Backsight points                   | 4-2: 4-16 |
| - | Battery                            |           |
|   | Charging the battery               | 10-14     |
|   | Battery management                 |           |
|   | Bearing angle input                |           |
|   | Before measurement                 |           |
| ~ |                                    |           |
| С | Calibration scale                  |           |
|   | Centering                          | 3-2       |
|   | Circle shift                       |           |
|   | Eccentric station                  |           |
|   | Free stationing                    |           |
|   | Stationing on a known point        |           |
|   | Coarse Levelling                   |           |
|   | Code block                         | 9-37      |
|   | Codelists                          |           |
|   | Configuration                      |           |
|   | Using codelists                    | 3-11      |
|   | Compensator                        |           |
|   | Adjustment                         |           |
|   | Symbol                             |           |
|   | Compensator run center determinate |           |
|   | Connecting distances               | 5-8       |

|   | Control point                    | 3-17; 9-23; 10-7 |
|---|----------------------------------|------------------|
|   | Error limits                     | 9-23             |
|   | Coordinate position              | 4-5              |
|   | Correction of measured values.   | 3-18             |
|   | Cross misclosure                 | 3-17             |
|   |                                  |                  |
| D | Data format                      | 7-21             |
|   | Data line                        | 7-21             |
|   | Data memory reorganization       | 7-13             |
|   | Data synchronization             | 7-15             |
|   | Data transfer                    | 7-14             |
|   | Date and time configuration      | 9-10             |
|   | Deleting of data records         | 7-11             |
|   | Detail points                    | 5-2              |
|   | Configuration                    |                  |
|   | Distance measurement             |                  |
|   | Formulae                         | 10-17; 10-18     |
|   | Free stationing                  | 4-7              |
|   | Stationing on a known point      | 4-15             |
|   | Distance tracking                | 5-9              |
| Е | Earth radius configuration       | 9-21             |
|   | Eccentricity                     |                  |
|   | Eccentric measuring              |                  |
|   | Detail points                    | 5-3              |
|   | Point determination in a loca    |                  |
|   | Eccentric station                |                  |
|   | Editor                           | 7-2              |
|   | EDM calibration                  | 9-4              |
|   | Error handling (Free Stationing) | 4-12             |
|   | Error messages                   |                  |
|   | Error limits                     |                  |
|   | Definition                       | 9-15 cont.       |
|   | Free stationing                  |                  |
|   | On/Off                           |                  |
|   | Symbol                           |                  |
|   |                                  |                  |

| F | Filtering of records<br>Fine levelling<br>Fine centering<br>Free Stationing<br>Configuration   | 3-3<br>3-3<br>4-2  |
|---|--|--|
|   | Funktion keys  |  |
| G | Geometry problems<br>(Station and 3 BP's are on a circle).<br>Georadio   |  |
| H | <ul> <li>Height adjustment</li> <li>Eccentric station</li> <li>Free stationing</li> <li>Heightstationing</li> <li>Height reduction</li> <li>Formulae</li> <li>On/Off</li> <li>Heightstationing</li> <li>Configuration</li> <li>Hidden point measurement</li> <li>Detail point</li> <li>Measuring in a local system</li> <li>Object height measurement</li> <li>(Detail Points)</li> <li>Object height measurement</li> <li>(Measuring in a local system)</li> <li>Hotkeys</li> </ul> | 4-2<br>4-20<br>4-11<br>9-16<br>9-16<br>9-17<br>9-17<br>5-6<br>3-15<br>3-8<br>5-7<br>3-16 |
| I | Incrementation<br>Instrument errors  |  |
|   | IIISUUIIIEIILEIIUIS  |  |

## Index

|   | Instrument height  |                                       |
|---|--|---------------------------------------|
|   | Eccentric station<br>Free stationing<br>Heightstationing<br>Measuring in a local system<br>Stationing on a known point<br>Interface (RS232C)   | 4-2<br>4-19<br>3-8<br>4-15            |
| к | Keyboard<br>Keys and Function  |                                       |
| L | Length misclosure<br>Levelling   |                                       |
| Μ | Main Menu<br>Markings<br>Configuration<br>Generating new markings<br>Store markings<br>Measuring in a local system<br>Menu guidance<br>Motorized directions and<br>Hz circle orientation | 9-25<br>9-27<br>9-34<br>3-8<br>2-63   |
| Ν | Neighbourhood principle  | 4-11                                  |
| 0 | Object height measurement2<br>Optical plummet2<br>Oriented Hz-direction (Orientation)<br>Configuration<br>Output filter  | -2; 3-2 cont.<br>5-2; 5-7<br>9-7; 9-8 |
| Ρ | Periphery switch<br>Perpenticular position<br>Plane adjustment<br>Point-to-line distance<br>Point identification P.I.<br>Filtering<br>Input  | 3-16<br>4-2<br>6-2<br>7-5; 7-6        |
|   | Markings   |                                       |

|   | Position of the prism (Setting out) | 5-8             |
|---|-------------------------------------|-----------------|
|   | Pressure input                      | 3-8             |
|   | Prism constant                      |                 |
|   | Formulae                            |                 |
|   | Input                               | 3-8             |
|   | Prism sensors                       |                 |
|   | Configuration                       | 9-9             |
|   | Prism tracking                      |                 |
|   | Configuration                       |                 |
|   | Datentransfer                       |                 |
|   | Project                             |                 |
|   | Connect                             | 3-6             |
|   | Сору                                | 3-7             |
|   | Create a new project                |                 |
|   | Delete, Edit, Rename                |                 |
|   | Project information                 |                 |
|   | Project management                  |                 |
|   | Point number                        |                 |
|   | Filtering                           | 7-7             |
|   | Searching                           | 7-8             |
| Q | QuickLock                           |                 |
|   | Configuration                       | 9-9             |
|   | Laser beam safety                   | 2-32            |
|   | Operation                           | 2-17            |
| R | Radial misclosure                   | 3-17            |
|   | Recording                           | . 4-3; 4-5; 5-2 |
|   | Connecting distance                 |                 |
|   | Inputs                              | 7-3             |
|   | Setting out                         |                 |
|   | Switch On/Off                       |                 |
|   | Recording modes                     |                 |
|   | Configuration                       | 9-22            |
|   | Hidden point                        |                 |
|   | Selection                           |                 |

| Reductions                             | 4-11  |
|--|-------|
| Configuration                          | 9-16  |
| Reduction formulae                     | 10-18 |
| Reduction into the plane               | 4-11  |
| Configuration                          | 9-16  |
| Formulae                               | 10-19 |
| Reference point Object height measuren | nent  |
| Detail points                          | 5-7   |
| Measuring in a local system            | 3-16  |
| Refraction coefficient configuration   | 9-21  |
|  |       |
| Robotic                                | 2-36  |
| Robotic<br>Remote Target (RMT)         |       |
|  | 7-20  |

## S Scale

| Configuration Stationing    | 9-14; 9-16    |
|-----------------------------|---------------|
| Eccentric station           | 4-24          |
| Free stationing             | 4-5; 4-8      |
| Local system scale factor   | 3-8; 3-9      |
| Stationing on a known point | 4-17          |
| Scale factor                | 4-11          |
| Scale range 4-10            | ); 4-12; 4-24 |
| Configuration               | 9-16          |
| Searching for data records  | 7-8           |
| Search                      |               |
| Search window               | 2-29          |
| Search for point numbers    | 7-10          |
| Servo                       |               |
| Setting out                 | 5-12          |
| Configuration               |               |
| Position of the prism       | 5-13          |
| Sighting axis correction8   | -3; 8-4 cont. |
| Sighting axis error         | 8-3           |
| Single point adjustment     | 4-7           |
| Softkeys (Function keys)    | 2-2 cont      |
| Station height input        | 4-20          |
| Stationing                  | 4-2           |
| Configuration               | 9-14          |
|                             |               |

|   | Stationing on a known point4-15         |
|---|---|
|   | Check5-15                               |
|   | Configuration9-14                       |
|   | Status symbols10-2                      |
|   | Symbols (Status)10-2                    |
| т | Target height                           |
|   | Free stationing4-3                      |
|   | Measuring in a local system             |
|   | Technical Data10-13                     |
|   | Telescope focussing                     |
|   | Temperature                             |
|   | Display modification9-6                 |
|   | Influence on the distance accuracy3-18  |
|   | Input                                   |
|   | Time block9-32                          |
|   | Time search option7-8                   |
|   | Tracker, Tracker Unit2-16               |
|   | Tracking5-10                            |
|   | TrackLight <sup>®.</sup> 2-18           |
|   | Transformation4-6; 4-10                 |
|   | Configuration9-14                       |
|   | Trunnion axis error8-3                  |
| U | Units configuration9-6                  |
|   | UTM Coordinates4-11; 9-16               |
| v | Verifying on calibration distances10-20 |
|   | Vertical index correction8-3; 8-4       |
|   | Vertical index error                    |
|   | Vertical reference system9-7; 10-4      |
| w | Weather correction10-17; 10-20          |
|   | Weight definition9-16                   |
|   | Window2-29                              |
| z | Zenith Angle9-7                         |