


# GeoSWITCH



## Quick Start Guide

## CONNECTING THE SYSTEM



Connect the cable with the 12 pin Deutsch connector from the GeoSWITCH to the CFX Display port A or to the FmX Display port A or B.  
 Connect the other cable from the GeoSWITCH with the Serial Connector to the Bogballe or with the 4 pin Deutsch CAN connector the the Grimme Terminal adapter cable.

## CONFIGURING THE TRIMBLE DISPLAY

Your Display must be unlocked for Variable Rate Application. For the FmX Display the Serial Rate plug-in must be loaded. When configuring the implement Rate controller type, choose Trimble. The implement settings in the display will be automatically set according to connected implement Terminal. When the implement settings have changed the GeoSWITCH will time out and reboot to reinitialize the implement settings of the display. The GeoSWITCH stores the last used settings in memory.

**NB:** With a FmX Display you must have the Rate Control switched ON in the VRA Settings to have the VRA plug-in tab with the section control override button in your work screen.

## CONFIGURING THE BOGBALLE TERMINAL

Bogballe has headland management commands over the serial RS232 interface implemented in the following products:

CALIBRATOR ZURF software version 1.12 or higher

CALIBRATOR ICON software version 1.12 or higher

CALIBRATOR UNIQ software version 1.12 or higher

If necessary contact your Bogballe Dealer to update the Terminal.

## FIELD OPERATION WITH BOGBALLE

With all systems connected and turned on, set the desired working width in the Bogballe Terminal. When changed the GeoSwitch will reboot and re-initialize the communication with the Trimble Display to upload the new width. Open the field to start operation.

For reasons of a fertilizer spreader applying the material 'far' behind the implement, Bogballe uses automatic delayed starting and stopping of the spreading in normal operation. This delay is half a swath width. The start and stop delay is not visible in the coverage logging. When working in *Trend to Border* or *Trend from Border* mode the delay is not used.

When working in *Trend from Border* mode the sections at the right of the spreader are turned off. Only the sections behind the spreader and to the left are used for coverage logging.

Bogballe sets the rate to zero (turns off all sections) when less than a quarter of the full width is engaged. The system uses a specific section lay-out to accommodate this and the *Trend from Border* mode.

## CONFIGURING THE GRIMME TERMINAL

The GeoSWITCH can communicate with Grimme planters using a VC50 or CCI terminal in combination with an MDA machine controller. For good performance row individual hydraulic drive is recommended. The old style electric row dis-engage actuators have too long and too much variation in delay times.

Ask your Grimme Dealer to update the Terminal and MDA Controller.

The Grimme Dealer also must activate the Task Control and list the Task Control Button in one of the workscreens.

## FIELD OPERATION WITH GRIMME

With all systems connected and turned on, the GeoSwitch will upload the Grimme Planter settings to the Trimble Display. Open a field to start operation.

To enable section control:

- Set the Grimme Task Controller to ON
- Lower de planter to activate the master switch
- Drive forward:
  - The planter wheels must detect forward speed for the application control to start.
  - The GPS must go over 0.5km/h to start section control.

For automatic row shut off at the headland:

- Use Headland guidance pattern.
- Set the overlap/infill to inner boundary.

